

[Manuals.plus](#) /

› [Minka Lavery](#) /

› Minka Lavery 5750-77 1-Light Chrome Down Pendant Instruction Manual

Minka Lavery 5750-77

Minka Lavery 5750-77 1-Light Chrome Down Pendant Instruction Manual

Model: 5750-77

[Installation](#) [Operation](#) [Safety Information](#) [Package Contents](#) [Setup &](#)
[Maintenance](#) [Troubleshooting](#) [Specifications](#) [Warranty](#) [Support](#)

INTRODUCTION

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Minka Lavery 5750-77 1-Light Chrome Down Pendant. Please read all instructions carefully before beginning installation and retain this manual for future reference.





Image: Detail of the Minka Lavery 5750-77 pendant light's textured finish, showcasing the material and design of a key component.

SAFETY INFORMATION

WARNING: Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing. Consult a qualified electrician if you are unsure about electrical wiring.

- Read all instructions carefully before installation.
- Ensure the electrical supply is turned off at the main circuit breaker or fuse box before handling any wiring.
- All electrical connections must be in accordance with local codes, ordinances, or the National Electric Code (NEC).
- Use only UL listed wire connectors.

- Do not exceed the recommended wattage for the bulb.
- This fixture is designed for indoor use only.

PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not attempt to assemble or install the fixture.

- Mounting Bracket
- Canopy
- Fixture Body (Pendant)
- Etched Opal Glass Shade
- Mounting Hardware (screws, wire nuts)
- Instruction Manual
- *Note: A-19, Medium base bulbs are required but not included.*

SETUP & INSTALLATION

Follow these steps to properly install your pendant light fixture.

1. **Turn Off Power:** Locate the circuit breaker or fuse box controlling the power to the installation location. Turn off the power completely.
2. **Prepare Mounting Bracket:** Attach the mounting bracket to the junction box in the ceiling using the provided screws. Ensure the bracket is securely fastened.
3. **Adjust Cord Length (if applicable):** If your pendant features an adjustable cord, determine the desired hanging height and adjust the cord length accordingly. Secure any excess cord within the canopy or junction box.
4. **Wire Connections:**
 - Connect the **green or bare copper ground wire** from the fixture to the **green or bare copper ground wire** from the junction box using a wire nut.
 - Connect the **white (neutral) wire** from the fixture to the **white (neutral) wire** from the junction box using a wire nut.
 - Connect the **black (hot) wire** from the fixture to the **black (hot) wire** from the junction box using a wire nut.
 - Ensure all wire connections are secure and insulated.
5. **Mount Canopy:** Carefully push the wired canopy up to the ceiling, aligning the mounting holes with the screws on the mounting bracket. Secure the canopy in place with the decorative nuts or screws provided.
6. **Install Glass Shade:** Attach the Etched Opal Glass shade to the fixture body according to the specific design. This typically involves threading it onto a socket ring or securing it with small screws.
7. **Install Bulb:** Screw one A-19, Medium base incandescent bulb (not included) into the socket. Do not exceed the maximum wattage specified in the specifications section.
8. **Restore Power:** Once installation is complete and all components are secure, restore power at the circuit breaker or fuse box.

OPERATING INSTRUCTIONS

The Minka Lavery 5750-77 pendant light operates via a standard wall switch connected to the circuit. Simply toggle the wall switch to turn the light fixture on or off.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your pendant light.

- **Cleaning:** To clean the fixture, ensure the power is off. Wipe with a soft, dry cloth. Do not use abrasive cleaners, polishes, or solvents as they may damage the finish.
- **Glass Shade Cleaning:** The Etched Opal Glass shade can be gently wiped with a damp cloth and mild soap if necessary, then dried thoroughly.
- **Bulb Replacement:**
 - a. Turn off power at the circuit breaker.
 - b. Allow the old bulb to cool completely before touching.
 - c. Carefully unscrew the old bulb.
 - d. Screw in a new A-19, Medium base incandescent bulb, ensuring it does not exceed the maximum wattage.
 - e. Restore power.

TROUBLESHOOTING

If your pendant light is not functioning correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Faulty bulb. Faulty wall switch.	Check circuit breaker/fuse. Turn off power, check all wire connections. Replace bulb. Consult a qualified electrician.
Light flickers.	Loose bulb. Loose wire connection. Incorrect bulb type/wattage.	Tighten bulb. Turn off power, check all wire connections. Ensure correct bulb type and wattage.

If the problem persists after attempting these solutions, contact customer support or a qualified electrician.

SPECIFICATIONS

Model Number:	5750-77
Brand:	Minka Lavery
Light Source Type:	Incandescent
Number of Light Sources:	1
Bulb Type:	A-19, Medium Base (not included)
Voltage:	120 Volts
Material:	Stone
Finish:	Chrome
Product Dimensions:	9 x 9 x 8.5 inches

Item Weight:	20.6 pounds
Mounting Type:	Ceiling Mount
Certification:	UL Listed

WARRANTY INFORMATION

The Minka Lavery 5750-77 1-Light Chrome Down Pendant comes with a limited one-year warranty from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage resulting from improper installation, accident, misuse, abuse, or unauthorized modifications. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For technical assistance, missing parts, or warranty inquiries, please contact Minka Lavery customer service. Refer to the official Minka Lavery website for current contact information.
You can also visit the [Minka Lavery Store on Amazon](#) for more product information.

© 2024 Minka Lavery. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

