

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [TW Steel](#) /

› [TW Steel Goliath TW118W Chronograph Watch User Manual](#)

TW Steel TW118W

TW Steel Goliath TW118W Chronograph Watch User Manual

Model: TW118W

INTRODUCTION

Thank you for choosing the **TW Steel Goliath TW118W Chronograph Watch**. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read it thoroughly to ensure optimal performance and longevity of your watch.

The TW Steel Goliath TW118W features a robust stainless steel case, a stylish white leather strap, and a precise quartz chronograph movement. Its elegant design is complemented by a fixed silver-tone bezel set with diamonds, a white dial with clear Arabic numeral hour markers, and functional sub-dials for chronograph measurements.



Figure 1: Front view of the TW Steel Goliath TW118W Chronograph Watch, showcasing its white dial, sub-dials, and diamond-set bezel.

SETUP

Before using your watch, familiarize yourself with its components:

- **Crown (B):** Used for setting time and date.
- **Pusher A:** Used to start/stop the chronograph.
- **Pusher C:** Used to reset the chronograph.



Figure 2: Side view illustrating the crown (B) and chronograph pushers (A and C).

Setting the Time

1. Pull the crown (B) out to position 2. The second hand will stop.
2. Turn the crown (B) clockwise or counter-clockwise to set the hour and minute hands.
3. Push the crown (B) back to position 0 (normal position). The second hand will resume movement.

Setting the Date

1. Pull the crown (B) out to position 1.
2. Turn the crown (B) counter-clockwise to set the date.
3. Push the crown (B) back to position 0 (normal position).

Note: Avoid setting the date between 9:00 PM and 3:00 AM, as this may interfere with the automatic date change mechanism.

OPERATING INSTRUCTIONS

Chronograph Function

Your TW Steel Goliath TW118W watch is equipped with a chronograph function, allowing you to measure elapsed time. The three sub-dials display 60 minutes, 60 seconds, and 24 hours.

- **Start/Stop:** Press pusher A to start the chronograph. Press pusher A again to stop it.
- **Reset:** While the chronograph is stopped, press pusher C to reset all chronograph hands to their zero positions.



Figure 3: The watch dial highlighting the 60-minute, 60-second, and 24-hour chronograph sub-dials.

MAINTENANCE

Cleaning

Regularly clean your watch with a soft, dry cloth. For the leather strap, avoid excessive moisture and harsh chemicals. If the strap becomes dirty, gently wipe it with a slightly damp cloth and allow it to air dry completely before wearing.

Water Resistance

This watch is water resistant up to **100 meters (330 feet)**. It is suitable for showering, swimming, and snorkeling, but not for diving. Always ensure the crown is fully pushed in before any contact with water to

maintain water resistance.



Figure 4: Rear view of the watch case, indicating its water resistance rating.

Battery Replacement

The watch is powered by a quartz movement and requires a battery. When the battery is low, the second hand may jump in two-second intervals as an End-of-Life (EOL) indicator. Battery replacement should be performed by a qualified watch technician to avoid damage to the movement or case and to ensure water resistance is maintained.

Strap Care

The white leather strap is durable but can be affected by sweat, moisture, direct sunlight, and cosmetics. To prolong its life, avoid prolonged exposure to extreme temperatures and direct sunlight. If the strap gets wet, dry it thoroughly with a soft cloth and allow it to air dry naturally.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Watch not running	Battery depleted	Replace battery (professional service recommended).
Hands not moving smoothly or irregularly	Impact or strong magnetic field exposure	Consult a professional watch repair service.
Date not changing at midnight	Time set incorrectly (AM/PM cycle)	Advance the time by 12 hours.
Chronograph hands not resetting to zero	Requires calibration	Consult a professional watch repair service for adjustment.

SPECIFICATIONS

Feature	Detail
Model Number	TW118W
Case Material	Stainless Steel
Case Diameter	39 mm
Case Thickness	13 mm
Dial Color	White
Bezel	Fixed Silver-tone, set with Diamonds
Crystal	Scratch Resistant Mineral
Strap Material	White Leather
Band Width	24 mm
Movement	Quartz Chronograph
Water Resistance	100 meters (330 feet)
Functions	Hours, Minutes, Seconds, Date, Chronograph (60 minutes, 60 seconds, 24 hours)
Item Weight	27.2 g

WARRANTY AND SUPPORT

For warranty information and support regarding your TW Steel Goliath TW118W watch, please **contact the seller of record directly**. It is important to retain your proof of purchase for any warranty claims.

For technical assistance, complex repairs, or battery replacement beyond basic user maintenance, it is highly recommended to consult an authorized TW Steel service center or a qualified watchmaker to ensure proper handling and preservation of your watch's integrity and water resistance.

Related Documents - TW118W

	<p><u>TW Steel 8040.B Ronda Movement Watch User Manual and Maintenance Guide</u></p> <p>Comprehensive user manual for the TW Steel 8040.B watch, featuring the Ronda 8040.B movement. This guide provides detailed instructions on watch maintenance, setting the time and date, and operating the chronograph functions, including basic, accumulated, and interval timing, as well as adjusting the chronograph hands to their zero positions.</p>
	<p><u>TW Steel 6S10 Watch: User Manual and Instructions</u></p> <p>Detailed instructions and maintenance guide for the TW Steel 6S10 watch featuring a Miyota movement. Learn how to set time, date, use the chronograph, and reset functions.</p>
	<p><u>TW Steel 5030.D Watch User Manual - Operation and Maintenance</u></p> <p>Comprehensive user manual for the TW Steel 5030.D watch, detailing operation, maintenance, chronograph functions, and care instructions for the Ronda movement.</p>
	<p><u>TW Steel VK63 Chronograph Watch User Manual</u></p> <p>User manual for the TW Steel VK63 chronograph watch, detailing maintenance, setting the time and date, and operating the chronograph functions. Features a Seiko VK63 movement.</p>
	<p><u>TW Steel 6S21 Miyota Movement Watch User Manual and Maintenance Guide</u></p> <p>User manual for TW Steel watches with the 6S21 Miyota movement, covering maintenance, time and date setting, and chronograph operation. Includes instructions and care tips.</p>
	<p><u>TW Steel Z60 Watch User Manual and Operating Instructions</u></p> <p>Comprehensive guide to operating and maintaining your TW Steel Z60 watch, including setting time, date, day of the week, and using chronograph functions. Learn how to adjust chronograph hands and care for your timepiece.</p>