

TOMY 45-163003

TOMY TRANSFORMER Starscream G1 Instruction Manual

Model: 45-163003

INTRODUCTION

Welcome to the instruction manual for your TOMY TRANSFORMER Starscream G1 action figure. This collectible figure is a remake of the original G1 Starscream, the second-in-command of the Decepticons, capable of transforming into a Cybertronian Jet. This manual provides essential information for assembly, operation, and care of your figure.

SAFETY INFORMATION

- Recommended for ages 8 years and up.
- Keep small parts away from young children to prevent choking hazards.
- Avoid excessive force during transformation to prevent damage to the figure.

PACKAGE CONTENTS

Please ensure all components are present upon opening the package:

- Starscream G1 Action Figure

SETUP

Your Starscream figure comes pre-assembled in robot mode. No initial assembly is required beyond removing it from its packaging.

OPERATING INSTRUCTIONS: TRANSFORMATION

This section details the steps to transform Starscream between Robot Mode and Cybertronian Jet Mode. Always handle the figure with care during transformation.

Transforming from Robot Mode to Cybertronian Jet Mode

1. Step 1: Position Arms.

Rotate the arms upwards and inward, aligning them with the torso.

2. Step 2: Fold Legs.

Fold the legs backward and secure them against the underside of the main body.

3. **Step 3: Adjust Wings.**

Extend the wings from the back and position them to form the jet's wingspan.

4. **Step 4: Rotate Cockpit.**

Rotate the cockpit section forward to form the nose of the jet.

5. **Step 5: Attach Weapons (if applicable).**

Attach any included weapons to the designated ports on the jet wings or underside.



Image: Starscream G1 figure displayed in its Cybertronian Jet mode. The figure is predominantly grey with red and blue accents, featuring the Decepticon insignia on its wings. The cockpit is visible at the front, and the twin engines are positioned at the rear.

Transforming from Cybertronian Jet Mode to Robot Mode

1. **Step 1: Detach Weapons (if applicable).**

Remove any attached weapons.

2. **Step 2: Retract Cockpit.**

Rotate the cockpit section backward to reveal the robot's head.

3. **Step 3: Fold Wings.**

Fold the wings inward and secure them against the robot's back.

4. **Step 4: Extend Legs.**

Unfold the legs from the underside and position them for robot stance.

5. **Step 5: Position Arms.**

Rotate the arms downward and outward to their robot mode position.



Image: Starscream G1 figure displayed in its Robot mode. The figure stands upright, showcasing its humanoid form with jet components integrated into its back and arms. The grey, red, and blue color scheme is prominent, along with the Decepticon insignia.

MAINTENANCE

- **Cleaning:**
Wipe the figure gently with a dry, soft cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the paint or plastic.
- **Storage:**
Store the figure in a cool, dry place away from direct sunlight to prevent discoloration or material degradation. Keep it away from extreme temperatures.
- **Joint Care:**
If joints become stiff, gently manipulate them. Do not force movement. If they become loose, this is typically a characteristic of the toy's design and not easily adjustable without specialized tools.

TROUBLESHOOTING

- Problem: Parts do not fit together during transformation.**
Solution: Ensure all previous steps are completed correctly and that parts are aligned properly. Do not apply excessive force. Refer to the transformation steps again, paying close attention to the order and direction of movement.
- Problem: Figure feels loose or unstable.**
Solution: This can be a characteristic of some action figures. Ensure all joints are fully extended or retracted as per the mode. For persistent looseness, gentle repositioning may help, but significant repairs are generally not recommended for collectible items without expert knowledge.

SPECIFICATIONS

Model Number	45-163003
Brand	TOMY
Manufacturer	Takara

Product Dimensions	12 x 12 x 12 inches (approximate)
Item Weight	1.1 pounds (approximate)
Recommended Age	8 years and up

WARRANTY INFORMATION

This product is a collectible item. Please refer to the original packaging or contact TOMY customer support for specific warranty details, if any. Typically, collectible figures may have limited or no warranty coverage for wear and tear from play or transformation.

CUSTOMER SUPPORT

For further assistance or inquiries regarding your TOMY TRANSFORMER Starscream G1 figure, please visit the official TOMY website or contact their customer service department.

Online Resources: [TOMY Official Store on Amazon](#)

© 2024 TOMY. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question