

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Titan](#) /
- › [Titan Tools 11018 Folding Pocket Utility Knife Instruction Manual](#)

## Titan 11018

# Titan Tools 11018 Folding Pocket Utility Knife Instruction Manual

Model: 11018

## INTRODUCTION

The Titan Tools 11018 Folding Pocket Utility Knife is designed for various cutting tasks, offering convenience and portability. This manual provides essential information for its safe and proper use, including blade installation, operation, and maintenance.



Image: The Titan Tools 11018 Folding Pocket Utility Knife in its compact, folded position, showcasing its blue handle and the Titan logo.

## Key Features:

- Quick-change blade mechanism requires no additional tools.
- Integrated folding lock for enhanced safety during storage and transport.

- Equipped with an easy-carry belt clip for convenient access.
- Includes a dispenser with 5 extra blades for extended use.
- Folds into a compact size for easy and safe storage.

## SAFETY INFORMATION

---

Always exercise extreme caution when handling any utility knife. Blades are very sharp and can cause severe injury if not handled properly.

- **Keep out of reach of children.**
- Always ensure the blade is fully retracted or the knife is folded and locked when not in use.
- Wear appropriate personal protective equipment, such as gloves, when changing blades or performing cutting tasks.
- Cut away from your body and use a stable cutting surface.
- Never use a dull or damaged blade, as it can slip and cause injury. Replace blades promptly.
- Dispose of used blades safely in a designated container.

## SETUP: BLADE INSTALLATION AND REPLACEMENT

---

The Titan Tools 11018 features a quick-change blade mechanism that allows for tool-free blade replacement.


1. **Open the Knife:** Carefully unfold the knife until the blade holder is fully extended.
2. **Remove Old Blade (if applicable):** Locate the blade release button or lever on the blade holder. Press down on this mechanism. While holding it down, carefully slide the old blade out from the front of the holder.
3. **Insert New Blade:** Take a new standard utility knife blade. Align the notches on the blade with the pins in the blade holder. While still pressing the release mechanism, slide the new blade into the holder until it clicks securely into place. Release the mechanism to lock the blade.
4. **Verify Security:** Gently tug on the blade to ensure it is firmly seated and locked before use.

# TITAN®

## Folding Utility Knife

**Quick-Change Blade  
Requires No Tools**

**Easily Press  
Down & Carefully  
Slide Out Blade**



**Flip Blade or  
Replace Blade**

Image: A close-up view of hands demonstrating how to easily press down and slide out a blade from the utility knife, highlighting the quick-change feature.

The knife includes a handy dispenser with 5 extra blades. These are standard utility knife blades (Titan #11034 compatible).



**Includes 5 Extra  
Blades in Handy  
Dispenser**

**Accepts Standard Utility  
Knife Blades. Titan #11034**

Image: The Titan Tools utility knife displayed alongside a dispenser containing five extra blades, illustrating the included accessories.

## OPERATING INSTRUCTIONS

### Unfolding and Folding the Knife:

1. **To Unfold:** Hold the knife firmly. Locate the thumb stud or opening mechanism. Apply gentle pressure to swing the blade holder open until it locks into the fully extended position. Ensure the blade is securely locked before use.
2. **To Fold:** Locate the folding lock mechanism (often a lever or button near the pivot point). Press or slide this lock to disengage the blade holder. Carefully fold the blade holder back into the handle until it is fully closed and secured.



Image: A hand pressing the safety lock to carefully fold the utility knife, illustrating its compact storage capability.

### **Using the Knife:**

- Always ensure the blade is sharp and free from damage.
- Apply firm, even pressure when cutting.
- Use the knife for its intended purpose, such as cutting cardboard, plastic, or other materials. Avoid prying or twisting motions that could damage the blade or knife.

# TITAN®

## Folding Utility Knife



Image: The utility knife in action, demonstrating its effectiveness in cutting through different materials such as foam, cardboard, and mesh.

### **Belt Clip Functionality:**

The integrated belt clip allows for convenient and secure carrying.

- Attach the clip to a belt, pocket, or waistband for easy access.
- Ensure the knife is folded and locked when carried to prevent accidental deployment.

### Easy Carry Belt Clip



Image: The utility knife featuring its easy-carry belt clip, shown securely attached to the pocket of a pair of jeans.

## MAINTENANCE

- **Cleaning:** After each use, wipe the knife clean with a dry cloth to remove any debris or moisture. Avoid using harsh chemicals that could damage the handle or blade.
- **Lubrication:** If the folding mechanism becomes stiff, apply a small amount of light machine oil (e.g., 3-in-1 oil) to the pivot points. Operate the knife a few times to distribute the lubricant.
- **Blade Replacement:** Replace blades as soon as they become dull or damaged to maintain cutting efficiency and safety.
- **Storage:** Store the knife in its folded and locked position in a dry, safe place, away from moisture and out of reach of children.

## TROUBLESHOOTING

- **Blade is loose or slips out:**  
Ensure the blade is correctly seated and the quick-change mechanism has fully engaged and locked the blade in place. If the issue persists with a new blade, inspect the blade holder for any damage or wear.

- **Knife is difficult to open or close:**

The pivot points may require lubrication. Apply a small amount of light machine oil to the hinge and operate the knife several times. Ensure no debris is obstructing the mechanism.

- **Blade is not cutting effectively:**

The blade is likely dull. Replace it with a new, sharp utility blade.

## SPECIFICATIONS



Image: A diagram illustrating the dimensions of the Titan Tools folding utility knife when open (6 inches long, 1.25 inches wide) and folded (3.625 inches long, 1.5 inches wide).

Feature	Detail
Model Number	11018
Brand	Titan
Material	Titanium (Handle), Stainless Steel (Blade)
Color	Blue (Factory)
Item Weight	4.8 ounces (0.3 Pounds)
Product Dimensions	0.8 x 3.3 x 8.4 inches (unfolded)
Blade Type	Standard Utility Knife Blade

Special Features	Foldable, Quick-Change Blade, Belt Clip
UPC	802090110184

## WARRANTY AND SUPPORT

---

For specific warranty information or product support, please refer to the packaging or contact Titan Tools directly. Keep your purchase receipt as proof of purchase.

You can visit the official Titan Tools store for more information and contact options: [Titan Tools Store](#)

---

© 2026 Titan Tools. All rights reserved.