

[Manuals.plus](#) /

› [Nuvo](#) /

› Nuvo TH206 R30 Step Cylinder Track Head Instruction Manual

Nuvo TH206

Nuvo TH206 R30 Step Cylinder Track Head Instruction Manual

INTRODUCTION

This manual provides instructions for the Nuvo TH206 R30 Step Cylinder Track Head. This track head is designed for use with standard R30 bulbs and is suitable for various indoor lighting applications. It features a clean, simple design in a white finish, complementing diverse interior styles. The adjustable head allows for flexible light direction, making it ideal for accent or task lighting.



Image: The Nuvo TH206 R30 Step Cylinder Track Head in white, showcasing its design and compatibility with track lighting systems.

SETUP INSTRUCTIONS

Unpacking

Carefully remove the track head from its packaging. Inspect for any damage. Ensure all components are present.

Installation onto Track

The Nuvo TH206 R30 Step Cylinder Track Head is designed for easy, tool-free installation onto most standard track lighting systems.

1. Ensure the power to the track lighting system is turned OFF at the circuit breaker.

2. Align the track head's adapter with the track slot.
3. Insert the adapter into the track and twist to secure it in place. Ensure it clicks firmly.
4. Once secured, you can slide the track head along the track to your desired position.

Bulb Installation

1. Turn OFF the power at the circuit breaker.
2. Insert a standard E26 Medium base R30 bulb (not included) into the socket of the track head. Do not exceed the maximum wattage of 75 watts.
3. Turn the power ON at the circuit breaker.

OPERATING INSTRUCTIONS

Adjusting Light Direction

The track head features an adjustable design. You can tilt and rotate the head to direct light precisely where needed. This allows for highlighting specific areas, artwork, or architectural features.

Dimming Functionality

If paired with a compatible dimmer switch and a dimmable R30 bulb, the brightness of the track head can be adjusted to create various lighting atmospheres.

MAINTENANCE

Cleaning

To clean the track head, ensure the power is OFF and the bulb is cool. Wipe the exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents.

Bulb Replacement

1. Turn OFF the power to the track lighting system at the circuit breaker.
2. Allow the bulb to cool completely.
3. Carefully unscrew the old R30 bulb from the socket.
4. Screw in a new E26 Medium base R30 bulb, ensuring it is securely seated. Do not exceed 75 watts.
5. Restore power to the track lighting system.

TROUBLESHOOTING

Light Does Not Turn On

- Check if the power is ON at the circuit breaker.
- Ensure the bulb is correctly installed and not burnt out. Replace if necessary.
- Verify the track head is securely connected to the track.

Light Flickers

- Ensure the bulb is fully screwed in.
- If using a dimmer, ensure the bulb is dimmable and compatible with the dimmer switch.

- Check for loose connections in the track system.

SPECIFICATIONS

Feature	Detail
Brand	Nuvo
Model Number	TH206
Style	PAR30LN Step
Color	White
Material	Glass, Metal
Light Fixture Form	Track Light Head
Indoor/Outdoor Usage	Indoor
Power Source	Corded Electric
Light Source	Incandescent (compatible with R30 bulb)
Number of Light Sources	1
Voltage	120 Volts
Wattage	75 watts (max)
Bulb Base	E26 Medium
Item Dimensions (L x W x H)	4.5"L x 8.5"W x 6.5"H
Required Assembly	Yes
Safety Rating	UL Listed

WARRANTY INFORMATION

This product comes with a 1-year limited manufacturer's warranty. Please refer to the original purchase documentation for full details or contact Nuvo Lighting customer service for specific warranty terms and conditions.

CUSTOMER SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please contact Nuvo Lighting customer service. Contact information can typically be found on the manufacturer's official website or your product packaging.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question