

[manuals.plus](#) /

- > [WMF](#) /
- > **WMF Profi Plus Cheese Slicer (Model 18.7156.6030) Instruction Manual**

**WMF 18.7156.6030**

## WMF Profi Plus Cheese Slicer (Model 18.7156.6030) Instruction Manual

Brand: WMF

### 1. INTRODUCTION

Welcome to the instruction manual for your WMF Profi Plus Cheese Slicer. This manual provides essential information for the safe and effective use, care, and maintenance of your new kitchen tool. Please read these instructions carefully before first use and retain them for future reference.

### 2. PRODUCT OVERVIEW

The WMF Profi Plus Cheese Slicer (Model 18.7156.6030) is a traditional wire cheese slicer designed for effortless slicing of semi-hard cheeses. Crafted from high-grade Cromargan 18/10 stainless steel, this tool offers durability, resistance to food acids, and is dishwasher-safe. Its design ensures uniform slices and requires less force than a knife.



Image 1: WMF Profi Plus Cheese Slicer

### 3. SAFETY INSTRUCTIONS

- Always handle the cheese slicer with care. The cutting wire is taut and can be sharp.
- Keep the slicer out of reach of children.
- Do not attempt to slice extremely hard cheeses, as this may damage the wire or the slicer itself.
- Ensure your hands are dry when handling the slicer to maintain a firm grip.

### 4. SETUP

The WMF Profi Plus Cheese Slicer comes ready for use. No assembly is required.

1. **Unpack:** Carefully remove the cheese slicer from its packaging.
2. **Initial Cleaning:** Before first use, wash the slicer thoroughly with warm soapy water and dry completely.

### 5. OPERATING INSTRUCTIONS

Follow these steps to effectively slice cheese with your WMF Profi Plus Cheese Slicer:

1. **Prepare the Cheese:** Ensure your cheese is semi-hard (e.g., Cheddar, Edam). For best results, the

cheese should be firm and slightly chilled.

2. **Position the Slicer:** Place the cheese on a stable, flat surface. Position the wire of the slicer at the edge of the cheese block.
3. **Slice:** Apply gentle, even pressure and draw the slicer smoothly across the cheese. The wire will create a uniform slice.
4. **Adjusting Thickness:** The slicer is designed to produce consistent slices. For slight variations, some users find tilting the cheese block or adjusting the angle of the slicer can influence thickness, though the primary design is for a standard slice.



Image 2: Using the WMF Profi Plus Cheese Slicer

## 6. CLEANING AND MAINTENANCE

Proper cleaning and maintenance will ensure the longevity and performance of your cheese slicer.

- **Dishwasher Safe:** The slicer is completely dishwasher safe. Place it in the dishwasher with other

utensils.

- **Hand Washing:** For hand washing, use warm water and a mild dish soap. Carefully clean around the wire. Rinse thoroughly and dry immediately to prevent water spots.
- **Material Care:** Made from 18/10 stainless steel, the slicer is rust-resistant and resistant to food acids, ensuring long-lasting appearance and performance.
- **Wire Replacement:** Over time, the cutting wire may wear or break. Replacement wires are available separately and can be easily swapped out. Refer to the packaging of replacement wires for specific instructions on how to change them.

## 7. TROUBLESHOOTING

- **Wire Breaks:** If the cutting wire breaks, it can be replaced. Contact WMF customer support or refer to the replacement wire packaging for instructions.
- **Uneven Slices:** Ensure the cheese is consistently firm and that you are applying even pressure across the entire width of the cheese block. Practice may be required to achieve perfectly uniform slices.
- **Difficulty Slicing:** This slicer is intended for semi-hard cheeses. Attempting to slice very hard cheeses (like Parmesan) may cause difficulty or damage. Ensure the cheese is not too cold or too soft.

## 8. SPECIFICATIONS

Attribute	Detail
Brand	WMF
Model Number	18.7156.6030
Material	Cromargan 18/10 Stainless Steel
Blade Material	Stainless Steel (Wire)
Handle Material	Stainless Steel
Blade Edge	Plain (Wire)
Item Length	25.5 cm (10.04 inches)
Item Weight	0.09 kg (2.99 ounces)
Dishwasher Safe	Yes

## 9. WARRANTY AND SUPPORT

WMF provides a guarantee against manufacturing and material defects for the Profi Plus Cheese Slicer. For warranty claims, replacement parts (such as wires), or further assistance, please contact WMF customer support through their official website or the retailer where the product was purchased. Keep your proof of purchase for warranty validation.

**Related Documents - 18.7156.6030**





## WMF 1100 S Topping Rengjøringsmanual

Detaljerte instruksjoner for daglig og ukentlig rengjøring av kaffemaskinen WMF 1100 S Topping.