

TIMEX T2M518

Timex E Class Analog Black Dial Men's Watch - T2M518 User Manual

Model: T2M518

INTRODUCTION

This manual provides detailed instructions for the proper use and care of your Timex E Class Analog Black Dial Men's Watch, model T2M518. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece.



Image: Front view of the Timex E Class Analog Black Dial Men's Watch, model T2M518, showcasing its black dial, silver-tone stainless steel case, and bracelet.

SETUP

1. Initial Inspection

Upon unpacking, carefully inspect the watch for any visible damage. Ensure all protective films are removed from the crystal and case back.

2. Setting the Time

1. Gently pull the crown (the small knob on the side of the watch case) out to the time-setting position.
2. Rotate the crown clockwise or counter-clockwise to move the hands and set the correct time.
3. Once the time is set, push the crown back into its original position to engage the movement and start the watch.

3. Adjusting the Stainless Steel Bracelet

The stainless steel bracelet may require adjustment for a comfortable fit. This typically involves removing or adding links. It is recommended to have this procedure performed by a qualified jeweler or watch technician to prevent damage to the bracelet or watch.

4. Winding the Automatic Movement

Your Timex T2M518 watch features an automatic movement, which means it is powered by the motion of your wrist. For initial use or if the watch has stopped due to inactivity, it may need manual winding:

- With the crown in its normal, pushed-in position, rotate it clockwise approximately 20-30 times. This will provide enough power reserve to start the watch.
- Wearing the watch regularly will keep it wound. If worn daily, manual winding is generally not required.

OPERATING YOUR WATCH

Timekeeping

The watch displays hours, minutes, and seconds through its analog hands. Ensure the crown is fully pushed in for accurate timekeeping and water resistance.

Water Resistance

This watch is water resistant up to 100 meters (10 ATM). This rating makes it suitable for swimming and snorkeling, but it is not recommended for scuba diving. **Do not operate the crown or pushers while the watch is wet or submerged in water.**

- **30M (3 ATM):** Splash resistant.
- **50M (5 ATM):** Suitable for short periods of recreational swimming.
- **100M (10 ATM):** Suitable for swimming and snorkeling.
- **200M (20 ATM) or more:** Suitable for scuba diving.

MAINTENANCE AND CARE

Cleaning

To clean your watch, wipe the case and bracelet with a soft, damp cloth. For stainless steel bracelets, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid using harsh chemicals or abrasive materials.

Storage

When not wearing the watch, store it in a cool, dry place away from direct sunlight, extreme temperatures, and strong magnetic fields. A watch box or pouch is ideal for protection.

Avoiding Extreme Conditions

- **Temperature:** Avoid exposing the watch to sudden temperature changes or extreme temperatures (below 0°C / 32°F or above 60°C / 140°F).

- **Shocks:** Protect the watch from strong impacts or vibrations.
- **Chemicals:** Keep the watch away from solvents, detergents, perfumes, and cosmetics, as these can damage the case, gasket, or bracelet.
- **Magnetic Fields:** Strong magnetic fields can affect the accuracy of the automatic movement. Avoid placing the watch near speakers, refrigerators, or other magnetic devices.

TROUBLESHOOTING

Watch Not Running or Stopping Frequently

- **Automatic Movement:** Ensure the watch is sufficiently wound. If it has been inactive, manually wind it by rotating the crown 20-30 times while it's in the pushed-in position.
- **Insufficient Wear:** Automatic watches require regular wear to stay wound. If you wear it infrequently, consider using a watch winder.

Time Inaccuracy

- **Magnetic Interference:** Check if the watch has been exposed to strong magnetic fields. Demagnetization may be required by a professional.
- **Service Interval:** Mechanical watches typically require servicing every 3-5 years to maintain accuracy.

Water Inside the Watch

If you notice condensation or water inside the watch, immediately take it to an authorized service center. Do not attempt to open the watch yourself, as this can void the warranty and cause further damage.

SPECIFICATIONS

Brand	TIMEX
Model Number	T2M518AU
Display Type	Analog
Movement Type	Automatic
Case Material	Stainless Steel
Case Diameter	44 Millimetres
Case Thickness	12 Millimetres
Band Material Type	Stainless Steel
Band Colour	Silver
Band Width	20 Millimetres
Dial Colour	Black
Crystal Material	Mineral
Water Resistance Depth	100 Metres
Item Weight	500 Grams

Product Dimensions	13 x 13 x 13 cm
Closure Type	Push-Button
UPC	753048275687

WARRANTY AND SUPPORT

Warranty Information

Your Timex T2M518 watch comes with a **1-year manufacturer warranty** from the date of purchase. This warranty covers manufacturing defects under normal use.

How to Avail Warranty:

- To claim your warranty, you must produce either the original bill copy/invoice or the warranty card.
- Present these documents at any authorized Timex service center.

Customer Support

For any service-related inquiries or feedback, please contact Timex India customer support:

- **Toll-Free Number:** [1800 419 2727](tel:18004192727) (Monday to Sunday, 10:00 am to 7:00 pm, except government holidays)
- **Email Support:** custservice@timexindia.com, feedback@timexindia.com

For more information, you can visit the official Timex store on Amazon:[Timex Store](#)

© 2024 TIMEX. All rights reserved. This manual is for informational purposes only.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000RE9AGO>

More documents and user manuals: <https://manuals.plus/>