

Timex T2H371

Timex Women's Easy Reader 25mm Watch Instruction Manual

Model: T2H371

Brand: Timex

1. PRODUCT OVERVIEW

The Timex Women's Easy Reader 25mm Watch (Model T2H371) is designed for clear readability and comfortable wear. It features a classic analog display with full Arabic numerals, a date window, and an INDIGLO backlight for visibility in low light conditions. The watch is equipped with a durable stainless steel expansion band and is water-resistant up to 30 meters.



Figure 1: Front view of the Timex Women's Easy Reader 25mm Watch.

2. SETUP AND INITIAL USE

2.1 Setting Time and Date

1. **Pull the Crown:** Gently pull the crown (the small knob on the side of the watch case) out to the first or second position.
2. **Set the Date:** If your watch has a date function, pull the crown to the first position and turn it clockwise or counter-clockwise to adjust the date.
3. **Set the Time:** Pull the crown to the second position. Turn the crown to move the hands clockwise until the desired time is displayed. Ensure you set the correct AM/PM for the date change.
4. **Push the Crown In:** Once the time and date are set, push the crown back into its original position against the watch case to start the watch movement.



Figure 2: Side view of the watch, highlighting the crown for time and date adjustment.

2.2 Adjusting the Expansion Band

This watch features a stainless steel expansion band designed for easy slip-on comfort. The band is self-adjusting to fit most wrist sizes up to 7.5 inches. No manual adjustment or tools are typically required for sizing.



Figure 3: The watch worn on a wrist, demonstrating the fit of the expansion band.

Your browser does not support the video tag.

Video 1: Timex Sizing Chart. This video provides a visual guide to watch sizing, which can be helpful for understanding how different case sizes appear on various wrist dimensions.

3. OPERATING INSTRUCTIONS

3.1 INDIGLO Night-Light

The INDIGLO night-light illuminates the watch dial for easy reading in the dark. To activate the INDIGLO night-light, simply press and hold the crown (the same button used for setting the time) for a few seconds. The dial will glow, allowing you to read the time clearly.

Your browser does not support the video tag.

Video 2: Timex Women's Easy Reader Date Expansion Band Watch. This video demonstrates the watch's features, including the expansion band and potentially the INDIGLO function.

4. MAINTENANCE

4.1 Water Resistance

This watch is water-resistant to 30 meters (100 feet). This means it is suitable for splashes, rain, or brief immersion in water. It is **not** recommended for swimming, showering, or diving. Always ensure the crown is fully pushed in to maintain water resistance.

4.2 Cleaning Your Watch

To clean your watch, wipe the case and band with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these can damage the finish. For the expansion band, ensure it is dry after cleaning to prevent any residue buildup.

5. TROUBLESHOOTING

- **Watch Not Running:** Ensure the crown is fully pushed in. If the watch still does not run, the battery may need replacement.
- **Date Not Changing:** Check if the time is set correctly for AM/PM. The date typically changes around midnight.
- **INDIGLO Not Working:** Ensure the crown is pressed firmly. If it still doesn't light up, the battery might be low or depleted.

For further assistance, please refer to the warranty information or contact Timex customer support.

6. SPECIFICATIONS

Feature	Detail
Model Number	T2H371
Case Diameter	25 Millimeters
Case Material	Brass
Band Material	Stainless Steel
Band Width	12 Millimeters
Band Length	7 Inches

Dial Color	White
Display Type	Analog
Movement Type	Quartz
Water Resistance Depth	30 Meters (100 Feet)
Power Source	Battery Powered (1 Lithium Metal battery included)
Item Weight	0.06 Pounds




Figure 4: Watch dimensions for reference.

7. WARRANTY AND SUPPORT

7.1 Warranty Information

This Timex watch comes with a Limited Lifetime Warranty provided by the manufacturer. Please refer to the warranty card included with your purchase for specific terms, conditions, and coverage details.

7.2 Customer Support

For any questions, technical assistance, or warranty claims, please contact Timex customer support. Contact information can typically be found on the official Timex website or in the documentation provided with your watch.

Your browser does not support the video tag.

Video 3: Easy Reader Women. This video showcases the Timex Easy Reader watch, highlighting its design and features.

