Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Intex 69627E

Intex 69627 Kayak Paddle Set Instruction Manual

Model: 69627E | Brand: Intex

Introduction

The Intex 69627 Kayak Paddle Set is designed for versatility, functioning as either a single kayak paddle or two individual boat oars. Constructed with a lightweight yet sturdy aluminum shaft and durable blades, this set provides reliable performance for various water activities. When assembled as a kayak paddle, it measures approximately 244 cm (96 inches). It can also be converted into two 122 cm (48 inch) oars for use with inflatable boats or other watercraft.

Product Components

Before assembly, ensure all components are present and undamaged. The Intex 69627 Kayak Paddle Set includes the following parts:

- **Aluminum Shaft Sections:** Two main shaft pieces that connect to form the paddle or oars.
- **Paddle Blades:** Two large black blades designed for efficient propulsion.
- **Connector Piece:** A central connector used to join the two shaft sections for kayak paddle configuration.
- **Oar Retainer/Drip Rings:** Two rubber rings designed to prevent water from dripping down the shaft into the boat.




Figure 1: All components of the Intex 69627 Kayak Paddle Set, including two aluminum shaft sections, two black paddle blades, a central connector, and two drip rings.

Setup and Assembly

The Intex 69627 paddle set offers two primary configurations: a single kayak paddle or two individual boat oars.

1. Assembling as a Kayak Paddle (Approx. 244 cm / 96 inches)

1. Take one aluminum shaft section and attach a paddle blade to one end. Ensure the spring-loaded pin on the shaft clicks securely into the hole on the blade.
2. Repeat step 1 for the second aluminum shaft section and the other paddle blade.
3. Connect the two assembled shaft-and-blade sections using the central connector piece. Align the holes and ensure the spring-loaded pins click into place, creating a single, long paddle.
4. Slide the two oar retainer/drip rings onto the shaft, positioning them approximately 12-15 cm (5-6 inches) from each blade. These rings help prevent water from running down the shaft.



Figure 2: The Intex 69627 paddle assembled into a single kayak paddle, showing the central connector and blades.

2. Assembling as Two Boat Oars (Approx. 122 cm / 48 inches each)

1. Take one aluminum shaft section and attach a paddle blade to one end. Ensure the spring-loaded pin on the shaft clicks securely into the hole on the blade.
2. Slide one oar retainer/drip ring onto the shaft, positioning it approximately 12-15 cm (5-6 inches) from the blade.
3. Repeat steps 1 and 2 for the second aluminum shaft section and the other paddle blade to create the second oar.
4. The central connector piece is not used in this configuration.



Figure 3: The Intex 69627 paddle set configured as two separate boat oars, each with a blade and drip ring.

Operating Instructions

Proper use of your Intex 69627 paddle set ensures efficient propulsion and a comfortable experience on the water.

Using as a Kayak Paddle:

- Hold the paddle with both hands, spaced roughly shoulder-width apart, centered on the shaft.
- For forward motion, immerse one blade into the water near your feet and pull it towards your hip. As you finish the stroke on one side, immerse the other blade on the opposite side and repeat the motion.
- Maintain a smooth, consistent rhythm.
- The drip rings should be positioned to catch water running down the shaft, preventing it from entering your kayak.



Figure 4: An individual demonstrating the use of a kayak paddle in a watercraft, illustrating proper grip and stroke technique.

Using as Boat Oars:

- Insert each oar into the oarlocks of your boat. Ensure the oar retainer/drip rings are positioned correctly to prevent water intrusion.
- Grip the handles firmly. For forward motion, push the oars forward, immerse the blades, and pull them back towards your body.

- Coordinate strokes for balanced movement.

Maintenance

Proper maintenance extends the life of your paddle set and ensures optimal performance.

- **Cleaning:** After each use, rinse the paddle components thoroughly with fresh water to remove salt, sand, and debris.
- **Drying:** Allow all parts to air dry completely before disassembling and storing to prevent corrosion and mildew.
- **Inspection:** Regularly inspect the aluminum shafts for dents or bends, and the blades for cracks or damage. Check that the spring-loaded pins operate smoothly and securely.
- **Storage:** Store the disassembled paddle set in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid storing under heavy objects that could cause damage.

Troubleshooting

This section addresses common issues you might encounter with your paddle set.

- **Difficulty Assembling/Disassembling:** Ensure the spring-loaded pins are fully depressed when inserting or removing components. If a pin is stuck, gently wiggle the parts while applying pressure to the pin. A small amount of silicone lubricant can help if parts are stiff.
- **Loose Connections:** If a connection feels loose after assembly, ensure the spring-loaded pin has fully engaged in the corresponding hole. Inspect the pin and hole for any obstructions or damage.
- **Water Dripping into Boat:** Verify that the oar retainer/drip rings are correctly positioned on the shaft, close to the blades, to effectively deflect water.
- **Reduced Paddling Efficiency:** Check blades for damage or excessive wear. Ensure blades are oriented correctly for optimal water displacement.

Specifications

Feature	Detail
Model Number	69627E
Brand	Intex
Material Type	Aluminum (shaft)
Kayak Paddle Length	244 cm (96 inches)
Individual Oar Length	122 cm (48 inches) each
Color	Multicolor (shafts typically silver, blades black)
Product Dimensions (packaged)	24.99 x 24 x 8 cm
Item Weight	9 g

Note: The listed item weight of 9g appears to be an error in the source data. The actual weight of a paddle set of this size would be significantly higher.

Warranty Information

Intex products are manufactured to high-quality standards. For specific warranty details regarding your Intex 69627 Kayak Paddle Set, please refer to the warranty card included with your purchase or visit the official Intex website. Keep your proof of purchase for any warranty claims.

Customer Support

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please contact Intex customer support. Contact information can typically be found on the product packaging or on the official Intex website. When contacting support, please have your model number (69627E) and purchase details readily available.
You can visit the official Intex Store for more information:Intex Store on Amazon.co.uk

© 2026 Intex. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B000SKI74S

More documents and user manuals: **https://manuals.plus/**