

[manuals.plus](#) /

› [Hozelock](#) /

› [Hozelock Multi-Jet Spray Gun Plus \(Model 2691 6001\) Instruction Manual](#)

Hozelock 2691 6001

Hozelock Multi-Jet Spray Gun Plus Instruction Manual

Model: 2691 6001

1. INTRODUCTION

This manual provides instructions for the safe and effective use of your Hozelock Multi-Jet Spray Gun Plus. This durable spray gun features a powder-coated die-cast metal body, comfortable soft-touch ergonomics, and a versatile selection of eight spray patterns for various watering and cleaning tasks.

Please read these instructions carefully before first use and retain them for future reference.

2. PACKAGE CONTENTS

- 1 x Hozelock Multi-Jet Spray Gun Plus (Model 2691 6001)

3. SETUP

To begin using your spray gun, follow these steps:

1. **Connect to Hose:** Ensure your garden hose is equipped with a compatible hose connector. Attach the Hozelock Multi-Jet Spray Gun Plus to the hose connector by pushing it firmly until it clicks into place.
2. **Water Supply:** Turn on the water supply to your garden hose.



Image 1: The Hozelock Multi-Jet Spray Gun Plus connected to a garden hose, actively spraying water onto plants in a garden setting.

4. OPERATING INSTRUCTIONS

4.1. Trigger Operation

- **Variable Flow Control:** The spray gun features an infinitely variable trigger flow control. Squeeze the trigger gently for a lower flow rate and harder for a higher flow rate.
- **Two-Stage Locking Trigger:**
 - To lock the trigger at 100% flow, squeeze the trigger fully and engage the lock mechanism (usually a small lever or button near the trigger).
 - To lock the trigger at approximately 40% flow, squeeze the trigger partially and engage the lock mechanism.
 - To release the lock, simply squeeze the trigger again.

4.2. Changing Spray Patterns

The spray gun offers eight distinct spray patterns. To change the pattern, rotate the nozzle head at the front of the gun until the desired pattern is selected.



Image 2: A close-up view of the Hozelock Multi-Jet Spray Gun Plus, highlighting the adjustable nozzle head with clearly labeled spray patterns such as 'Cone', 'Centre', and 'Fan'.

5. SPRAY PATTERNS DESCRIPTION

The Hozelock Multi-Jet Spray Gun Plus provides the following spray patterns:

- **Powerful Jet:** A concentrated stream for cleaning stubborn dirt or reaching distant areas.
- **Cone:** A wide, gentle spray suitable for covering large areas quickly and watering delicate plants.
- **Fast Fill:** Designed for rapidly filling buckets or watering cans.
- **Fan:** A broad, flat spray ideal for covering more surface area, such as rinsing soap from a car.
- **Mist:** A very fine, gentle mist for watering seedlings or sensitive plants without causing damage.
- **Fine Rose:** A classic, gentle shower-like spray for general watering of borders, pots, and hanging baskets.
- **Aerated:** Produces a soft, bubbly flow of water that is gentle enough not to disturb flower beds.
- **Angled:** A flat spray pattern, useful for specific cleaning tasks or watering under foliage.



Image 3: A user demonstrating the comfortable and easy operation of the Hozelock Multi-Jet Spray Gun Plus while watering garden plants.

6. MAINTENANCE

- **Cleaning:** Periodically rinse the spray gun with clean water to remove any dirt or debris. If the spray patterns become irregular, check the nozzle for blockages and gently clear them.
- **Storage:** Store the spray gun in a dry, frost-free location when not in use, especially during winter months, to prevent damage from freezing water.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners or harsh chemicals on the spray gun, as this may damage the finish or internal components.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Reduced water flow or irregular spray.	Nozzle blockage or low water pressure.	Check the nozzle for debris and clear it. Ensure the water supply is fully open and hose is not kinked.
Leaks from connections.	Loose connection or worn washer.	Ensure the hose connector is securely attached. Check and replace any worn rubber washers in the connector.
Trigger is stiff or stuck.	Mineral buildup or debris.	Rinse thoroughly with warm water. Avoid forcing the trigger.

8. SPECIFICATIONS

- **Model:** 2691 6001
- **Material:** Metal (Powder-coated die-cast)
- **Dimensions (L x W x H):** 2.36 x 5.12 x 9.84 inches (approximately 6 x 13 x 25 cm)

- **Weight:** 10.2 ounces (approximately 289 grams)
- **Spray Patterns:** 8 (Powerful Jet, Cone, Fast Fill, Fan, Mist, Fine Rose, Aerated, Angled)
- **Special Features:** Adjustable flow control, ergonomic handle, two-stage locking trigger.


9. WARRANTY AND SUPPORT


Hozelock products are designed for durability and performance. This product comes with a 2-year guarantee from the date of purchase. For warranty claims or technical support, please contact Hozelock customer service or visit the official Hozelock website.

Spare part availability is generally supported for 1 year in the EU region. For specific spare part inquiries, please consult Hozelock directly.

For further assistance, please refer to the official Hozelock website:www.hozelock.com


Related Documents - 2691 6001

	<p>Hozelock Product Guarantee Periods and Terms</p> <p>Comprehensive guide to Hozelock and Hozelock Cyprio product guarantee periods, including terms and conditions for hoses, reels, spray guns, watering systems, pumps, and pond equipment. Learn about standard and extended warranties.</p>
<p>User Manual of Product 1: Hozelock Auto Reel 20m, 25m, 30m Power Bank 22.2V Fast Charging 20000mAh Power Bank 22.2V Fast Charging 20000mAh Out with LCD Display Battery Pack 20000mAh Pro Max Samsung S21 5G (Pad 5G)</p>	<p>Hozelock Auto Reel User Manual & Installation Guide</p> <p>Comprehensive user manual and installation guide for the Hozelock Auto Reel (20m, 25m, 30m). Learn how to set up, use, maintain, and troubleshoot your Hozelock garden hose reel.</p>
<p>User Manual of Product 1: HOZELOCK - Drip Watering Kit 20 Pot - Complete Stand-alone System with Select Controller Programmer, Built-in Potted Plant and Window Boxes, or Pots, Indoor/Outdoor Watering (2803 0000)</p>	<p>HOZELOCK Drip Watering Kit 20 Pot: AC1 Select Controller Programmer User Manual</p> <p>User manual for the HOZELOCK Drip Watering Kit 20 Pot (Model AC1, 2803 0000), a complete stand-alone system with a Select Controller Programmer for precise, water-saving irrigation of potted plants and window boxes. Includes instructions for installation, programming, maintenance, and troubleshooting.</p>



[Hozelock Watering Spares Manual 2014: Parts and Model Numbers](#)

Official Hozelock spares manual detailing parts and part numbers for various watering products including hose reels, carts, pumps, and sprayers. Find service kits, replacement parts, and accessories.



[Hozelock AC1 Automatic Watering Timer User Manual and Programming Guide](#)

Comprehensive user manual for the Hozelock AC1 automatic watering timer, model 2705. Learn how to install batteries, program automatic and manual watering cycles, set start times, and troubleshoot common issues. Includes detailed watering program descriptions and essential frost protection guidelines for optimal garden irrigation.



[Hozelock AC1+ Automatic Garden Watering System User Manual](#)

Comprehensive guide for the Hozelock AC1+ automatic watering system, covering installation, programming, and troubleshooting for efficient garden irrigation.