

[Manuals.plus](#) /

› [HOLMES](#) /

› HOLMES HFH6610-U 1500W Tower Heater Instruction Manual

HOLMES HFH6610-U

HOLMES HFH6610-U 1500W Tower Heater Instruction Manual

Model: HFH6610-U

PRODUCT OVERVIEW

The HOLMES HFH6610-U Tower Heater is designed for efficient heating in smaller spaces. Its space-saving tower design and rotating top grille allow users to direct heat effectively. The 1Touch controls ensure ease of use, and an integrated carrying handle provides convenient portability.



Image: HOLMES HFH6610-U 1500W Tower Heater. This image displays the compact tower design of the heater, highlighting its modern aesthetic and space-saving form factor.

Key Features

- 1500-watt tower heater with dual heating fan elements for powerful warmth.
- Rotating top grille allows for adjustable heat direction.
- Intuitive 1Touch controls for simple operation.
- Three heat settings: Low, High, and Auto.
- Electronic thermostat maintains a consistent, preset temperature.
- Built-in tip-over protection for enhanced safety.
- Automatic safety shut-off feature prevents overheating.
- Integrated carrying handle for easy transport.
- Compact dimensions: 10 x 9-2/5 x 22-4/5 inches.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

1. Read all instructions before using this heater.
2. This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces. Use handles when moving this heater. Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and keep them away from the sides and rear.
3. Extreme caution is necessary when any heater is used by or near children or invalids and whenever the heater is left operating and unattended.
4. Always unplug heater when not in use.
5. Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
6. Do not use outdoors.
7. This heater is not intended for use in bathrooms, laundry areas and similar indoor locations. Never locate heater where it may fall into a bathtub or other water container.
8. Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
9. To disconnect heater, turn controls to OFF, then remove plug from outlet.
10. Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
11. To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
12. A heater has hot and arcing or sparking parts inside. Do not use it in areas where gasoline, paint, or flammable liquids are used or stored.
13. Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
14. Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or

relocatable power tap (outlet/power strip).

SETUP AND PLACEMENT

Unpacking

- Carefully remove the heater from its packaging.
- Remove all plastic bags and protective materials.
- Inspect the heater for any signs of damage. If damaged, do not operate and contact customer support.

Placement

- Place the heater on a firm, level surface to ensure stability and proper operation of the tip-over safety switch.
- Ensure there is at least 3 feet (0.9 meters) of clear space around the heater from walls, furniture, curtains, and other combustible materials.
- Do not place the heater directly under a power outlet.
- Avoid placing the heater in high-traffic areas where the power cord could be a tripping hazard.

OPERATING YOUR HEATER

Powering On/Off

- Plug the heater directly into a 120V AC electrical outlet. Do not use extension cords or power strips.
- Press the **Power** button on the 1Touch control panel to turn the heater ON. The heater will typically start in a default heat setting.
- To turn the heater OFF, press the **Power** button again.

Control Panel (1Touch Controls)

The heater features intuitive 1Touch controls for easy adjustment of settings.

- **Power Button:** Turns the heater ON or OFF.
- **Mode Button:** Cycles through the available heat settings: Low, High, and Auto.
- **Temperature Up/Down Buttons:** Adjusts the desired temperature when in Auto mode.

Thermostat Operation (Auto Mode)

- Press the **Mode** button until 'Auto' is selected.
- Use the **Temperature Up** or **Down** buttons to set your desired room temperature.
- The electronic thermostat will automatically turn the heater ON and OFF to maintain the set temperature, optimizing energy consumption.

Rotating Grille

- The top grille of the heater can be manually rotated to direct the airflow and heat to a specific area of the room.

- Gently grasp the top section of the grille and rotate it to the desired angle.

Safety Features

- **Tip-Over Protection:** The heater is equipped with an internal safety switch that automatically shuts off the unit if it is accidentally tipped over. If this occurs, place the heater upright on a stable surface, and it should resume operation.
- **Automatic Safety Shut-Off:** In the event of overheating, the heater will automatically shut off. If this happens, unplug the heater, allow it to cool down for at least 10 minutes, and ensure air intake/exhaust vents are not blocked before plugging it back in and resuming use.

CARE AND MAINTENANCE

Regular cleaning and proper storage will help ensure the longevity and efficient operation of your heater.

Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Use a soft, damp cloth to wipe the exterior surfaces of the heater. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust and lint from the air intake and exhaust grilles. Ensure these openings are clear to prevent overheating.
- Never immerse the heater in water or allow water to drip into the interior.

Storage

- When not in use, store the heater in its original packaging or a clean, dry place.
- Avoid storing the heater in areas with extreme temperatures or high humidity.
- Ensure the power cord is neatly wrapped and secured to prevent damage.

TROUBLESHOOTING GUIDE

If your heater is not operating as expected, please consult the following guide before contacting customer support.

Problem	Possible Cause	Solution
Heater does not turn on.	No power to the unit. Tip-over switch activated. Overheat protection activated.	Ensure the heater is securely plugged into a working 120V outlet. Place the heater on a firm, level surface. Unplug, allow to cool for 10 minutes, and check for blocked vents.
Heater turns off unexpectedly.	Overheat protection activated. Tip-over switch activated.	Unplug, allow to cool for 10 minutes, and check for blocked vents. Ensure the heater is on a stable, level surface.

Problem	Possible Cause	Solution
Heater is on but not producing heat.	Thermostat set too low. Air intake/exhaust blocked.	Increase the desired temperature setting in Auto mode. Unplug and clear any obstructions from the grilles.

PRODUCT SPECIFICATIONS

Attribute	Value
Brand	HOLMES
Model Number	HFH6610-U
Power Source	Corded Electric
Wattage	1500 Watts
Heating Method	Fan & Forced Air
Mounting Type	Floor Mount
UPC	048894678554
Dimensions (L x W x H)	10 x 9.4 x 22.8 inches (25.4 x 23.9 x 57.9 cm)

WARRANTY INFORMATION

This HOLMES HFH6610-U Tower Heater comes with a limited manufacturer's warranty. Please refer to the warranty card included with your product for specific terms, conditions, and duration of coverage. Keep your purchase receipt as proof of purchase for any warranty claims.

CUSTOMER SUPPORT

For technical assistance, troubleshooting beyond this guide, or warranty inquiries, please contact HOLMES customer support. Contact information can typically be found on the product packaging, the official HOLMES website, or the warranty card.