

Lindam 44372

Lindam Flexiguard Door Safety Gate User Manual

Model: 44372 | Brand: Lindam



Official Lindam product logo, emphasizing safety.

INTRODUCTION

Thank you for choosing the Lindam Flexiguard Door Safety Gate. This manual provides essential information for the safe and effective installation, operation, and maintenance of your new safety gate. Please read all instructions carefully before assembly and use, and keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

- Always ensure the gate is securely installed and locked before leaving a child unattended.
- This safety barrier is for domestic use only.
- This safety barrier is suitable for use with children up to 24 months of age.
- Never use the gate if any components are damaged or missing.
- Do not allow children to climb on the gate.
- Regularly check all fittings and components to ensure they are secure and in good working order.
- This gate is designed for openings between 71 cm and 92 cm. Do not attempt to install in openings outside this range.

SETUP AND INSTALLATION

1. Unpacking and Component Check

Carefully remove all contents from the packaging. Verify that all components are present and undamaged. Refer to the parts list (not provided in this manual, but typically found in the product box).

2. Gate Overview



Image: The Lindam Flexiguard Door Safety Gate shown fully unfolded, highlighting its mesh fabric and pressure-fit frame.

3. Installation Steps (4-Point Pressure Fit)

1. **Prepare the Opening:** Ensure the surface where the gate will be installed is clean, dry, and structurally sound. The gate is designed for openings between 71 cm and 92 cm.
2. **Position the Gate:** Place the gate in the desired opening. Ensure the bottom bar is flush with the floor and the gate is centered.
3. **Adjust Width:** Extend the gate's frame by twisting the adjustment mechanisms on the sides until the pressure pads make contact with the walls/door frame.
4. **Secure the Pressure Points:** The gate features a 4-point pressure fitting system. Use the quick-release handle to simultaneously engage all four pressure points. Turn the adjustment knobs on each corner to tighten the gate until it is firmly secured and does not move when pushed.
5. **Test Security:** Once installed, firmly push and pull the gate to ensure it is stable and cannot be dislodged. The gate should feel rigid and secure.



Image: The Lindam Flexiguard Door Safety Gate shown installed in a typical doorway, demonstrating its function as a barrier.

OPERATING THE GATE

Opening and Closing

- To open the gate, locate the quick-release handle. Press the release button (if applicable) and lift the handle to disengage the pressure points.
- To close the gate, simply push the gate back into position and ensure the quick-release handle locks securely, re-engaging all four pressure points. A click sound indicates it is locked.

Folding Mechanism

The Lindam Flexiguard gate features a patented twist and fold mechanism for easy storage and portability. To fold the gate, disengage the pressure points, then follow the instructions provided with your product for the specific folding sequence. This allows the gate to collapse into a compact size, ideal for travel or storage in the included carry bag.

MAINTENANCE

- **Cleaning:** Clean the gate regularly with a damp cloth and mild soap. Do not use abrasive cleaners or harsh chemicals, as these may damage the materials.
- **Inspection:** Periodically inspect all parts for wear, damage, or loose fittings. Pay close attention to the pressure pads, locking mechanism, and fabric mesh.
- **Storage:** When not in use, store the gate in a clean, dry place, preferably in its carry bag, away from direct sunlight or extreme temperatures.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|--------------------------------------|--|--|
| Gate does not fit opening. | Opening is outside the 71-92 cm range. | Ensure your opening is within the specified range. This gate is not suitable for wider or narrower openings. |
| Gate feels loose after installation. | Pressure points not sufficiently tightened. | Re-tighten the adjustment knobs on all four corners until the gate is firmly secured. |
| Quick-release handle not locking. | Gate not properly aligned or mechanism obstructed. | Ensure the gate is correctly positioned and there are no obstructions. Check for any damage to the handle mechanism. |

SPECIFICATIONS

Model Number: 44372

Product Dimensions: 78 x 19 x 8 cm (folded); 1.94 kg

Adjustable Width: 71 cm to 92 cm

Color: Blue

Manufacturer: Lindam

Type: 4-point Pressure Fit Safety Gate

Features: Patented twist and fold mechanism, quick-release handle, lightweight, includes carry bag.

WARRANTY AND SUPPORT

Lindam products are manufactured to high-quality standards. For information regarding warranty coverage, please refer to the warranty card included with your purchase or visit the official Lindam website. For technical support or replacement

parts, please contact Lindam customer service through their official channels.

Note: Specific warranty terms and contact details may vary by region.



© Lindam. All rights reserved. This manual is for informational purposes only.