

Guide Gear 3A-HT103

Guide Gear Deluxe Deer Cart Instruction Manual

Model: 3A-HT103

Brand: Guide Gear

PRODUCT OVERVIEW

The Guide Gear Deluxe Deer Cart is designed for efficient and easy transportation of large game and hunting gear over various outdoor terrains. Its robust construction and thoughtful design ensure stability and ease of use.

- **DEER CART** – Our wheeled cart is perfect for transporting large game and deer after a hunt. Includes 3 lashing straps for secure attachment.
- **DURABLE** – The Guide Gear deer hunting cart features a durable stainless steel frame and smart design which centers the weight over the axle for easier movement.
- **LARGE WHEELS** – The hunting equipment cart features 16" solid-rubber spoked wheels for puncture-proof, seamless movement over rough outdoor terrain.
- **300-LB WEIGHT CAPACITY** – A high weight capacity of 300-lbs. makes this hunting push cart great for hauling large game, hunting accessories, tree stands or deer hoists.
- **PORTABLE** – The deer cart with big wheels has a folding design that folds flat for easy storage and transport. Easily fit in your truck or with your other hunting and camping equipment.

SETUP AND ASSEMBLY

Follow these steps to assemble your Guide Gear Deluxe Deer Cart:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the packing list are present.
2. **Attach Wheels:** Insert the axle through the designated holes in the cart frame. Secure the 16-inch solid-rubber spoked wheels onto the axle ends. Ensure retaining pins or clips are firmly in place to prevent wheel detachment.
3. **Assemble Frame:** Unfold the main frame of the cart. The design allows for the frame to extend into its operational position. Secure any locking pins or latches that hold the frame rigid.
4. **Attach Support Arms (if applicable):** If your model includes separate support arms, attach them to

the main frame as indicated in the diagrams. Ensure they are securely fastened to provide stability for heavy loads.

5. **Inspect All Connections:** Before first use, double-check all bolts, pins, and connections to ensure they are tight and secure.



Figure 1: Fully assembled Guide Gear Deluxe Deer Cart, ready for use.



Figure 2: The deer cart in its folded configuration, demonstrating its portability and ease of storage.

OPERATING INSTRUCTIONS

Proper operation ensures safety and extends the life of your deer cart.

1. **Loading Game/Gear:** Position the cart on level ground. Carefully place the game or gear onto the cart, ensuring the weight is centered over the axle. This design feature helps to balance the load, making it easier to maneuver.
2. **Securing the Load:** Utilize the included 3 lashing straps to firmly secure the game or gear to the cart frame. Ensure the load is stable and will not shift during transport. Additional straps may be used for irregularly shaped or very heavy items.
3. **Maneuvering the Cart:** Grasp the handle firmly. Lift the handle slightly to shift some weight onto the wheels, then push or pull the cart. For optimal control and reduced strain, maintain a balanced posture.
4. **Navigating Terrain:** The 16-inch solid-rubber spoked wheels are designed for rough outdoor terrain, including uneven ground, downed trees, and shallow streams. Approach obstacles slowly and with caution. For very steep inclines or declines, consider using two people for better control.
5. **Folding for Transport/Storage:** To fold the cart, remove any load and release the locking mechanisms (if present) that hold the frame rigid. Collapse the frame flat. The wheels can remain attached for compact storage.



Figure 3: A hunter demonstrating the use of the deer cart in an outdoor setting, highlighting its practical application for hauling game.

Your browser does not support the video tag.

Video 1: Official product video showcasing the features and utility of the Guide Gear Deluxe Deer Cart, including its solid steel frame, large wheels, and folding design.

MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your deer cart.

- **Cleaning:** After each use, especially in muddy or wet conditions, clean the cart frame and wheels with water and a mild detergent. Rinse thoroughly and dry completely to prevent rust.
- **Lubrication:** Periodically apply a light lubricant to the wheel axles and any moving joints to ensure smooth operation.
- **Inspection:** Before and after each use, inspect the frame for any signs of damage, bends, or cracks. Check all bolts, pins, and fasteners for tightness. Tighten any loose components.
- **Storage:** Store the cart in a dry, covered area to protect it from the elements. The folding design allows for compact storage in a garage, shed, or vehicle.

TROUBLESHOOTING

Common issues and their solutions:

- **Wheels not rolling smoothly:** Check for debris caught in the axles or spokes. Apply lubricant to the axle bearings. Ensure wheels are properly seated and retaining pins are secure.
- **Cart feels unstable or wobbly:** Verify that all frame connections and locking pins are fully engaged and secure. Ensure the load is balanced and centered over the axle.

- **Difficulty folding/unfolding:** Check for any obstructions or bent components. Lubricate moving joints if stiffness is present.
- **Lashing straps not holding securely:** Ensure straps are threaded correctly through buckles and pulled taut. Replace worn or damaged straps.

SPECIFICATIONS

Feature	Detail
Brand	Guide Gear
Model Number	3A-HT103
Material	Alloy Steel, Rubber, Stainless Steel
Color	As Shown
Recommended Uses	Outdoor
Item Weight	28.2 Pounds
Number of Wheels	2
Weight Limit	300 Pounds
Assembly Required	No
Item Dimensions (LxWxH)	36.5 x 21.25 x 5.5 inches

WARRANTY AND SUPPORT

For specific warranty information and customer support, please refer to the documentation included with your purchase or visit the official Guide Gear website. Keep your proof of purchase for any warranty claims.

For additional assistance, you may contact the seller, The Sportsman's Guide, directly through their contact information provided at the time of purchase or on their Amazon seller page.