

[Manuals.plus](#) /

> [Smoby](#) /

> Smoby Jumplanet Stunt Center Instruction Manual

Smoby 211003

Smoby Jumplanet Stunt Center Instruction Manual

1. PRODUCT OVERVIEW

The Smoby Jumplanet is a first-age stunt center designed for young children aged 18 months and older. It features various activities for mini cars, including a stunt ramp, two trampolines, a seesaw, a circuit, a bumper, and a bridge, allowing mini cars to perform exciting stunts and develop motor skills through play.



Image 1.1: The Smoby Jumplanet Stunt Center, showcasing its various play elements and included mini cars.

2. IMPORTANT SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Keep this manual for future reference.

- Recommended for children aged 18 months and older.
- Adult supervision is recommended at all times during play.
- Ensure all parts are securely assembled before allowing children to play.
- This toy contains small parts before assembly and should be kept away from children under 18 months.
- Do not modify the product in any way. Use only original Smoby parts for replacement.

3. PACKAGE CONTENTS

Carefully unpack all items and verify that you have received the following components:

- Jumplanet stunt center track pieces and structural components
- 2 mini cars (typically one red, one green)
- Instruction manual (this document)



Image 3.1: An overview of the Smoby Jumplanet components, including track sections, ramps, and the two mini cars.

4. SETUP AND ASSEMBLY

Adult assembly is required. Please follow these steps carefully to assemble your Smoby Jumplanet stunt center.

1. **Unpack and Identify Parts:** Lay out all components on a clean, flat surface. Refer to the package contents list to ensure all pieces are present.
2. **Connect Main Track Sections:** Begin by connecting the main circuit pieces. Ensure each connection clicks firmly into place to form a stable base.

3. **Attach Stunt Elements:** Securely attach the ramp with the jump mechanism, the two trampolines, and the seesaw element to their designated positions on the track.
4. **Install Bumper and Bridge:** Place the bumper at the starting point and connect the bridge section as indicated in the visual guide.
5. **Final Check:** Before play, double-check all connections to ensure the entire structure is stable and secure.



Image 4.1: A red mini car positioned on the starting ramp, ready for launch. This section is part of the overall assembly.



Image 4.2: A child observing the fully assembled Smoby Jumplanet stunt center, demonstrating the scale and complete setup.

5. OPERATING INSTRUCTIONS

The Smoby Jumplanet is designed for simple and engaging play. Follow these steps to operate the stunt center:

1. **Place Mini Car:** Select one of the provided mini cars and place it at the starting point of the circuit, typically near the bumper mechanism.
2. **Launch Car:** Use the bumper or launch mechanism to propel the mini car onto the track.
3. **Observe Stunts:** Watch as the mini car navigates the ramps, jumps, and other stunt elements, performing various actions.
4. **Experiment:** Encourage children to experiment with different launch speeds and car placements to achieve various stunts and explore the full potential of the circuit.
5. **Multi-Car Play:** Utilize both included mini cars for racing or simultaneous play, enhancing interaction and fun.



Image 5.1: The two mini cars included with the Jumplanet set, ready to be used on the track.



Image 5.2: A mini car in action, descending a ramp on the Smoby Jumplanet, illustrating a typical play scenario.

6. MAINTENANCE

Proper maintenance will ensure the longevity and hygiene of your Smoby Jumplanet stunt center.

- **Cleaning:** Regularly wipe down all plastic surfaces with a damp cloth and mild soap. Avoid using abrasive cleaners or solvents, as these may damage the plastic.
- **Storage:** Store the toy indoors in a dry place when not in use to prevent damage from weather or prolonged sun exposure.
- **Inspection:** Periodically check all connections and moving parts for wear, damage, or loose fittings. Replace any damaged parts immediately to ensure safe play.

7. TROUBLESHOOTING

If you encounter any issues with your Smoby Jumplanet, please refer to the following troubleshooting guide:

Problem: Mini cars do not move smoothly on the track.

Solution: Check for any obstructions on the track, such as small debris or foreign objects. Ensure all track pieces are correctly aligned and securely connected. Clean the wheels of the mini cars if they appear dirty or have accumulated lint.

Problem: Parts of the stunt center detach during play.

Solution: Re-secure the detached parts by firmly clicking them back into place. During assembly, ensure all connections are fully engaged. Adult supervision can help prevent excessive force during play that might cause parts to separate.

8. SPECIFICATIONS

Feature	Detail
Model Number	211003
Brand	Smoby
Recommended Age	18 months and up
Material	Plastic
Product Weight	2.32 kg
Product Length	96 cm
Product Width	60 cm
Product Height	52 cm
International Article Code	03032162110034

9. WARRANTY INFORMATION

Smoby products are manufactured to high-quality standards and undergo rigorous checks. For specific warranty details regarding your Jumplanet stunt center, please refer to the warranty card included with your purchase. It is important to retain your proof of purchase for any warranty claims. General warranty terms and conditions may also be available on the official Smoby website.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report a missing or damaged part, please do not hesitate to contact Smoby customer service. You can find contact information and additional resources on the official Smoby website or through their dedicated customer support channels.

Visit the official Smoby Store for more information: [Smoby Official Store](#)