

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Munchkin](#) /

› [Munchkin Steam Microwave Bottle Sterilizer Instruction Manual](#)

Munchkin 11065

Munchkin® Steam™ Microwave Bottle Sterilizer

Model: 11065 | Brand: Munchkin

INTRODUCTION

The Munchkin Steam Guard Microwave Sterilizer provides a safe, natural, and efficient method for sterilizing baby bottles, nipples, pacifiers, teethingers, small toys, and breast pump accessories using steam. Designed for convenience, it fits all standard microwaves and accommodates both regular and wide-mouth bottles.



The Munchkin Steam Microwave Bottle Sterilizer, ready for use. Its compact design allows for easy placement within most standard microwave ovens.

WHAT'S IN THE BOX

- 1 x Munchkin Steam Microwave Bottle Sterilizer
- Heat-resistant tongs
- Large capacity removable basket



The sterilizer's interior, designed to hold up to 4 bottles and 2 breast pump shields, along with other small items like pacifiers and teethers. A removable basket and heat-resistant tongs are included for convenience.

SETUP

1. **Preparation:** Before first use, wash all components of the sterilizer and items to be sterilized in mild soapy water. Rinse thoroughly with un-softened water. Do not use antibacterial soap.
2. **Assembly:** Place the removable basket into the base of the sterilizer.
3. **Loading Items:** Arrange bottles, nipples, pacifiers, teethers, or breast pump accessories within the basket. Ensure items are placed to allow steam circulation. The sterilizer can hold up to 4 bottles and 2 breast pump shields at once.
4. **Add Water:** Pour 7 oz (210 mL) of water into the base of the sterilizer.
5. **Secure Lid:** Place the lid onto the base and ensure the side carrying handles lock it in place. The locking tab is designed to safeguard everything inside and prevent accidental opening.



Proper loading of items within the sterilizer's basket before adding water and securing the lid. Ensure adequate space for steam to circulate around all items.

OPERATING INSTRUCTIONS

1. **Microwave Placement:** Place the assembled sterilizer into your microwave oven. Ensure it fits comfortably and the microwave's turntable can rotate freely.
2. **Sterilization Cycle:** Microwave for 2-4 minutes, depending on your microwave's wattage (800-1500 watts). Refer to your microwave's manual for specific power settings if needed.
3. **Cooling Period:** After the cycle, allow the sterilizer to cool for at least 2 minutes inside the microwave before opening. This helps prevent steam burns.
4. **Removal:** Carefully remove the sterilizer from the microwave using the heat-resistant handles.
5. **Unloading:** Open the lid using the open-away latch to direct steam away from you. Use the included heat-resistant tongs to safely remove sterilized items.



The sterilizer positioned on a kitchen counter, illustrating its compact size and readiness for the microwave sterilization process.

MAINTENANCE AND CARE

Cleaning

To maintain optimal performance and hygiene, regularly clean your Munchkin Steam Microwave Bottle Sterilizer.

- Wash all components in mild soapy water and rinse thoroughly with un-softened water.
- Do not use abrasive cleaners or antibacterial soap, as these can damage the plastic or leave residue.
- The sterilizer is **not** dishwasher safe. Hand wash only.
- Periodically check for mineral deposits (limescale) in the base, especially if using hard water. These can be removed by descaling with a solution of white vinegar and water, then rinsing thoroughly.

TROUBLESHOOTING

Common Issues and Solutions

Items not fully sterilized or still wet:

Ensure you have added the correct amount of water (7 oz / 210 mL) to the base. Verify that the microwave wattage is within the recommended range (800-1500 watts) and adjust the sterilization time accordingly. Make sure the lid is securely latched to contain the steam.

Sterilizer leaking after use:

Some condensation may remain after the cycle. Ensure the lid is properly sealed during operation. Allow the unit to cool for the recommended time before opening to minimize condensation. If significant leakage occurs, check for cracks or damage to the unit.

Plastic appears cloudy or discolored:

This can be due to mineral deposits from hard water. Follow the descaling instructions in the Maintenance section. Avoid using harsh chemicals or abrasive cleaning tools.

SPECIFICATIONS

Feature	Detail
Product Dimensions	12.5 x 11.3 x 6.7 inches
Item Model Number	11065
Item Weight	7.4 ounces
Material Type	BPA Free, Latex Free, Nitrosamine Free
Capacity	Holds up to 4 bottles and 2 breast pump shields
Dishwasher Safe	No (Hand wash only)
Compatibility	Fits all standard microwaves; works with regular and wide-mouth bottles
Special Features	Heat-resistant handles, Open-away latch to prevent steam burns

WARRANTY AND SUPPORT

For product support or inquiries, please visit the official Munchkin website or contact their customer service.

Legal Disclaimer:

IN NO EVENT, REGARDLESS OF CAUSE, SHALL LUCKY INFANT BE LIABLE FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE OR CONSEQUENTIAL DAMAGES OF ANY KIND, WHETHER ARISING UNDER BREACH OF CONTRACT, TORT (INCLUDING NEGLIGENCE), STRICT LIABILITY OR OTHERWISE, AND WHETHER BASED ON THIS AGREEMENT OR OTHERWISE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.