

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Casio](#) /
- › [Casio WVQ-M610LE-1AVER Men's Watch Instruction Manual](#)

Casio WVQ-M610LE-1AVER

Casio WVQ-M610LE-1AVER Wave Ceptor Tough Solar Watch User Manual

Your guide to setting up, operating, and maintaining your Casio timepiece.

INTRODUCTION

Thank you for choosing the Casio WVQ-M610LE-1AVER Wave Ceptor Tough Solar watch. This timepiece combines advanced technology with classic design, featuring multi-band radio-controlled timekeeping (Wave Ceptor) for accurate time synchronization and solar power (Tough Solar) for reliable, long-lasting operation. This manual provides essential information for proper use and care of your watch.



Image: Front view of the Casio WVQ-M610LE-1AVER watch, showcasing its dark dial, silver-tone case, and leather strap.

SETUP

1. Initial Charge (Tough Solar)

Your watch is equipped with Casio's Tough Solar power system, which converts light into electrical energy to power the watch and recharge its built-in rechargeable battery. For optimal performance, ensure the watch receives sufficient light exposure.

- Upon first use or after prolonged storage in darkness, expose the watch face to bright light (e.g., sunlight through a window) for several hours.
- Avoid exposing the watch to extremely high temperatures during charging.
- A fully charged battery can power the watch for approximately 5-6 months in total darkness with power-saving function enabled.



Image: The 'Tough Solar' logo, featuring a stylized sun, indicating the watch's solar charging capability.

2. Time Signal Reception (Wave Ceptor)

The Wave Ceptor feature allows your watch to automatically receive time calibration signals from atomic clocks, ensuring precise timekeeping. The watch attempts to receive the signal automatically several times a day.

- **Manual Reception:** To manually initiate signal reception, refer to the detailed instructions in the full Casio module manual (typically module number 5174 or similar, found on the watch's case back).
- **Optimal Reception:** Place the watch near a window, away from metal objects or electronic devices that might interfere with the signal.
- **Reception Areas:** This model supports reception of signals from transmitters in Europe, North America, Japan, and China.



Image: The 'Wave Ceptor' logo, depicting radio waves, signifying the watch's radio-controlled timekeeping function.

3. Setting Home City and Time Zone

Before using the watch, ensure your home city (time zone) is correctly set. This is crucial for accurate time signal reception and world time display.

1. Enter the Timekeeping Mode.
2. Press and hold the Adjust button (usually top-left) until the city code starts to flash.
3. Use the Forward/Reverse buttons (usually top-right/bottom-right) to select your desired home city code.
4. Press the Adjust button again to exit the setting mode.

OPERATING YOUR WATCH

Basic Timekeeping

The watch displays the current time (hour, minute, second), day of the week, and date. The hands automatically adjust based on the received time signal.

World Time Function

This feature allows you to view the current time in various major cities around the world.

- Enter the World Time Mode (refer to your specific module manual for button operation).
- Use the appropriate buttons to cycle through different city codes. The watch will display the current time for the selected city.

Alarm Function

Set daily alarms to remind you of important events.

1. Enter the Alarm Mode.
2. Select the alarm number you wish to set.
3. Adjust the hour and minute settings for the alarm.
4. Activate or deactivate the alarm.

Stopwatch Function

Measure elapsed time with precision.

- Enter the Stopwatch Mode.
- Press the Start/Stop button to begin and end timing.
- Press the Reset button to clear the stopwatch.

Illumination

The watch features an LED light for easy readability in low-light conditions. Press the light button (usually bottom-right) to activate the illumination.

MAINTENANCE

Cleaning Your Watch

Regular cleaning helps maintain the appearance and longevity of your watch.

- Wipe the case and band with a soft, dry cloth.
- For stubborn dirt, use a soft cloth dampened with water and a mild neutral detergent, then wipe dry.
- Avoid using volatile agents like thinner, gasoline, or alcohol, as they may damage the watch's finish.

Water Resistance

This watch is designed with a certain level of water resistance. Refer to the markings on the watch case back for its specific water resistance rating (e.g., 10 BAR, 20 BAR). Always ensure the crown is pushed in completely to maintain water resistance.

- **Do not operate buttons or the crown while the watch is wet or submerged.**
- Avoid exposing the watch to hot water or steam (e.g., in a shower or sauna), as this can compromise seals.

Battery Care (Rechargeable)

As a Tough Solar watch, it uses a rechargeable battery. To ensure its longevity:

- Expose the watch to light regularly.
- Avoid storing the watch in complete darkness for extended periods, as this can lead to the battery becoming fully depleted and potentially shortening its lifespan.

Storage

When storing the watch for long periods, place it in an area where it can receive light to prevent the battery from running down. If storing in darkness, periodically expose it to light to recharge.

TROUBLESHOOTING

- **Time is incorrect or not syncing:**
 - Ensure your home city setting is correct.
 - Try manual signal reception in an open area, away from interference.
 - Check the battery charge level. Insufficient charge can prevent signal reception.
 - Verify that the watch is within range of a time signal transmitter.
- **Watch is not charging:**
 - Ensure the watch face is directly exposed to light.
 - Avoid covering the watch face with clothing or other objects.
 - If the watch has been in darkness for a very long time, it may take longer to show signs of charge.
- **Hands are misaligned:**
 - Strong magnetic fields or impacts can cause hand misalignment. Refer to your module manual for instructions on correcting hand home positions.

SPECIFICATIONS

Feature	Detail
Model Number	WVQ-M610LE-1AVER
Manufacturer	Casio
Category	Men's Watch
Power Source	Tough Solar (Solar Powered)
Timekeeping	Wave Ceptor (Radio-Controlled)
ASIN	B000VE41N2
Package Dimensions	11.4 x 11.2 x 8 cm
Item Weight	240.4 grams
First Available on Amazon.it	August 7, 2012

WARRANTY AND SUPPORT

Your Casio watch comes with a manufacturer's warranty. The terms and duration of the warranty may vary by region. Please retain your proof of purchase for warranty claims.

For detailed warranty information, service, or further assistance, please visit the official Casio website or contact Casio customer support in your region. You can often find the specific module number of your watch (e.g., 5174) on the case back, which is helpful when seeking support or looking up detailed instructions online.

Official Casio Website: www.casio.com