

[Manuals.plus](#) /

› [Epson](#) /

› Epson Perfection V500 Photo Scanner User Manual

Epson B11B189011

Epson Perfection V500 Photo Scanner User Manual

Model: B11B189011

Brand: Epson

INTRODUCTION



The Epson Perfection V500 Photo is a high-quality, multi-purpose photo scanner designed to digitize your photos, film, and documents with exceptional clarity. It combines advanced scanning technology with user-friendly features to help you preserve and enhance your cherished memories.

KEY FEATURES

- Create crystal-clear photo enlargements and scan slides, negatives, and medium-format film.
- Easy Photo Fix quickly restores faded photos with one touch.
- Digital Ice technology removes dust particles and scratches from images.
- Energy-efficient LED light eliminates warm-up time while allowing faster scans.

- 1-year limited manufacturer's warranty.

SETUP

Unboxing and Initial Setup



Carefully remove the scanner from its packaging. Place the scanner on a stable, flat surface. The scanner lid is designed to stay open, providing convenience when placing items on the scanning bed. The scanning bed accommodates standard 8.5 x 11 inch documents and photos.

Software Installation

Insert the provided software CD into your computer's CD/DVD drive. Follow the on-screen instructions to install the Epson scanning software and drivers. The setup process is designed to be straightforward and easy.

Connecting the Scanner

Connect the scanner to your computer using the supplied USB cable. Ensure both the scanner and your computer are powered on. The scanner is ready for use once the software installation is complete and the device is recognized by your operating system.

OPERATING THE SCANNER

Basic Scanning



Place your document or photo face down on the scanner glass, aligning it with the guides. Close the scanner lid gently. The Epson scanning software features a 'smart scanner' capability that can automatically separate multiple photos placed on the scanning bed into individual files.

Scanning Options

The scanner offers various quick-scan buttons for common tasks. You can scan directly to a PDF document, email a scanned image, send a scan to a connected printer, or save the scanned file directly to your computer's desktop. These options streamline your workflow for different needs.

Advanced Features

The Epson Perfection V500 Photo Scanner is equipped with advanced features to enhance your scanning experience:

This video highlights the Epson Perfection V500 Photo Scanner's capabilities, including its 6400 x 9600 dpi optical resolution for vivid enlargements up to 13x19 inches or larger. It demonstrates the built-in transparency unit for high-quality scans of slides, negatives, and medium-format panoramic film.

This video showcases Epson's Easy Photo Fix and Digital ICE technology. Easy Photo Fix restores original colors to faded photos, slides, and negatives with one touch. Digital ICE automatically removes defects like dust and scratches from film, ensuring clean and clear scans.

MAINTENANCE

To ensure optimal performance and longevity of your Epson Perfection V500 Photo Scanner, regular maintenance is recommended. Keep the scanner glass clean by gently wiping it with a soft, lint-free cloth and a mild glass cleaner. Avoid abrasive materials that could scratch the surface. Periodically check the film holders for any dust or debris and clean them as needed to prevent imperfections in your film scans.

TROUBLESHOOTING

If you encounter any issues with your scanner, first ensure all cables are securely connected and the scanner is powered on. Restarting your computer and the scanner can often resolve minor software glitches. If problems persist, consult the comprehensive help section within the Epson scanning software or refer to the online support resources available on the Epson website for detailed troubleshooting steps and solutions.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Product Dimensions	10.7 x 18.8 x 4.5 inches
Item Weight	8.82 pounds (4000 Grams)
ASIN	B000VG4AY0
Item Model Number	B11B189011
Date First Available	August 26, 2007
Manufacturer	Epson
Media Type	Negatives, Slide, Photo
Scanner Type	Film, Photo, Document
Brand	Epson
Model Name	V500
Connectivity Technology	USB
Resolution	6400 dpi
Wattage	16 watts
Sheet Size	Letter
Color Depth	48 bpp

WARRANTY AND SUPPORT

The Epson Perfection V500 Photo Scanner comes with a 1-year limited manufacturer's warranty. For warranty claims or technical assistance, please refer to the official Epson support channels. You can find detailed support information, FAQs, and contact options on the Epson website.

© 2024 Epson. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question