## Manuals+

Q & A | Deep Search | Upload

## manuals.plus /

- > Rowenta /
- Rowenta SO 2020 Sprinto Silence Fan Heater Instruction Manual

### Rowenta SO 2020

# Rowenta SO 2020 Sprinto Silence Fan Heater Instruction Manual

Model: SO 2020

## Introduction

This instruction manual provides essential information for the safe and efficient use of your Rowenta SO 2020 Sprinto Silence Fan Heater. Please read all instructions carefully before operating the appliance and retain this manual for future reference.

## IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the appliance is placed on a stable, flat surface.
- Do not cover the heater to prevent overheating. Maintain adequate clearance around the appliance.
- Keep flammable materials such as furniture, curtains, and bedding at least 1 meter (3 feet) from the front and sides of the heater.
- Do not use this heater in the immediate vicinity of a bath, shower, or swimming pool.
- Ensure the voltage indicated on the appliance corresponds to your mains voltage before connecting.
- Unplug the heater when not in use or before cleaning.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory
  or mental capabilities, or lack of experience and knowledge, unless they have been given supervision
  or instruction concerning use of the appliance by a person responsible for their safety.

# **PRODUCT OVERVIEW**

Familiarize yourself with the components of your Rowenta SO 2020 Sprinto Silence Fan Heater:

- Power/Mode Selector Knob: Controls power on/off and operating modes (fan, 1000W, 2000W, Silence).
- Thermostat Control Knob: Adjusts the desired room temperature.

- Air Outlet Grille: Where heated or cool air is expelled.
- Integrated Handle: For easy portability.



Figure 1: Front view of the Rowenta SO 2020 Sprinto Silence fan heater. The appliance is black with two silver rotary control knobs on the top panel. The left knob is the power/mode selector, and the right knob is the thermostat control. The main body features a horizontal slatted air outlet grille. An integrated handle is located at the top for convenient carrying.

The Rowenta logo and "2000W" are printed on the top panel.

# SETUP

- 1. **Unpacking:** Carefully remove the heater from its packaging. Retain packaging for storage if desired.
- 2. **Placement:** Place the heater on a firm, level, heat-resistant surface. Ensure there is at least 1 meter (3 feet) of clear space around the heater to allow for proper airflow and prevent fire hazards. Do not

place it directly under a power outlet.

3. **Power Connection:** Ensure the power/mode selector knob is in the "0" (off) position. Plug the power cord into a suitable 230V AC electrical outlet.

# **OPERATING INSTRUCTIONS**

To operate your Rowenta SO 2020 Sprinto Silence Fan Heater:

- 1. Power On: Turn the power/mode selector knob (left knob) from "0" to your desired setting:
  - Fan Mode (\*): For cool air circulation without heating.
  - 1000W Heat Setting (1): For moderate heating.
  - 2000W Heat Setting (2): For rapid and powerful heating.
  - Silence Mode: A specific setting for reduced noise operation, typically available in one of the heat settings. Refer to the knob markings for the exact position.
- 2. **Set Temperature:** Turn the thermostat control knob (right knob) to your desired room temperature. The heater will operate until the set temperature is reached, then cycle on and off to maintain it.
- 3. **Frost Protection:** To activate frost protection, set the thermostat knob to the snowflake symbol †) and the power/mode selector to a heat setting. The heater will automatically turn on if the room temperature drops below approximately 5°C (41°F).
- 4. **Power Off:** To turn off the heater, rotate the power/mode selector knob back to the "0" position. Unplug the appliance from the wall socket when not in use.

## MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your heater.

## • Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Use a vacuum cleaner with a brush attachment to remove dust from the air inlet and outlet grilles.
- Never immerse the heater in water or any other liquid.
- **Storage:** If storing the heater for an extended period, clean it thoroughly and store it in its original packaging in a cool, dry place.

# **T**ROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power switch off; no power at outlet; overheat protection activated.	Ensure plug is securely in outlet; turn power switch to desired setting; check circuit breaker; unplug and allow to cool for 30 minutes before restarting.
Heater produces an unusual smell during first use.	New appliance burning off manufacturing residues.	This is normal for the first few uses and should dissipate quickly. Ensure good ventilation.

Problem	Possible Cause	Solution
Heater turns off unexpectedly.	Overheat protection activated; thermostat reached set temperature.	Check for obstructions around the heater; unplug and allow to cool. If thermostat, this is normal operation.

# **S**PECIFICATIONS

• Model: Rowenta SO 2020 Sprinto Silence

• Power Settings: 1000W, 2000W

• **Maximum Wattage:** 2400W (as per product specifications, actual operating modes are 1000W and 2000W)

• Voltage: 230 Volt

• Dimensions (L x W x H): 24 x 21.5 x 29.9 cm

• Weight: Approximately 202 g (Please note: This weight appears unusually low and may be a data entry error. Refer to product packaging for precise weight.)

• Safety Features: Overheat Protection, Frost Protection

• Energy Source: Electric with cord

## WARRANTY AND SUPPORT

Your Rowenta SO 2020 Sprinto Silence Fan Heater is covered by the manufacturer's warranty. For specific warranty details, please refer to the warranty card included with your product or contact Rowenta customer support. Do not attempt to repair the appliance yourself; this may void the warranty and pose safety risks. For technical assistance, spare parts, or service, please visit the official Rowenta website or contact their customer service department.

© 2023 Rowenta. All rights reserved.

# Related Documents - SO 2020



# Rowenta SPRINTO AQUA 2400W Heater User Manual and Safety Instructions

Detailed user manual and safety instructions for the Rowenta SPRINTO AQUA 2400W heater. Learn how to safely operate, maintain, and store your appliance.



# Rowenta SO9030 Fan Heater User Manual and Safety Guide

Comprehensive user manual and safety guide for the Rowenta SO9030 fan heater, covering operation, maintenance, troubleshooting, and important safety precautions.



## Rowenta Silence Force Vacuum Cleaner User Guide and Filter Maintenance

Comprehensive user guide for Rowenta Silence Force vacuum cleaners, detailing filter maintenance, assembly, and usage instructions. Includes multilingual support and product specifications.



## Rowenta Air Force Hot & Cool HQ7112 User Manual

User guide for the Rowenta Air Force Hot & Cool HQ7112 fan heater, detailing operation modes (AUTO, ECO, FROST GUARD), timer functions, delayed start, and safety instructions.



## Rowenta Silence Force Cyclonic Vacuum Cleaner User Guide

User guide for the Rowenta Silence Force Cyclonic vacuum cleaner, covering assembly, usage, maintenance, and accessory information. Includes safety instructions.



# Rowenta SO9420 / SO9261 / SO9266 Electric Heater User Manual & Safety Instructions

Comprehensive user manual and safety guidelines for Rowenta SO9420, SO9261, and SO9266 electric heaters. Learn about operation, maintenance, safety precautions, and environmental care.