

Alpine Corporation 43 Contemporary W/ Leds

Alpine Corporation 43" Tall Outdoor Floor Contemporary Tiered Bronze Metal Water Fountain with LED Lights

MODEL: 43 CONTEMPORARY W/ LEDS

Brand: Alpine Corporation

Introduction

This manual provides essential instructions for the safe and efficient operation, installation, and maintenance of your Alpine Corporation 43" Tall Outdoor Floor Contemporary Tiered Bronze Metal Water Fountain with LED Lights. Please read this manual thoroughly before assembly and use, and retain it for future reference.

Important Safety Information:

- Always disconnect the power supply before performing any maintenance or cleaning.
- Ensure the fountain is placed on a stable, level surface to prevent tipping.
- Do not operate the pump dry; always ensure it is fully submerged in water.
- Keep children and pets away from the fountain during operation unless supervised.
- Use only with a properly grounded electrical outlet.





Image: The Alpine Corporation 43-inch Tall Outdoor Floor Contemporary Tiered Bronze Metal Water Fountain with LED Lights, showcasing its elegant design and water flow.

Package Contents

Verify that all components are present and undamaged:

- Fountain Body (1)
- Water Pump (1)
- Power Adapter (1)
- LED Light Assembly (pre-installed or separate)
- Instruction Manual (1)

Specifications

Feature	Detail
Model Number	43 Contemporary W/ Leds
Dimensions (L x W x H)	17" x 17" x 43" (43 cm x 43 cm x 109 cm)
Item Weight	21.2 Pounds
Material	Polystone
Power Source	Corded Electric
Special Feature	Durable, LED Lights

**durable
quality**

*made of durable material
for long-lasting use*



Image: Visual representation of the fountain's dimensions, indicating a height of 43 inches (109 cm) and a length/width of 17 inches (43 cm).

Setup Instructions

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Inspect for any damage.
2. **Position the Fountain:** Choose a stable, level location for your fountain, ensuring it is near a grounded electrical outlet and away from areas where splashing water could cause damage.
3. **Install the Pump:** Place the water pump inside the fountain's reservoir. Connect the pump's tubing to the water inlet on the fountain's water distribution system. Ensure the LED light cable (if separate) is also routed correctly.
4. **Fill with Water:** Fill the fountain reservoir with distilled water until the pump is fully submerged. Do not overfill.
5. **Connect Power:** Plug the pump's power adapter into a grounded electrical outlet. The pump and LED lights should activate.

6. **Adjust Water Flow:** If your pump has an adjustable flow rate, set it to your desired level.

Your browser does not support the video tag.

Video: An official Alpine Corporation video demonstrating the 43-inch Tall Indoor/Outdoor Tiered Fountain, showing its features and operation.

Operating Instructions

Once assembled and filled with water, operating your fountain is straightforward:

- **Power On/Off:** Plug the power adapter into a grounded electrical outlet to turn the fountain on. Unplug it to turn it off.
- **Water Level:** Regularly check the water level. Due to evaporation, water levels will decrease over time. Refill with distilled water as needed to ensure the pump remains fully submerged.
- **LED Lights:** The integrated LED lights will illuminate automatically when the fountain is powered on, enhancing the visual appeal, especially in low-light conditions.



Maintenance

Regular maintenance ensures the longevity and optimal performance of your fountain:

- **Cleaning the Fountain:** Periodically drain the water and clean the fountain surface with a soft cloth and mild soap. Rinse thoroughly to remove any residue.
- **Pump Cleaning:** Disconnect the pump from power. Remove the pump from the fountain and disassemble it according to the pump's specific instructions (usually involves removing the impeller cover). Clean the impeller and pump housing to remove any debris or mineral buildup.
- **Water Quality:** Use distilled water to minimize mineral buildup and algae growth. If using tap water, consider adding a fountain algaecide (follow product instructions).
- **Winterization:** In freezing climates, drain all water from the fountain and pump. Clean and dry all components. Store the pump indoors in a dry, frost-free location. Cover the fountain or store it indoors to protect it from harsh winter conditions.





Image: A detailed view of the water cascading down the bronze metal tiers, highlighting the continuous flow that requires regular maintenance.

Troubleshooting

If you encounter issues with your fountain, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Pump not operating	Not plugged in; circuit breaker tripped; low water level; clogged pump.	Ensure power is connected; check circuit breaker; add water to reservoir; clean pump.
Water flow is weak or inconsistent	Low water level; kinked tubing; clogged pump or tubing; pump flow rate set too low.	Add water; straighten tubing; clean pump/tubing; adjust pump flow rate.
Excessive splashing	Water flow too high; uneven surface.	Adjust pump flow rate; ensure fountain is on a level surface.
LED lights not working	Loose connection; damaged LED unit.	Check all connections; contact support if lights are damaged.

Warranty and Support

Your Alpine Corporation water fountain is backed by a **two-year manufacturer's support** for a worry-free experience. This warranty covers defects in materials and workmanship under normal use.

For warranty claims, technical assistance, or replacement parts, please contact Alpine Corporation customer service directly. Keep your proof of purchase for warranty validation.

For further assistance, please visit the official Alpine Corporation website or refer to the contact information provided with your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question