

## Durgol 0297

# Durgol Swiss Steamer Descaler and Decalcifier Instruction Manual

Model: 0297

## 1. PRODUCT OVERVIEW

---

The Durgol Swiss Steamer is a professional-grade descaling solution designed to remove calcium deposits and limescale buildup from steamer ovens. This product helps maintain and enhance the performance of your appliance. Its formula is effective against tough limescale buildup that can compromise machine performance.

Key features include:

- **Effective Descaling:** Specifically formulated to break up harmful calcium deposits and limescale.
- **Material Gentle:** Designed to be safe for use with various steamer oven materials.
- **No Residue:** Leaves no residue, odor, or aftertaste after use.
- **Ready to Use:** No pre-mixing or preparation required.
- **Swiss Quality:** Developed and manufactured in Switzerland, adhering to strict safety and quality standards.

**durgol**  
SWISS STEAMER  
Special decalcifier  
Descalcificador especial

Spezial-Entkalker  
Détartrant spécial  
Special decalcifier  
Descalcificador especial

for steamers of all brands  
para aparatos de cocción al vapor de todas las marcas

Recommended by  
Recomendado por

Das Schweizer Original gegen Kalk  
L'original suisse contre le calcaire

The Swiss Original against Limescale  
El original suizo contra la cal

**For steam cookers  
of all brands**

**The Swiss Original against Limescale**

Image 1: Durgol Swiss Steamer descaler shown with a steam oven, indicating compatibility with various brands.

## 2. SAFETY INFORMATION

---

### 2.1. Ingredients

The primary active ingredients are descaler/decalcifier agents.

### 2.2. Legal Disclaimer

Statements regarding dietary supplements have not been evaluated by the FDA and are not intended to diagnose, treat, cure, or prevent any disease or health condition. This product is for appliance descaling only and should not be ingested or used for medical purposes.

**Warning:** Keep out of reach of children. Avoid contact with eyes and skin. In case of contact, rinse thoroughly with water. If irritation persists, seek medical attention. Use in a well-ventilated area.

## 3. USAGE INSTRUCTIONS (OPERATING)

---

Follow these steps to descale your steamer oven using Durgol Swiss Steamer:

1. **Preparation:** Ensure your steamer oven is cool and empty. Remove any food residues or accessories.
2. **Add Descaler:** Pour the entire contents of one 16.9 fluid-ounce bottle of Durgol Swiss Steamer directly into

the water tank of your steam oven.

3. **Fill with Water:** Fill the remaining part of the water tank with clean tap water, according to your oven's maximum fill line.
4. **Start Descaling Program:** If your steam oven has a dedicated decalcification program, start it according to the manufacturer's instructions.
5. **Manual Descaling (if no program):** If your oven does not have a decalcification program, distribute the descaler liquid throughout the water tank with a clean sponge. Allow it to stand for the time recommended by your oven's manufacturer (typically 30 minutes to 1 hour).
6. **Rinse:** After the program or standing time is complete, thoroughly rinse the water tank and any removable parts with clean water. Run at least two full cycles with clean water through the oven to ensure all descaler residue is flushed out.
7. **Dry:** Dry the water tank and interior of the oven well before next use.



Image 2: Demonstrating the pouring of Durgol Swiss Steamer into an appliance's water reservoir.

#### 4. MAINTENANCE

---

Regular descaling of your steam oven is crucial for optimal performance and longevity. The frequency of descaling depends on the hardness of your water and how often you use the appliance. It is generally recommended to descale your steam oven every 2 to 3 months, or as indicated by your oven's manufacturer or its descaling

indicator.

## 5. SPECIFICATIONS

---

Feature	Detail
Product Name	Durgol Swiss Steamer, Descaler and Decalcifier
Model Number	0297
Brand	Durgol
Item Form	Liquid
Scent	Fragrance Free
Material Feature	Unscented
Specific Uses For Product	Oven (Steamer Ovens)
Product Dimensions	3.25 x 2 x 8.56 inches
Item Weight	1.06 Pounds
Volume	16.9 Fluid Ounces (500 ml)
Manufacturer	Durgol

## 6. TROUBLESHOOTING

---

This section provides general advice for common issues. For specific problems related to your steamer oven, please consult your appliance's instruction manual.

- **Descaling not effective:** Ensure you have used the correct amount of Durgol Swiss Steamer as per instructions. Verify that your appliance's descaling cycle (if applicable) was completed without interruption. Water hardness can affect descaling frequency; consider descaling more often if you have very hard water.
- **Residue after descaling:** Durgol Swiss Steamer is designed to leave no residue. If you observe any, it may indicate insufficient rinsing. Run additional cycles with clean water through your appliance until no residue is visible or detectable.

## 7. SUPPORT & WARRANTY

---

Information regarding product warranty and direct customer support for Durgol Swiss Steamer is not provided in this manual. Please refer to the product packaging or the official Durgol website for the most current support and warranty details.