

[Manuals.plus](#) /

› [Bush Business Furniture](#) /

› BUSH FURNITURE Segments Small Swivel TV Stand Instruction Manual

Bush Business Furniture VS11550A-03

BUSH FURNITURE Segments Small Swivel TV Stand Instruction Manual

Model: VS11550A-03

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bush Furniture Segments Small Swivel TV Stand. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use damaged parts.
- Assembly requires at least two people due to the weight and size of components.
- This unit is designed for tip-free safety when assembled correctly and used within specified weight limits.
- Do not exceed the maximum weight capacity for the TV mount or shelves.
- Keep small parts away from children during assembly.

SETUP AND ASSEMBLY

Assembly is required for this TV stand. It is highly recommended that two people perform the assembly to ensure safety and ease of construction. The packaging contains heavy components; exercise caution when unpacking.

Unpacking and Preparation:

1. Carefully open the packaging. Note that the packaging may contain cheap styrofoam which can create a mess; prepare a clean workspace.
2. Identify all components against the parts list provided in the included instruction manual. If any parts are missing or damaged, contact customer service immediately.
3. Locate the clear plastic separators. These are very thin and may be stamped together in layers. Carefully peel them apart to ensure all are accounted for.

Assembly Steps:

Follow the step-by-step instructions provided in the physical instruction manual included with your purchase. Key points to remember during assembly:

- **Frame Construction:** Assemble the solid wood frame according to the diagrams.
- **Shelf Installation:** The three black tempered-glass shelves are fixed. When installing, ensure they are properly aligned with the dowels. It may be helpful to prop a book or similar item under the shelf to hold it in place while securing it to the frame. Each shelf has

a maximum weight capacity of 25 lbs.

- **TV Mounting Bracket:** Install the sturdy mounting bracket as directed. This bracket is designed to accommodate most flat-panel TVs up to 60 inches and 154 lbs. Ensure all screws are securely fastened. The stand includes various screws for mounting your TV; select the correct ones for your television model.
- **Wire Management:** Utilize the cutouts in the back post and the built-in Velcro straps for neat wire management. This helps to keep cables organized and out of sight.



Figure 1: Product dimensions. The stand measures approximately 57 inches (144.6 cm) wide, 22 1/8 inches (55.9 cm) deep, and 24 1/8 inches (61.2 cm) high.

OPERATING INSTRUCTIONS

- **TV Placement:** Place your flat-panel TV securely on the installed mounting bracket. Ensure the TV's weight does not exceed 154 lbs and its size is within 60 inches.
- **Swivel Function:** The TV mounting bracket allows for a 10-degree swivel to the right or left. Gently adjust the TV to your desired viewing angle.
- **Component Placement:** Utilize the three tempered-glass shelves for your media components such as DVD players, gaming consoles, or sound systems. Ensure the weight on each shelf does not exceed 25 lbs.
- **Cable Management:** Route all cables through the grommets and use the Velcro straps at the back of the stand to maintain a tidy

appearance and prevent tangling.

MAINTENANCE

To maintain the appearance and longevity of your TV stand:

- **Cleaning:** Wipe the surfaces with a dry cloth. Avoid abrasive cleaners or harsh chemicals that may damage the finish.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Weight Limits:** Adhere to the specified weight limits for the TV mount and shelves to prevent structural damage.

TROUBLESHOOTING

- **Missing or Damaged Parts:** If you discover any missing or damaged components during unpacking or assembly, please contact customer service immediately for replacement parts.
- **TV Support Arm Lean:** If the TV support arm appears to lean slightly, ensure the TV is centered and within the specified weight limits. Verify all mounting screws are securely tightened. Some users have observed a slight downward tilt which can help reduce screen glare.
- **Assembly Difficulties:** Refer to the detailed assembly instructions included with your product. If you encounter persistent difficulties, contact customer service for assistance.

SPECIFICATIONS

Product Dimensions (W x D x H)	56.93 x 22.01 x 24.09 inches (144.6 x 55.9 x 61.2 cm)
Item Weight	61.8 pounds
TV Size Capacity	Up to 60 inches
TV Weight Capacity	Up to 154 lbs
Shelf Weight Capacity	25 lbs per shelf
Swivel Range	10 degrees right or left
Finish Type	Rosebud Cherry with Bright Silver accents
Model Number	VS11550A-03
Manufacturer	Bush Furniture

WARRANTY INFORMATION

This Bush Furniture Segments Small Swivel TV Stand comes with a **1-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and material flaws under normal use. It does not cover damage due to improper assembly, misuse, accidents, or normal wear and tear.

CUSTOMER SUPPORT

For assembly assistance, missing parts, or any other inquiries regarding your Bush Furniture Segments Small Swivel TV Stand, please contact our customer service team:

Phone: [800-950-4782](tel:800-950-4782)

Please have your model number (VS11550A-03) and purchase information ready when you call.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B000W8MZO4>

More documents and user manuals: <https://manuals.plus/>