

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Star Wars Tours Disney Exclusive G2-4T Action Figure Instruction Manual

Hasbro 4149951

Hasbro Star Wars Tours Disney Exclusive G2-4T Action Figure Instruction Manual

Model: G2-4T (4149951)

1. INTRODUCTION

Welcome to the instruction manual for your Hasbro Star Wars Tours Disney Exclusive G2-4T Action Figure. This guide provides essential information on the setup, operation, maintenance, and specifications of your new collectible. Please read this manual thoroughly to ensure proper handling and to maximize your enjoyment of this product.

2. PRODUCT OVERVIEW

The G2-4T action figure is a detailed representation of the G2 droids from the Star Tours attraction. It features a unique sculpt and paint application, designed for display and light play.

10181

COLLECTION

1



STAR WARS



AGES
4+



WARNING:

CHOKING HAZARD—Small parts.
Not for children under 3 years.



STAR
TOUR

Figure 2.1: The G2-4T action figure as it appears in its packaging. This image shows the overall design and presentation of the product.

The figure is crafted from durable plastic and features several points of articulation, including the shoulders, hips, and neck, allowing for various poses. Its design captures the essence of the G2 droids, making it a notable addition to any Star Wars collection.

3. SETUP

1. **Unboxing:** Carefully remove the action figure from its packaging. Inspect the figure for any visible damage or missing parts. The package should contain the G2-4T action figure and any included accessories.
2. **No Assembly Required:** This action figure comes pre-assembled and does not require any additional assembly.
3. **Placement:** Choose a stable, flat surface for displaying your figure. Avoid direct sunlight or extreme temperatures to prevent material degradation or paint fading.

4. OPERATING THE FIGURE

The G2-4T action figure operates in a manual mode, meaning all interactions are physical.

- **Posing:** Gently manipulate the articulated joints at the shoulders, hips, and neck to position the figure as desired. Avoid excessive force to prevent damage to the joints.
- **Display:** The figure is designed for display. Ensure it is placed in a secure location where it will not easily fall or be knocked over.
- **Play:** While durable, this figure is intended for light play. Avoid rough handling, throwing, or dropping the figure to maintain its condition.

5. MAINTENANCE

- **Cleaning:** To clean the figure, gently wipe it with a soft, dry, lint-free cloth. For stubborn dirt, a slightly damp cloth (water only) can be used, followed immediately by a dry cloth. Do not use harsh chemicals, abrasive cleaners, or solvents, as these can damage the paint or plastic.
- **Storage:** When not on display, store the figure in a cool, dry place away from direct sunlight and extreme temperatures. Original packaging can be used for long-term storage to protect it from dust and environmental factors.
- **Handling:** Always handle the figure by its main body parts. Avoid pulling on small or delicate components.

6. TROUBLESHOOTING

Most issues with action figures are minor and can be resolved with careful handling.

- **Loose Joints:** If a joint becomes slightly loose over time, it may be possible to tighten it gently. Avoid applying glues or adhesives unless specifically designed for action figure repair, as this can permanently seize the joint.
- **Stiff Joints:** If a joint is stiff, gently warm the area with a hairdryer on a low setting for a few seconds (hold at a safe distance) to make the plastic more pliable, then carefully attempt to move the joint. Do not force it.
- **Paint Transfer/Scuffs:** Minor scuffs can sometimes be carefully buffed out with a very soft cloth. For paint transfer,

consult specialized hobby forums or professional advice, as improper cleaning can damage the figure's finish.

- **Missing Parts:** If any parts were missing upon unboxing, please refer to the Warranty and Support section for contact information.

7. SPECIFICATIONS

Feature	Detail
Brand Name	Hasbro
Model Name	G2-4T
Model Number	4149951
Toy Figure Type	Action Figure
Character	Star Wars (G2-4T Droid)
Manufacturer Minimum Age	5.00 Months
UPC	076930101612
Assembly Required	No
Batteries Required	No
Operation Mode	Manual
Outer Material	Plastic
Item Weight	0.1 Pounds
Number of Pieces	4 (Figure and accessories, if any)
Item Dimensions	8.4 x 5.1 x 1.5 inches

8. WARRANTY AND SUPPORT

For information regarding product warranty, returns, or to contact customer support, please refer to the official Hasbro website or the retailer from whom you purchased this product.

You can also visit the official Hasbro store on Amazon for more information:[Hasbro Toyland Store](#).

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question