

Peg Perego IMPDIBNA76PBU49

Peg Perego Prima Pappa Diner Instruction Manual

Model: IMPDIBNA76PBU49

INTRODUCTION

The Peg Perego Prima Pappa Diner is a versatile high chair and feeding system designed for infants through toddlers. It features a dual vinyl seat upholstery with a Comfort-dry™ microfiber fabric cotton cover, ensuring breathability and softness. This high chair is engineered for convenience, offering multiple adjustments for height and recline, a dual tray system, and compact folding capabilities.

Key features include:

- Easy folding design with a double tray system.
- Adjustable height with 7 positions and 4 tilt-in-space reclining positions.
- Stain-resistant micro-leather-like material and a 5-point safety harness system.
- Adjustable footrest with three positions to accommodate a child's growth.
- Non-scratching rubber wheels with rear brakes to protect flooring.
- Net storage pouch on the back of the seat.
- Tray stores easily and compactly on chair legs when folded.



Image: The Peg Perego Prima Pappa Diner high chair in Bubbles Red, showcasing its full assembly with the tray attached and the adjustable frame.

SETUP

The Peg Perego Prima Pappa Diner high chair is designed to be fully assembled and ready for use upon unboxing. No complex assembly steps are typically required.

Unfolding the High Chair

1. Carefully remove the high chair from its packaging.
2. Place the high chair on a flat, stable surface.
3. Locate the folding mechanism (refer to the product's physical labels or quick start guide for exact location, usually near the base or side frame).
4. Release the locking mechanism and gently unfold the chair until it clicks securely into its open position. Ensure all legs are fully extended and locked.

Attaching the Tray

The dual tray system can be easily attached to the high chair. Align the tray with the armrests and slide it into place until it locks securely. Ensure both sides are properly engaged.

OPERATING INSTRUCTIONS

Adjusting Height

The high chair offers 7 height positions. To adjust, locate the height adjustment levers (typically on the side of the frame). Squeeze or press the levers and simultaneously raise or lower the seat to the desired height. Release the levers to lock the seat into position.

Reclining the Seat

The seat can be reclined into 4 tilt-in-space positions. Find the recline adjustment mechanism (usually on the back of the seat). Activate the mechanism and gently tilt the seat to the desired angle. Ensure it locks securely in place before placing a child in the chair.

Adjusting the Footrest

The footrest has three adjustable positions to accommodate a child's growth. Locate the footrest adjustment points (typically on the sides of the footrest support). Adjust to the appropriate height for your child's comfort and support.

Using the Safety Harness

Always secure your child using the 5-point safety harness. Place the child in the seat, bring the shoulder straps over their shoulders, and the waist straps around their waist. Connect all buckles into the central buckle until you hear a click. Adjust the straps snugly but comfortably around the child.

Moving the High Chair

The high chair is equipped with large, quiet, mar-resistant caster wheels for easy movement. To move the chair, ensure the rear brakes are disengaged. Push or pull the chair to the desired location. Engage the rear brakes once the chair is in position to prevent accidental movement.



Image: A close-up view of one of the high chair's mar-resistant caster wheels, designed to protect flooring, with a safety certification sticker visible on the frame.

MAINTENANCE AND CLEANING

Cleaning the Tray

The dual dinner tray is dishwasher safe for convenient cleaning. Remove the tray from the high chair and place it in the dishwasher. Alternatively, wash by hand with warm soapy water and rinse thoroughly.



Image: A woman demonstrating the ease of cleaning by placing the high chair's removable tray into a dishwasher.

Cleaning the Upholstery

The dual vinyl seat upholstery with Comfort-dry™ microfiber fabric can be cleaned with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners. Allow the fabric to air dry completely before re-use.

General Care

- Regularly inspect all parts for wear and tear, especially the safety harness, buckles, and adjustment mechanisms.
- Ensure all locking mechanisms are functioning correctly before each use.
- Store the high chair in a clean, dry place when not in use.

TROUBLESHOOTING

This section provides general guidance for common issues. For specific problems not listed, please contact customer support.

- **Chair does not fold/unfold smoothly:** Check for any obstructions in the folding mechanism. Ensure all levers are properly engaged or disengaged as required.
- **Tray does not attach securely:** Verify that the tray is aligned correctly with the armrests and pushed in until it clicks on both sides. Check for any food debris or obstructions in the attachment points.
- **Wheels are not rolling freely:** Inspect wheels for debris (e.g., hair, lint). Ensure the rear brakes are fully disengaged.
- **Seat adjustment issues:** Ensure the adjustment levers are fully activated when attempting to change height or recline. Do not force adjustments.

SPECIFICATIONS

Feature	Detail
Product Dimensions	11.25 x 23 x 40.75 inches
Item Model Number	IMPDIBNA76PBU49
Material Type	Cotton, Leather, Rubber
Item Weight	19 pounds
Color	Bubbles Red
Age Range (Description)	Infant
Portability	Yes
Safety Certification	JPMA safety certified
Origin	Made in Italy

WARRANTY AND SUPPORT


Specific warranty details for the Peg Perego Prima Pappa Diner are not provided in this manual. For information regarding warranty coverage, claims, or technical support, please refer to the official Peg Perego website or contact their customer service directly.

You can typically find contact information and detailed warranty policies on the manufacturer's official website: us.pegperego.com

© 2024 Peg Perego. All rights reserved.

Related Documents

	<p>Peg Perego Prima Pappa Follow Me: Manuale d'Uso Completo e Sicurezza</p> <p>Scopri il seggiolone evolutivo Peg Perego Prima Pappa Follow Me, ideale dalla nascita fino ai 3 anni. Guida completa all'uso, alle funzioni sdraiata e seggiolone, e alle norme di sicurezza.</p>
	<p>Peg Perego Prima Pappa Follow Me High Chair Instructions</p> <p>Comprehensive instructions for the Peg Perego Prima Pappa Follow Me high chair, covering assembly, usage, safety, and maintenance in multiple languages.</p>

<p> <small> 1. Introduzione 2. Sicurezza 3. Montaggio 4. Uso 5. Pulizia e manutenzione 6. Smontaggio 7. Note 8. Note importanti 9. Note importanti 10. Note importanti 11. Note importanti 12. Note importanti 13. Note importanti 14. Note importanti 15. Note importanti 16. Note importanti 17. Note importanti 18. Note importanti 19. Note importanti 20. Note importanti 21. Note importanti 22. Note importanti 23. Note importanti 24. Note importanti 25. Note importanti 26. Note importanti 27. Note importanti 28. Note importanti 29. Note importanti 30. Note importanti 31. Note importanti 32. Note importanti 33. Note importanti 34. Note importanti 35. Note importanti 36. Note importanti 37. Note importanti 38. Note importanti 39. Note importanti 40. Note importanti 41. Note importanti 42. Note importanti 43. Note importanti 44. Note importanti 45. Note importanti 46. Note importanti 47. Note importanti 48. Note importanti 49. Note importanti 50. Note importanti 51. Note importanti 52. Note importanti 53. Note importanti 54. Note importanti 55. Note importanti 56. Note importanti 57. Note importanti 58. Note importanti 59. Note importanti 60. Note importanti 61. Note importanti 62. Note importanti 63. Note importanti 64. Note importanti 65. Note importanti 66. Note importanti 67. Note importanti 68. Note importanti 69. Note importanti 70. Note importanti 71. Note importanti 72. Note importanti 73. Note importanti 74. Note importanti 75. Note importanti 76. Note importanti 77. Note importanti 78. Note importanti 79. Note importanti 80. Note importanti 81. Note importanti 82. Note importanti 83. Note importanti 84. Note importanti 85. Note importanti 86. Note importanti 87. Note importanti 88. Note importanti 89. Note importanti 90. Note importanti 91. Note importanti 92. Note importanti 93. Note importanti 94. Note importanti 95. Note importanti 96. Note importanti 97. Note importanti 98. Note importanti 99. Note importanti 100. Note importanti </small> </p>  <p>prima pappa follow me</p>	<p> Peg Perego Prima Pappa Follow Me User Manual Comprehensive instructions for the Peg Perego Prima Pappa Follow Me high chair and recliner, covering assembly, usage, safety, cleaning, and maintenance. </p>
<p>  </p> 	<p> Peg Perego Prima Pappa Follow Me High Chair User Manual Comprehensive instructions for the Peg Perego Prima Pappa Follow Me high chair, covering assembly, safety, usage modes (recliner and high chair), cleaning, maintenance, and disposal. </p>