

## SINGER ESP-2

# SINGER Magic ESP-2 Electronic Steam Press Instruction Manual

Model: ESP-2

## INTRODUCTION

This manual provides detailed instructions for the safe and efficient operation of your SINGER Magic ESP-2 Electronic Steam Press. Please read all instructions carefully before use and retain this manual for future reference.

The SINGER Magic Steam Press is designed to provide professional pressing results at home, featuring a large pressing area and adjustable heat and steam settings. It includes an auto shut-off with an audible alarm for safety.

## SAFETY INFORMATION

- Always unplug the appliance when not in use and before cleaning.
- Do not operate the steam press with a damaged cord or plug.
- Keep the appliance out of reach of children.
- The appliance is warranted for use in the US and Canada at 110 volts only.
- The auto shut-off with electronic alarm sounds every 10 seconds if the handle is left down too long, reminding you to lift the handle to prevent fabric damage.

## PRODUCT OVERVIEW

The SINGER Magic ESP-2 Electronic Steam Press offers a large pressing surface, electronic temperature controls, and powerful steam capabilities for efficient garment care.



Image: The SINGER Magic ESP-2 Electronic Steam Press in its closed position, showcasing its compact design and control panel.



Image: The SINGER Magic ESP-2 Electronic Steam Press in an open position, with steam visible, demonstrating its large pressing surface.

## SETUP

1. **Unpacking:** Carefully remove the steam press from its packaging. Ensure all accessories (spray bottle, measuring cup, pressing cushion) are present.
2. **Placement:** Place the steam press on a stable, heat-resistant surface. Ensure adequate space around the unit for safe operation.
3. **Filling the Water Tank:**  
Locate the water tank on the side of the unit. Remove the cap and use the provided measuring cup or no-spill water can to fill the tank with distilled water. Do not overfill. Replace the cap securely.

Your browser does not support the video tag.

Video: This video demonstrates how to fill the water tank of the SINGER Magic ESP-2 Steam Press using the provided no-spill water can for easy refills.

4. **Power Connection:** Plug the power cord into a 110-volt electrical outlet.
5. **Power On and Temperature Selection:**  
Unlock the handle by rotating the dial to the 'on' position. The power indicator light will illuminate. Select the desired temperature setting based on your fabric type (Nylon, Silk, Wool, Cotton, Linen) using the control panel. Allow the unit to heat up until the temperature indicator light signals it's ready.

## OPERATING INSTRUCTIONS

1. **Preparing Garments:** Lay the garment flat on the pressing surface, ensuring it is smooth and free of

wrinkles. The extra-large pressing surface is suitable for various items like tablecloths, curtains, and dress pants.

2. **Pressing:** Gently lower the upper pressing plate onto the garment. The unit will apply even pressure. For best results, hold the plate down for a few seconds.
3. **Using Steam:** To activate a powerful burst of steam, press the steam button located on the handle. This is effective for stubborn wrinkles.
4. **Using the Pressing Cushion:** For sleeves, collars, and other contoured areas, place the pressing cushion inside the garment part. This allows for precise steaming and pressing without creating new creases.
5. **Fusible Projects:** The steam press is ideal for fusible projects, providing consistent heat and pressure for proper adhesion. Place the fusible material and fabric on the pressing surface, cover with a pressing cloth if necessary, and press.
6. **Auto Shut-Off:** The unit features an automatic shut-off with an audible alarm. If the handle is left down for an extended period, the alarm will sound, and the unit will power off to prevent overheating and fabric damage. Lift the handle to reset the safety feature.



Image: A person using the SINGER Magic ESP-2 Electronic Steam Press to smooth a garment, demonstrating the pressing action.

## MAINTENANCE

---

- **Cleaning the Pressing Surface:** Allow the unit to cool completely. Wipe the pressing surface with a damp cloth. For stubborn residue, use a mild, non-abrasive cleaner.
- **Draining the Water Tank:** Regularly drain any remaining water from the tank after use to prevent mineral buildup.
- **Storage:** Store the steam press in a cool, dry place. The locking handle allows for easy transport and storage.

## TROUBLESHOOTING

---

- **No Steam:** Ensure the water tank is filled and the unit has reached the selected temperature. Check if the steam button is being pressed correctly.
- **Unit Not Heating:** Verify the power cord is securely plugged in and the unit is turned on. Check the temperature setting.
- **Audible Alarm Sounds:** This indicates the handle has been left down for too long. Lift the handle to reset the safety feature.

- **Water Leaking:** Ensure the water tank cap is securely closed and the tank is not overfilled.

## SPECIFICATIONS

Feature	Detail
Model	ESP-2
Brand	SINGER
Product Dimensions	25.8"L x 21.2"W x 8.2"H (65.5cm x 53.8cm x 20.8cm)
Item Weight	22 Pounds (9.98 kg)
Voltage	120 Volts
Wattage	1540 watts
Upper Temperature Rating	154 Degrees Celsius
Material	Alloy Steel, Aluminum, Stainless Steel
Included Components	Measuring Cup, Pressing Cushion, Spray Bottle
Recommended Uses	Curtain, Dress Pants, Tablecloth

## WARRANTY INFORMATION

The SINGER Magic ESP-2 Electronic Steam Press comes with the following warranty:

- Wiring and electronic parts: Two (2) years from the date of purchase.
- All other parts: Ninety (90) days from the date of purchase.






Please retain your proof of purchase for warranty claims.

## SUPPORT

For further assistance, product registration, or to explore other SINGER products, please visit the official SINGER website or contact customer support.

You can also visit the [SINGER Store on Amazon](#).

### Related Documents - ESP-2

 <p>The cover of the instruction manual for the SINGER SteamCraft Plus Steam Iron. It features the SINGER logo at the top left, the title 'SteamCraft Plus Steam Iron Instruction Manual' in the center, and an illustration of the steam iron below. A small note at the bottom says 'Please read all instructions before use.'</p>	<p><a href="#">SteamCraft Plus Steam Iron Instruction Manual</a></p> <p>Comprehensive instruction manual for the SINGER SteamCraft Plus Steam Iron, covering features, operation, safety, maintenance, and troubleshooting for efficient household ironing.</p>
 <p>The cover of the Singer 2024 General Catalog. It features the SINGER logo at the top left, the title 'Catalogo Generale 2024' in the center, and a photograph of a woman sewing on a machine below.</p>	<p><a href="#">Catalogo Generale Singer 2024: Macchine da Cucire, Accessori e Elettrodomestici</a></p> <p>Scopri il catalogo completo Singer 2024, con una vasta gamma di macchine da cucire, accessori innovativi, kit per quilting e ricamo, e la linea Singer Home Essentials per la casa. Trova gli strumenti perfetti per ogni progetto creativo.</p>
 <p>The cover of the instruction manual for the SINGER SP-550 Professional Steam Press. It features the SINGER logo at the top left, the title 'Professional Steam Press Instruction Manual' in the center, and an illustration of the steam press below. A small note at the bottom says 'Please read all instructions before use.'</p>	<p><a href="#">SINGER SP-550 Professional Steam Press Instruction Manual</a></p> <p>Official instruction manual for the SINGER SP-550 Professional Steam Press. Learn about safe operation, features like auto shut-off and temperature control, cleaning, and troubleshooting. Get professional results for your garments.</p>
 <p>The cover of the parts list and diagrams for the Singer 500A sewing machine. It features the SINGER logo at the top left and the model number '500A' in the center.</p>	<p><a href="#">Singer 500A Sewing Machine Parts List and Diagrams</a></p> <p>Explore the official parts list and detailed diagrams for the Singer 500A sewing machine, including electrical components for related models. Find part numbers for maintenance and repair.</p>
 <p>The cover of the usage manual for the Singer 6199, 6180, and 6160 sewing machines. It features the SINGER logo at the top left, an illustration of a sewing machine in the center, and the model numbers '6199/6180/6160' and the title 'KULLANIM KILAVUZU' at the bottom.</p>	<p><a href="#">Singer 6199/6180/6160 Dikiş Makinesi Kullanım Kılavuzu</a></p> <p>Singer 6199, 6180 ve 6160 ev tipi dikiş makineleri için kapsamlı kullanım kılavuzu. Bu belge, makinenin güvenli kurulumu, tüm dikiş fonksiyonlarının kullanımı, düzenli bakım ve sorun giderme adımları hakkında detaylı bilgiler sunar.</p>

SINGER  
107W5

[Singer 107W5 Sewing Machine Parts List and Index](#)

Comprehensive parts list and index for the Singer 107W5 sewing machine, detailing components for the machine head, bobbin winder, and accessories.