

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Tombow](#) /

› [Tombow 62106 Mono Permanent Adhesive Applicator User Manual](#)

Tombow 62106

Tombow 62106 Mono Permanent Adhesive Applicator User Manual

Model: 62106 | Brand: Tombow

INTRODUCTION

The Tombow Mono Permanent Adhesive Applicator is designed for instant, clean, and wrinkle-free bonding. It is suitable for various materials including paper, photos, and cardstock. This manual provides instructions for the proper use and maintenance of your adhesive applicator.




Figure 1: Tombow Mono Permanent Adhesive Applicator (Model 62106)


This image shows the blue Tombow Mono Permanent Adhesive Applicator from a top-down perspective, highlighting its transparent casing and internal adhesive tape mechanism.

Key features include:

- Instant, clean, and wrinkle-free bonding.
- Safe for use on paper, photos, and cardstock.
- Permanent bond, acid-free, and refillable design.
- Approved for Photographic Activity Test (PAT).
- Adhesive dimensions: 1/3 inch x 472 inches (8.4 mm x 12 m).

SETUP AND FIRST USE

Before using your Tombow Mono Permanent Adhesive Applicator, ensure it is ready for operation.



TOMBOW

GLUE TAPE
RUBAN
ADHÉSIF



PERMANENT
REFILLABLE
DOUBLE-SIDED ADHESIVE

PERMANENT
RECHARGEABLE
RUBAN ADHÉSIF À DOUBLE FACE

1/3 in x 39 ft
8.4 mm x 12 m

Figure 2: Product Packaging Overview

This image displays the Tombow Mono Permanent Adhesive Applicator within its retail packaging, emphasizing its key attributes such as being permanent, refillable, and double-sided.

1. Remove the applicator from its packaging.
2. Locate the protective cover at the tip of the applicator.
3. Pull the cover away from the tip and lock it into place to expose the adhesive tape.

OPERATING INSTRUCTIONS

Follow these steps to effectively apply the permanent adhesive:



Figure 3: Applying Adhesive

A hand is shown holding the blue Tombow Mono Permanent Adhesive Applicator, pressing it onto a dark surface to dispense the adhesive tape in a straight line.

1. **Grip and Position:** Grasp the applicator firmly and position it at an angle, as shown in Figure 3.
2. **Apply Adhesive:** With constant, light pressure, slowly roll the applicator onto the desired surface.
3. **Finish Application:** When finished applying, lift the applicator straight off the surface.



Figure 4: Applicator Tip Detail

This close-up image focuses on the transparent dispensing tip of the Tombow Mono Permanent Adhesive Applicator, showing the adhesive tape being released.

MAINTENANCE: REFILLING THE ADHESIVE

The Tombow Mono Permanent Adhesive Applicator is designed for easy refilling. Use only Tombow snap-in adhesive cartridges (Model 62107 refills sold separately).



Figure 5: Opening for Refill

This image shows the Tombow Mono Permanent Adhesive Applicator partially opened, revealing the internal mechanism and the adhesive cartridge ready for replacement.

1. **Open Applicator:** Gently separate the two halves of the applicator casing. Refer to Figure 5 and Figure 6 for visual guidance.
2. **Remove Old Cartridge:** Carefully remove the empty adhesive cartridge.
3. **Insert New Cartridge:** Insert a new Tombow Mono Permanent Adhesive refill cartridge (Model 62107) into the applicator, ensuring it snaps securely into place.
4. **Close Applicator:** Align the two halves of the applicator and press them together until they click, securing the new cartridge.



Figure 6: Refill Cartridge Insertion

This image illustrates the process of opening the applicator and inserting a new adhesive refill cartridge, with both hands involved in the action.

TROUBLESHOOTING

If you encounter issues with your adhesive applicator, consider the following common solutions:

Problem	Possible Cause	Solution
Adhesive tape not dispensing smoothly or jamming.	Excessive pressure during application, or incorrect angle.	Apply with light, consistent pressure. Ensure the applicator is held at a consistent angle (approximately 45 degrees) to the surface.
Adhesive not sticking effectively.	Surface may be unsuitable, or adhesive cartridge is empty.	Ensure the surface is clean, dry, and compatible with permanent adhesive. Check if the cartridge needs refilling.

SAFETY INFORMATION

- Keep out of reach of children.
- Do not ingest adhesive.
- Store in a cool, dry place away from direct sunlight to prevent adhesive degradation.

SPECIFICATIONS

Feature	Detail
Brand	Tombow
Model Number	62106
Material	Plastic
Item Form	Tape
Special Feature	Strong, Permanent, Acid-Free, Photo-Safe
Color	Blue
Item Package Quantity	1 Applicator (with 1 cartridge)
Viscosity	Medium
Water Resistance Level	Water Resistant
Unit Count	39.0 Feet (1/3 inch x 472 inches / 8.4 mm x 12 m)
Product Dimensions	7.5 x 3.4 x 0.9 inches
Item Weight	1.28 ounces
UPC	085014621069 (Primary)

WARRANTY AND SUPPORT

Tombow products are manufactured to high-quality standards. For specific warranty information or support inquiries, please refer to the official Tombow website or contact their customer service directly. Keep your purchase receipt for any warranty claims.

Manufacturer: Tombow

Website: [TombowUSA.com](https://www.tombowusa.com)

PRODUCT VIDEOS

No official product videos from the seller were provided in the available data for embedding in this manual.

