

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [DURACELL](#) /


› [Duracell Fastest Value Charger \(CEF14DX\) User Manual](#)

## DURACELL DURCEF14

# Duracell Fastest Value Charger (CEF14DX) User Manual

### 1. INTRODUCTION AND OVERVIEW

The Duracell Fastest Value Charger (model CEF14DX) is designed for efficient charging of NiMH AA and AAA rechargeable batteries. This compact and portable charger allows you to power up to four batteries simultaneously, providing a convenient and economical solution for your electronic devices. It features a foldable wall plug for easy storage and travel, and incorporates smart charging technology to prevent overcharging.






Image: Duracell Fastest Value Charger (CEF14DX) with four Duracell 1300mAh AA rechargeable batteries. The charger is designed to charge both AA and AAA NiMH batteries and typically completes a charge in 4-8 hours.

## 2. SAFETY INFORMATION

Please read and understand all safety instructions before using the charger. Failure to follow these instructions may result in electric shock, fire, or personal injury.

- Only charge Duracell NiMH rechargeable batteries. Do not attempt to charge non-rechargeable batteries, as this may cause them to rupture, leading to personal injury or damage.
- For indoor use only. Ensure the charger is used in a dry location.
- Risk of electric shock. Never disassemble or alter any part of the charger or batteries.
- The charger and batteries may become warm during the charging process. This is normal and they will cool down once charging is complete.
- Not recommended for use by children without adult supervision.
- Always unplug the charger from the power outlet when not in use or before cleaning.

## 3. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Duracell Fastest Value Charger (CEF14DX)

- 4 x Duracell AA NiMH Rechargeable Batteries

## 4. SETUP AND OPERATION

---

Follow these steps to set up and operate your Duracell Fastest Value Charger:

1. **Insert Batteries:** Place 2 or 4 AA or AAA NiMH rechargeable batteries into the charging slots. Ensure correct polarity (+ and -) as indicated on the charger and batteries. The charger can charge a mix of AA and AAA batteries simultaneously.
2. **Connect to Power:** Fold out the integrated wall plug from the back of the charger. Plug the charger directly into a standard AC wall outlet (100-240V AC, 50/60Hz).
3. **Charging Indication:** A red LED indicator light will illuminate to show that the batteries are charging.
4. **Charging Completion:** The charger is designed to automatically switch to a trickle charge once batteries reach a full charge to prevent overcharging. The LED indicator will change to green or turn off (depending on the specific model variant) when charging is complete.
5. **Remove Batteries:** Once charging is complete, unplug the charger from the wall outlet and remove the charged batteries.

## 5. CHARGING INSTRUCTIONS

---

The Duracell Fastest Value Charger is Energy Star certified and provides efficient charging for your NiMH batteries.

- **Charge Time:** A full charge for the included 1300mAh AA batteries typically takes approximately 6 hours. Charging times may vary for batteries of different capacities (e.g., up to 2500mAh AA NiMH batteries) or if batteries are not fully depleted.
- **Overcharge Protection:** The charger features an automatic shut-off mechanism that transitions to a trickle charge once batteries are fully charged, protecting them from damage due to overcharging and extending their lifespan.
- **Compatibility:** This charger is compatible with Duracell Rechargeable and StayCharged Rechargeable batteries, as well as other brands' AA or AAA NiMH rechargeable batteries.

## 6. MAINTENANCE AND CARE

---

To ensure optimal performance and longevity of your charger and batteries:

- Keep the charger and batteries clean and dry. Wipe with a soft, dry cloth if necessary.
- Avoid exposing the charger to extreme temperatures, direct sunlight, or moisture.
- Store the charger in a cool, dry place when not in use.
- Do not store batteries in the charger for extended periods after they are fully charged.

## 7. TROUBLESHOOTING

---

If you encounter issues with your Duracell Fastest Value Charger, consider the following:

- **Batteries not charging:** Ensure batteries are inserted with correct polarity. Verify the charger is securely plugged into a working wall outlet. Check if the batteries are NiMH rechargeable type; non-rechargeable batteries will not charge.
- **LED indicator not lighting up:** Confirm the charger is properly plugged in and the outlet is functional. Check battery insertion for correct polarity.

- **Charger or batteries are hot:** Some warmth during charging is normal. If the charger or batteries become excessively hot, unplug immediately and allow them to cool. Ensure proper ventilation around the charger.
- **Reduced battery life:** Over time, rechargeable batteries naturally lose capacity. Ensure batteries are fully charged before use. If battery performance significantly degrades, it may be time to replace them.

## 8. SPECIFICATIONS

Feature	Specification
Model Number	DURCEF14 (CEF14DX)
Battery Compatibility	AA and AAA NiMH rechargeable batteries
Charging Capacity	2 or 4 batteries simultaneously
Input Voltage	100-240V AC, 50/60Hz
Output Voltage	1.35 Volts
Typical Charge Time	6 hours (for 1300mAh AA batteries)
Dimensions (L x W x H)	2.2 x 4 x 8.77 inches
Item Weight	2.7 ounces
Color	Black
Manufacturer	Procter & Gamble

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation included with your purchase or visit the official Duracell website. Duracell StayCharged Rechargeable batteries are guaranteed for three years in storage with Duralock Power Preserve Technology.