DYMO LM 210D

DYMO LabelManager 210D Label Maker Instruction Manual

Model: LM 210D

Setup Operation Maintenance Troubleshooting Specifications Warranty & Support

Product Overview

The DYMO LabelManager 210D is a versatile and easy-to-use label maker designed for home and office organization. It features a QWERTY keyboard, a large display, and one-touch smart keys for efficient label creation.



Figure 1: The DYMO LabelManager 210D Label Maker.

Setup

Unboxing and Initial Charge

Upon unboxing, ensure all components are present: the electronic label maker, one starter label cassette (black on white, 1/2" x 10'), and the user guide. The LabelManager 210D features a rechargeable battery. Connect the device to a power source using the appropriate adapter (not always included, check packaging) to ensure it is fully charged before first use. Keeping it plugged in when not in use ensures it's always ready.

Loading a Label Cassette

1. Open the label compartment cover, typically located on the back or side of the device.
2. Insert the DYMO D1 label cassette with the label tape facing the print head. Ensure the tape and ribbon are properly aligned.
3. Close the label compartment cover securely.

Operation

Typing and Editing Text

The LabelManager 210D features a familiar QWERTY keyboard for easy text input. Simply type your desired label

text on the keyboard. The large display allows you to preview your text before printing.



Figure 2: Typing text on the QWERTY keyboard.

Formatting Labels

Utilize the one-touch fast-formatting keys to customize your labels. The device offers:

- Six font sizes
- Seven text styles
- Eight box styles plus underline
- Over 20 ways to format text
- Over 200 symbols and clip art options for personalization

Printing Labels

Once your text is entered and formatted, press the 'Print' button. You can select the number of copies, up to 10 at a time. Press 'Print' again to confirm and start the printing process.



Figure 3: The label maker in use, printing a label.

Cutting Labels

After printing, use the integrated cutter on the side of the device. Press the cutter button down firmly to cleanly cut the label from the tape roll.



Figure 4: Applying a label to a file folder.

Maintenance

Cleaning the Device

To maintain optimal performance, periodically clean the print head and cutter blade. Use a soft, lint-free cloth. For stubborn residue, a cotton swab lightly dampened with rubbing alcohol can be used on the print head. Ensure the device is powered off before cleaning.

Replacing Label Cassettes

When the label tape runs out or you wish to change tape types, open the label compartment cover, remove the empty or desired cassette, and insert a new DYMO D1 label cassette as described in the Setup section.

Troubleshooting

Common Issues and Solutions

- **No Power:** Ensure the rechargeable battery is charged or the device is connected to a power source.
- **Poor Print Quality:** Check if the label cassette is correctly installed. Clean the print head if necessary. Ensure you are using genuine DYMO D1 label tapes.
- **Tape Jam:** Open the label compartment and carefully remove any jammed tape. Ensure the tape is not creased or misaligned when inserting a new cassette.
- **Cutter Not Working:** Check for any obstructions in the cutter mechanism. Clean the cutter blade if needed.

For further assistance, refer to the detailed user guide included with your product or contact customer support.

Specifications

Feature	Detail
Product Dimensions	1.5"D x 3.44"W x 3.12"H
Controller Type	Push Button
Maximum Media Size	12 mm
Print Media	Labels
Scanner Type	Portable
Max Input Sheet Capacity	10
Compatible Devices	PC (for connectivity, not direct printing)
Maximum Color Print Resolution	300 dpi
Maximum Black and White Print Resolution	300 dpi
Warranty Type	Limited warranty
Maximum Copies Per Run	10
Wattage	2 watts
Hardware Interface	USB
Ink Color	Black, Clear
Compatible Cartridge	DYMO D1 label tapes
Series Number	210
Memory Storage Capacity	64 MB
Item Model Number	S0784440
Manufacturer Part Number	V150287
Connectivity Technology	USB
Printing Technology	Dot Matrix

Feature	Detail
Special Feature	Portable
Color	Black/Clear
Model Name	LabelManager
Item Weight	0.71 Grams

Warranty & Support

Warranty Information

The DYMO LabelManager 210D comes with a 1-year limited warranty. Please refer to the warranty card included in your product packaging for full details regarding coverage and terms.

Customer Support

For any functionality issues or further assistance, please contact the DYMO customer helpdesk at **020 3564 8354**.

© 2024 DYMO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question