

[Manuals.plus](#) /

› [ELK Lighting](#) /

› Elk 2424/2 2-Light Flush Light Fixture Instruction Manual

ELK Lighting 2424/2

Elk 2424/2 2-Light Flush Light Fixture Instruction Manual

Model: 2424/2 | Brand: ELK Lighting

PRODUCT OVERVIEW

The Elk 2424/2 2-Light Flush Light Fixture is designed with a Georgian Court collection influence, characterized by well-balanced proportions and attractive details. It features an antique bronze and dark umber finish with marbled amber glass, reflecting a sense of grace and elegance.

Key Features

- Bulb Number: 2
- Bulb Type: 60W Medium
- Item Type: Flush Mount
- Item Collection: Georgian Court

Product Image



Image of the Elk 2424/2 2-Light Flush Light Fixture, showcasing its antique bronze and dark umber finish, and the distinctive marbled amber glass shade.

SETUP INSTRUCTIONS

Important Safety Information: Always disconnect power at the circuit breaker before beginning installation. Consult a qualified electrician if you are unsure about wiring procedures. Wear safety glasses during installation.

Tools Required:

- Screwdriver (Phillips and Flathead)
- Wire Strippers
- Electrical Tape
- Safety Glasses
- Ladder (if installing on ceiling)

Installation Steps:

1. **Unpack Contents:** Carefully remove all components from the packaging. Inspect for any damage. Keep all packaging materials until installation is complete.
2. **Prepare Wiring:** Ensure power is OFF at the circuit breaker. Identify the supply wires (usually black for live, white for neutral, and bare copper or green for ground) from the junction box.
3. **Mount Fixture:** Attach the mounting bracket to the junction box using the provided screws. Ensure it is securely fastened.
4. **Connect Electrical Wires:** Connect the fixture's black wire to the supply's black wire, the fixture's white wire to the supply's white wire, and the fixture's ground wire to the supply's ground wire. Secure connections with wire nuts and electrical tape.
5. **Secure Fixture:** Carefully push the wired fixture up to the mounting bracket and secure it with the decorative nuts or screws provided. Ensure no wires are pinched.
6. **Install Bulbs:** Screw in two 60W medium base incandescent bulbs (not included) into the sockets. Do not overtighten.
7. **Attach Glass Shade:** Carefully place the marbleized amber glass shade onto the fixture according to the design, securing it with any retaining rings or screws.
8. **Restore Power:** Turn the power back ON at the circuit breaker. Test the light fixture.

OPERATING INSTRUCTIONS

Once installed and powered, the Elk 2424/2 light fixture operates via a standard wall switch connected to the circuit. Simply toggle the wall switch to turn the light fixture ON or OFF.

MAINTENANCE

Cleaning:

To clean the fixture, ensure power is off and the fixture is cool. Wipe with a soft, dry cloth. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or glass. For the glass shade, a mild glass cleaner can be used on a soft cloth, then wiped dry.

Bulb Replacement:

Before replacing bulbs, ensure power is off at the circuit breaker and the bulbs are cool. Unscrew the old bulb and screw in a new 60W medium base incandescent bulb. Do not exceed the maximum wattage

specified. Restore power after replacement.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Light does not turn on	No power to fixture; Loose wiring; Faulty bulb; Tripped circuit breaker	Check circuit breaker; Ensure all wire connections are secure; Replace bulb; Check wall switch
Light flickers	Loose bulb; Loose wiring; Incorrect bulb type	Tighten bulb; Check wire connections; Ensure correct bulb wattage and type
Humming noise	Loose components; Incompatible dimmer switch (if applicable)	Ensure all parts are securely fastened; If using a dimmer, ensure it is compatible with incandescent lights

SPECIFICATIONS

Specification	Detail
Brand	ELK Lighting
Model Number	2424/2
Color	Antique Bronze & Dark Umber
Material	Glass
Style	Cottage
Power Source	Corded Electric
Installation Type	Flush Mount
Light Source Type	Incandescent
Number of Light Sources	2
Voltage	120 Volts
Wattage	60 watts (per bulb)
Item Weight	13 pounds
Product Dimensions	18 x 18 x 12 inches
UPC	748119242422, 705696242429
Date First Available	October 19, 2006

WARRANTY INFORMATION

This ELK Lighting product is covered by a **1-year parts and labor warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, please refer to the official ELK Lighting warranty policy or contact customer support.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to report a problem with your Elk 2424/2 light fixture, please contact ELK Lighting customer support. For the most up-to-date contact information, please visit the official ELK Lighting website or refer to the product packaging.

Please have your model number (2424/2) and purchase information ready when contacting support.