

## Seiko SPL011P1


# Seiko SPL011P1 Quartz Analog Men's Watch User Manual

Model: SPL011P1

Thank you for choosing a Seiko watch. For proper use, please read this instruction manual carefully before using your watch.

## PRODUCT OVERVIEW

The Seiko SPL011P1 is a classic quartz analog watch designed for men, featuring a durable leather strap and a clear analog display. It is built to offer reliable timekeeping and is water-resistant up to 100 meters, making it suitable for various daily activities.



*Image: Front view of the Seiko SPL011P1 watch, showcasing its round case, white dial with hour markers, and black leather strap.*

## SETUP

### Setting the Time

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch case) out to the first click position.
2. **Rotate the crown:** Turn the crown clockwise or counter-clockwise to set the hour and minute hands to the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its normal position. The second hand will start moving.

## Setting the Date (if applicable)

If your watch model includes a date display, follow these steps:

1. **Pull out the crown:** Gently pull the crown out to the first click position.
2. **Rotate the crown:** Turn the crown counter-clockwise to set the date. Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.
3. **Push in the crown:** Push the crown back into its normal position after setting the date.

## OPERATING THE WATCH

---

### Basic Timekeeping

Your Seiko SPL011P1 watch operates on a quartz movement, providing accurate timekeeping. Ensure the crown is fully pushed in for the watch to function correctly and maintain its water resistance.

### Water Resistance

This watch is water-resistant up to 100 meters (10 bar). This means it is suitable for swimming, showering, and snorkeling. However, it is **not** suitable for scuba diving. Always ensure the crown is fully pushed in before exposing the watch to water.

- Do not operate the crown or push buttons (if any) while the watch is wet or submerged.
- After exposure to saltwater, rinse the watch with fresh water and wipe it dry with a soft cloth.

## MAINTENANCE

---

### Cleaning Your Watch

To maintain the appearance and longevity of your watch:

- Wipe the case and crystal with a soft, dry cloth regularly.
- For stubborn dirt, use a slightly damp cloth and then dry thoroughly.
- Avoid using chemical cleaners, solvents, or abrasive cloths, as these can damage the watch's finish.

### Leather Strap Care

The leather strap is susceptible to wear and tear. To prolong its life:

- Avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture.
- If the strap gets wet, dry it thoroughly with a soft cloth and allow it to air dry naturally, away from direct heat.
- Clean the strap with a damp cloth and mild soap if necessary, then wipe dry.

## Battery Replacement

Your quartz watch is powered by a battery. When the battery runs low, the second hand may start moving in two-second intervals (End-of-Life indicator). It is recommended to have the battery replaced by an authorized Seiko service center to ensure proper sealing and maintain water resistance.

## Periodic Inspection

It is advisable to have your watch inspected every 2-3 years by an authorized Seiko service center. This inspection includes checking the movement, seals, and overall condition to ensure optimal performance and water resistance.

## TROUBLESHOOTING

---

If you encounter any issues with your watch, please refer to the following common problems and solutions:

- **Watch has stopped:**
  - Check if the crown is fully pushed in.
  - The battery may be depleted. Refer to the 'Battery Replacement' section.
- **Incorrect time:**
  - Refer to the 'Setting the Time' section to reset the time.
  - Ensure the crown is fully pushed in after setting.
- **Condensation inside the crystal:**
  - This may indicate a loss of water resistance. Avoid further exposure to water and contact an authorized service center immediately.

If the problem persists after attempting these solutions, please contact an authorized Seiko service center for assistance.

## SPECIFICATIONS

---

Feature	Detail
Model Number	SPL011P1
Movement Type	Quartz
Display Format	Analog
Water Resistance	100 Meters (10 bar)
Case Diameter	45 mm
Case Thickness	10 mm
Strap Material	Leather
Strap Color	Black
Dial Color	White

Power Source	Battery
Special Features	Water Resistant

## WARRANTY AND SUPPORT

---

### Warranty Information

Your Seiko watch is covered by a limited warranty against manufacturing defects. The specific terms and duration of the warranty may vary by region. Please refer to the warranty card included with your purchase or visit the official Seiko website for detailed information.

### Customer Support

For technical assistance, service, or warranty claims, please contact an authorized Seiko service center or your local Seiko dealer. You can find contact information and locations on the official Seiko website: [www.seikowatches.com/global-en/contact](http://www.seikowatches.com/global-en/contact)

When contacting support, please have your watch model number (SPL011P1) and purchase details readily available.