

[Manuals.plus](#) /

› [Hozelock](#) /

› Hozelock Multi Spray Gun HZ2676P0000 Instruction Manual

Hozelock HZ2676P0000

Hozelock Multi Spray Gun HZ2676P0000 Instruction Manual

Model: HZ2676P0000

1. PRODUCT OVERVIEW

The Hozelock Multi Spray Gun HZ2676P0000 is designed for various garden watering tasks. It features multiple spray patterns and a quick-connect male connector for easy attachment to your Hozelock system. The gun includes a lockable rear soft-touch trigger with flow control, allowing water flow adjustment from 0% to 100% and locking at 40% and 100% to conserve water.



Image 1: The Hozelock Multi Spray Gun HZ2676P0000, showing its yellow and grey body with red accents. This is the main product image.

2. KEY FEATURES

- **Five Spray Patterns:** Offers versatility for all garden tasks, from gentle watering to powerful cleaning.
- **Durable Construction:** Made from high-quality plastic materials for increased longevity.
- **Quick Connect System:** Features a male connector for simple and fast attachment to Hozelock hose systems.
- **Adjustable Flow Control:** Allows precise adjustment of water flow and includes lockable settings for continuous use, helping to reduce water waste.

3. SETUP INSTRUCTIONS

1. **Connect to Hose:** Ensure your garden hose is equipped with a Hozelock female quick-connect fitting. Push the male connector of the spray gun firmly into the female fitting until it clicks into place.
2. **Check Connections:** Verify that all connections are secure to prevent leaks.
3. **Turn on Water Supply:** Slowly open your outdoor tap to allow water to flow into the hose.



Image 2: A person demonstrating the use of the Hozelock Multi Spray Gun to water plants in a garden, highlighting its ergonomic design and ease of use.

4. OPERATING INSTRUCTIONS

4.1 Adjusting Spray Patterns

The spray gun features a rotating head to select from five distinct spray patterns. To change the pattern, simply rotate the grey nozzle head clockwise or counter-clockwise until the desired pattern icon aligns with the indicator mark.

- **Jet:** A powerful, concentrated stream for cleaning.
- **Cone:** A wide, gentle cone-shaped spray for general watering.
- **Fast Fill:** A high-volume flow for quickly filling buckets or watering cans.
- **Mist:** A fine, delicate mist ideal for seedlings and delicate plants.
- **Fan:** A broad, flat spray for covering larger areas or rinsing.

4.2 Using the Trigger and Flow Control

1. **Activate Flow:** Squeeze the rear soft-touch trigger to start the water flow.
2. **Adjust Flow Rate:** Use the red flow control knob located above the trigger to increase or decrease the water volume.
3. **Lock Trigger:** For continuous watering without holding the trigger, push the red lock mechanism forward while the trigger is squeezed. To release, simply squeeze the trigger again.

5. MAINTENANCE

- **Cleaning:** Periodically clean the nozzle head to remove any mineral deposits or debris that may affect spray patterns. Use a soft brush and mild soap if necessary.
- **Storage:** During colder months or when not in use for extended periods, disconnect the spray gun from the hose and store it indoors in a dry, frost-free location to prevent damage.
- **Check for Leaks:** Regularly inspect the connections and body for any signs of wear or leaks. Replace worn washers if needed.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No water flow or weak spray.	Water supply off or low pressure. Hose kinked or blocked. Nozzle clogged.	Ensure tap is fully open and check water pressure. Straighten hose or remove obstruction. Clean nozzle head.
Leaks from connections.	Loose connection. Worn washer.	Tighten connection. Replace washer in the quick-connect fitting.
Spray pattern is inconsistent.	Debris in nozzle. Nozzle head not fully rotated to a specific pattern.	Clean nozzle head. Rotate nozzle head fully until it clicks into the desired pattern.

7. SPECIFICATIONS

Attribute	Detail
Model Number	HZ2676P0000
Brand	Hozelock
Material	Plastic
Item Dimensions (L x W x H)	3.38 x 2.63 x 0.99 inches
Item Weight	120 Grams
Maximum Operating Pressure	100 Pound per Square Inch
Number of Spray Patterns	5
Connector Type	Barb
UPC	013523087434

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Hozelock website or contact their customer service directly. Keep your proof of purchase for any warranty claims.
Official Hozelock Website: www.hozelock.com

© 2023 Hozelock Ltd. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question