Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Acura TL

2000 Acura TL Owner's Manual

Your Guide to Vehicle Operation and Maintenance

Introduction

This owner's manual is an essential resource for understanding the operation, features, and maintenance requirements of your 2000 Acura TL. It contains important information regarding safety, driving procedures, vehicle care, and troubleshooting to ensure a safe and enjoyable driving experience. Please read this manual thoroughly and keep it in your vehicle for future reference.




Image: The front cover of the 2000 Acura TL Owner's Manual, displaying the vehicle model and year.



Image: A black leather case, embossed with the Acura logo, designed to hold the owner's manual and related documents.

Setup and Initial Familiarization

Upon acquiring your 2000 Acura TL, it is recommended to familiarize yourself with the vehicle's primary controls and settings. This section guides you through initial adjustments and understanding key components.

Key Components Included:

- **Acura TL 2000 Owner's Manual:** Detailed instructions for all vehicle functions.
- **Acura 2000 Warranties Booklet:** Information regarding vehicle warranties.
- **Supplemental Restraint System (SRS) Manual:** Specific details on airbag systems and safety.
- **Tire Owner's Manuals:** Guides for tire maintenance and warranty from manufacturers like Michelin and Bridgestone/Firestone.



Image: The 2000 Acura TL Owner's Manual and the Acura 2000 Warranties booklet, shown together.



Image: The cover of the Supplemental Restraint System (SRS) manual, providing information on airbags.

Operating Your Vehicle

This section covers the fundamental aspects of operating your 2000 Acura TL. It includes information on starting the engine, using the transmission, understanding dashboard indicators, and operating various comfort and convenience features.

Driving Controls:

- **Ignition System:** Procedures for starting and stopping the engine.
- **Transmission:** Operation of the automatic transmission, including parking, reverse, neutral, and drive gears.
- **Steering and Braking:** Guidelines for safe steering and effective use of the braking system, including ABS.

Dashboard and Indicators:

Learn about the instrument panel, warning lights, and gauges that provide critical information about your vehicle's status. Pay close attention to warning lights such as the check engine light, oil pressure warning, and battery charge indicator.

Maintenance

Regular maintenance is crucial for the longevity and optimal performance of your 2000 Acura TL. This section outlines recommended service schedules, fluid checks, and general care procedures.

Routine Checks:

- **Engine Oil:** Checking levels and recommended change intervals.
- **Coolant:** Monitoring coolant levels to prevent overheating.
- **Brake Fluid:** Ensuring proper brake system function.
- **Tire Pressure:** Critical for safety, fuel efficiency, and tire lifespan. Refer to the tire owner's manuals for specific guidelines.



Image: The English version of the Michelin Passenger & Light Truck Tire Owner's Manual, detailing tire care and warranty.



Image: The French version of the Michelin Tire Owner's Guide, providing information on tire maintenance and warranty.



Image: The Bridgestone Firestone Passenger and Light Truck Tire Limited Warranty with Tire Maintenance and Safety Manual.

Service Schedule:

Adhere to the recommended service intervals outlined in your manual for oil changes, tire rotations, filter replacements, and other periodic maintenance tasks. This helps maintain vehicle reliability and performance.

Troubleshooting

This section provides guidance on identifying and resolving common issues you might encounter with your 2000 Acura TL. For more complex problems, it is always recommended to consult a certified Acura technician.

Common Issues and Solutions:

- **Engine Not Starting:** Check battery, fuel level, and ignition system.
- **Warning Lights:** Understand the meaning of various dashboard warning lights and appropriate actions.
- **Brake Noise:** Investigate potential issues with brake pads or rotors.
- **Tire Issues:** Address low tire pressure, punctures, or uneven wear.

Specifications

Key technical specifications for the 2000 Acura TL are provided here for your reference. These details are important for maintenance, part replacement, and understanding your vehicle's capabilities.

Specification	Detail
Model Year	2000
Vehicle Type	Acura TL Sedan
Dimensions (approx.)	13.34 x 20.96 x 1.27 cm (Manual dimensions)
Language of Manual	English
ASIN	B00120XKPO

Note: Vehicle dimensions and weight are for the manual itself, not the car. Refer to the actual vehicle manual for specific car specifications.

Warranty and Support

Your 2000 Acura TL comes with various warranties covering different components of the vehicle. It is important to understand the terms and conditions of these warranties.

Warranty Information:

- **Acura Vehicle Warranty:** Details on coverage for major vehicle components. Refer to the 'Acura 2000 Warranties' booklet.
- **Tire Warranties:** Separate warranties are provided by tire manufacturers such as Michelin and Bridgestone/Firestone. Consult their respective manuals for coverage details and maintenance requirements to keep your warranty valid.

Customer Support:

For any questions or assistance not covered in this manual, please contact your authorized Acura dealership. They can provide expert service and support for your vehicle.

© 2000 Acura. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00120XKPO

More documents and user manuals: **https://manuals.plus/**