

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Schleich](#) /

› [Schleich Show Jumping Gift Set \(Model 42026\) Instruction Manual](#)

## Schleich 42026

# Schleich Show Jumping Gift Set (Model 42026) Instruction Manual

### 1. INTRODUCTION

This manual provides instructions for the assembly, use, and care of your Schleich Show Jumping Gift Set, Model 42026. This set includes a horse, a rider, tack, and a 2-bar jump with a gate, designed for imaginative play.



Image 1.1: The Schleich Show Jumping Gift Set, featuring the horse, rider, and the assembled jump obstacle.

## 2. PACKAGE CONTENTS

Please verify that all the following components are present in your package:

- 1 x Horse figure
- 1 x Rider figure
- 1 x Halter
- 1 x Bridle
- 1 x Saddle
- 2 x Shin guards
- 1 x 2-bar jump with gate (multiple pieces for assembly)

## 3. ASSEMBLY INSTRUCTIONS

Follow these steps to assemble your Show Jumping Gift Set:

1. **Assemble the Jump:** Carefully connect the pieces of the 2-bar jump to form the obstacle. Ensure all connections are secure. The gate should be able to swing freely or be positioned as desired.
2. **Attach the Halter and Bridle:** Gently place the halter onto the horse's head. Then, fit the bridle over the horse's head, ensuring the bit is positioned correctly.
3. **Place the Saddle:** Position the saddle onto the horse's back.
4. **Attach Shin Guards:** Secure the shin guards onto the horse's legs.
5. **Position the Rider:** Place the rider figure onto the saddle. The rider's hands can be positioned to hold the reins of the bridle.

Ensure all accessories are securely attached to prevent them from falling off during play.

#### 4. OPERATING INSTRUCTIONS

The Schleich Show Jumping Gift Set is designed for imaginative play. Here are some suggestions for use:

- **Setting up the Course:** Arrange the jump obstacle in various configurations to create different show jumping challenges.
- **Rider and Horse Interaction:** Practice guiding the horse and rider over the jumps. The rider can be removed and re-positioned as needed.
- **Creative Play:** Integrate the set with other Schleich figures and playsets to expand play scenarios.

#### 5. CARE AND MAINTENANCE

To ensure the longevity of your Schleich Show Jumping Gift Set, please follow these care guidelines:

- **Cleaning:** Wipe figures and accessories with a damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the paint and material.
- **Storage:** Store the set in a cool, dry place away from direct sunlight to prevent fading or material degradation.
- **Handling:** Handle figures and accessories gently to avoid breakage, especially small parts like reins or jump bars.

#### 6. TROUBLESHOOTING

If you encounter any issues with your Show Jumping Gift Set, consider the following:

- **Missing Parts:** Refer to the "Package Contents" section to ensure all items were received. If parts are missing, contact customer support.
- **Difficulty Assembling:** Review the "Assembly Instructions" carefully. Ensure pieces are aligned correctly before applying gentle pressure. Do not force parts together.
- **Figures Not Standing:** Ensure the figures are placed on a flat, stable surface. Slight adjustments to leg positions may be necessary for balance.

#### 7. PRODUCT SPECIFICATIONS

Model Number	42026
ASIN	B0012BU038

<b>Product Dimensions</b>	5 x 4 x 8 inches (approximate, assembled)
<b>Item Weight</b>	5.8 ounces
<b>Manufacturer Recommended Age</b>	5 - 15 years
<b>Manufacturer</b>	Schleich North America
<b>Release Date</b>	September 15, 2008

## 8. SUPPORT INFORMATION

For further assistance, missing parts, or warranty inquiries, please contact Schleich North America directly. Specific warranty details are not provided in this manual. Please refer to the manufacturer's official website or product packaging for the most current support and warranty information.

You can often find contact information on the official [Schleich Store on Amazon](#) or their corporate website.