



[Manuals.plus](#) /

› [AT&T](#) /

› AT&T 1070 4-Line Expandable Corded Phone System User Manual

AT&T 1070

AT&T 1070 4-Line Expandable Corded Phone System User Manual

Model: 1070

INTRODUCTION

The AT&T 1070 is a versatile 4-line expandable corded phone system designed for small business environments. It features Caller ID, Call Waiting, and a speakerphone for hands-free communication. This system supports up to four telephone lines and can be expanded to include up to 16 stations when used with compatible AT&T models 1040 and 1080.

Key features include:

- 4-line operation, compatible with 1 to 4 telephone lines.
- 32 Speed Dial and 16 Intercom locations for quick access.
- 3-Party Conferencing capability.
- Integrated Speakerphone for hands-free calls.
- Adjustable volume for handset, speaker, headset, and ringer.
- Caller ID and Call Waiting functionality.
- Compatibility with AT&T 1040 and AT&T 1080 models for system expansion.



Image: The AT&T 1070 4-Line Expandable Corded Phone System, showing the handset, keypad, display, and line buttons.

SETUP

Follow these steps to set up your AT&T 1070 phone system.

1. Power Connection

Connect the power adapter to the phone and then to a standard electrical outlet. Ensure the connection is secure.

2. Telephone Line Connection

Connect your telephone lines to the corresponding LINE 1, LINE 2, LINE 3, and LINE 4 jacks on the back of the phone. Use standard RJ11 telephone cords.

Note: If you are a DSL subscriber, you may need to use a DSL filter for each telephone line to prevent interference. This product does not work on a digital line.

3. Handset and Headset Connection

- Connect the coiled handset cord to the handset and the designated handset jack on the phone base.

- For hands-free operation, you can connect a 2.5-millimeter headset to the headset jack.



Image: Top-down view of the AT&T 1070 phone, highlighting the handset and overall layout.

4. Battery Installation (for memory backup)

The phone requires 4 AA batteries (included) for memory loss protection. Install these batteries into the compartment located on the underside of the phone base, observing correct polarity.

5. System Expansion

The AT&T 1070 system can be expanded to up to 16 stations using compatible AT&T models 1040 and 1080. Refer to the manuals of those specific models for detailed expansion instructions.

OPERATING INSTRUCTIONS

Making and Receiving Calls

- **To make a call:** Lift the handset or press the **SPEAKER** button. Select an available line (LINE 1-4) if not automatically selected. Dial the desired number.
- **To receive a call:** Lift the handset or press the **SPEAKER** button when the phone rings. The corresponding line indicator will flash.
- **Automatic Line Selection:** When the phone rings, picking up the handset or pressing **SPEAKER** will automatically connect you to the ringing line.



Image: Close-up view of the AT&T 1070 keypad and function buttons, including DO NOT DISTURB, REDIAL, FLASH, and TRANSFER.

Speakerphone Usage

Press the **SPEAKER** button to activate the speakerphone function. Press it again to end the call or lift the handset to switch to handset mode.

Caller ID and Call Waiting

- The large display shows incoming caller information (name and number) if you subscribe to Caller ID service.
- With Call Waiting service, you will see who is calling even if you are already on another line.
- The phone stores a 200-name-and-number Caller ID history. Numbers can be dialed directly from this history.



Image: Close-up of the AT&T 1070 display showing "Call Waiting" and caller information, along with line indicators.

3-Party Conferencing

To initiate a 3-party conference call, establish a call on one line, then use the **CONFERENCE** button to add another party from a different line. Refer to the full user manual for detailed steps.

Intercom and Paging

If your system is expanded with compatible AT&T 1040 or 1080 models, you can use the intercom feature to communicate between stations and page other users. The phone has 16 intercom number locations.

Speed Dial

The phone supports 32 speed dial locations for frequently called numbers. Consult the detailed manual for programming instructions.

Volume Control

Use the **VOLUME** up/down buttons to adjust the listening volume for the handset, speakerphone, or connected headset. Ringer volume can also be adjusted.



Image: Close-up of the right-side control panel of the AT&T 1070, showing the VOLUME, HEADSET, MUTE, and SPEAKER buttons.

Voicemail Indicator

If you subscribe to a voicemail service, a red light will blink on the phone when you have new voicemail messages.

MAINTENANCE

- **Cleaning:** Wipe the phone's exterior with a soft, slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Battery Replacement:** Replace the 4 AA batteries annually or as needed to ensure memory backup functionality.
- **Cord Management:** Ensure all cords are free from kinks or excessive tension to prevent damage.

TROUBLESHOOTING

Problem	Solution
No dial tone.	<p>Check all telephone line connections.</p> <p>Ensure the power adapter is securely connected.</p> <p>Verify that the telephone line is active.</p>
Caller ID not displaying.	<p>Confirm you subscribe to Caller ID service from your telephone provider.</p> <p>Ensure the phone is connected to an analog line, not a digital line.</p>
Interference or static on the line.	<p>If you have DSL, install DSL filters on all telephone lines.</p> <p>Move the phone away from other electronic devices that may cause interference.</p> <p>Check telephone cords for damage.</p>
Memory settings lost after power outage.	<p>Check if the 4 AA backup batteries are installed correctly and are not depleted.</p> <p>Replace if necessary.</p>

SPECIFICATIONS

Feature	Detail
Brand	AT&T
Model Number	1070
Telephone Type	Corded
Number of Lines	4
Color	Black/Silver
Power Source	Corded Electric
Batteries Required	4 AA batteries (included, for memory backup)
Item Dimensions (L x W x H)	8 x 5 x 10 inches
Item Weight	3 Pounds
Caller ID	Yes
Conference Call Capability	3-way
Speed Dial Locations	32
Intercom Locations	16
Compatible Devices	AT&T Models 1040, 1070, and 1080

WARRANTY INFORMATION

The AT&T 1070 4-Line Expandable Corded Phone System comes with a **1-Year Limited Warranty**. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty card included with your product or visit the official AT&T support website.

SUPPORT

For further assistance, technical support, or to inquire about replacement parts, please visit the official AT&T support website or contact their customer service department. Contact information can typically be found on the AT&T website or in the packaging materials.

Online Support: www.att.com/support