

[Manuals.plus](#) /

> [Timex](#) /

> Timex T2M518 Automatic Analog Watch User Manual

Timex T2M518

Timex T2M518 Automatic Analog Watch User Manual

Model: T2M518

INTRODUCTION

Thank you for choosing the Timex T2M518 Automatic Analog Watch. This manual provides essential information for the proper setup, operation, and maintenance of your timepiece. Please read these instructions carefully to ensure optimal performance and longevity of your watch.

PRODUCT OVERVIEW

The Timex T2M518 is a men's automatic analog watch featuring a robust stainless steel silver bracelet and a classic black dial. It is designed for durability and precision, offering a blend of traditional watchmaking with modern reliability.




Image: Front view of the Timex T2M518 Automatic Analog Watch, showcasing its black dial, silver-tone hands, and stainless steel bracelet.

Key Features:

- **Automatic Movement:** Self-winding mechanism powered by the motion of your wrist.
- **Analog Display:** Traditional hour, minute, and second hands.
- **Perpetual Calendar:** Automatically adjusts for different month lengths and leap years.
- **Water Resistance:** Rated for 100 meters (10 ATM), suitable for swimming and showering.
- **Durable Construction:** Mineral dial window and stainless steel case and bracelet.
- **Deployment Clasp:** Secure and easy-to-use single deployment clasp.

SETUP

Initial Winding:

As an automatic watch, the T2M518 is powered by the movement of your wrist. If the watch has stopped, it may require an initial manual wind to start. To manually wind, unscrew the crown (if applicable) and gently rotate it clockwise approximately 20-30 times. This will build up a power reserve to start the watch. The watch will then continue to wind itself with normal wear.

Setting the Time:

1. Unscrew the crown (if applicable) and pull it out to the outermost position.
2. Rotate the crown to move the hands clockwise until the desired time is set. Ensure to pass 12 o'clock to correctly set AM/PM for the date change.
3. Push the crown back into its normal position and screw it down securely (if applicable) to maintain water resistance.

Setting the Date:

1. Unscrew the crown (if applicable) and pull it out to the middle position.
2. Rotate the crown either clockwise or counter-clockwise (depending on the movement) to adjust the date.
3. Once the correct date is displayed, push the crown back into its normal position and screw it down securely (if applicable).
4. *Note: Avoid setting the date between 9 PM and 3 AM, as this can damage the movement. If the time falls within this period, first adjust the time outside this range, set the date, then reset the time.*

Adjusting the Bracelet:

The stainless steel bracelet can be adjusted by removing links. This procedure typically requires specialized tools and should ideally be performed by a qualified jeweler or watch technician to prevent damage to the bracelet or watch. Ensure the clasp closes securely after adjustment.

OPERATING

Daily Wear and Power Reserve:

Wear your Timex T2M518 regularly to keep it wound. Normal daily activity should provide sufficient movement to maintain the power reserve. If the watch is not worn for an extended period (typically 40 hours for this model), it will stop. Simply re-wind it manually or wear it to restart the movement.

Water Resistance:

Your watch is water-resistant to 100 meters (10 ATM). This rating means it is suitable for recreational swimming, showering, and snorkeling. **It is not suitable for scuba diving or high-impact water sports.** Always ensure the crown is fully pushed in and screwed down (if applicable) before any contact with water. Do not operate the crown while the watch is wet or submerged.

MAINTENANCE

Cleaning:

To clean your watch, wipe the case and bracelet with a soft, damp cloth. For stainless steel, a mild soap solution can be used, followed by rinsing with clean water and thorough drying. Avoid using harsh chemicals or abrasive materials, as these can damage the finish.

Storage:

When not wearing your watch, store it in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, consider a watch winder to keep the automatic movement running and lubricated.

Service:

Automatic watches benefit from periodic servicing, typically every 3-5 years, to ensure the movement

remains accurate and lubricated. Contact an authorized Timex service center or a reputable watchmaker for professional servicing.

TROUBLESHOOTING

- **Watch has stopped:** If the watch has not been worn for a while, manually wind it by rotating the crown 20-30 times clockwise. Ensure the crown is fully pushed in.
- **Date not changing:** Check if the time is set correctly for AM/PM. Avoid setting the date between 9 PM and 3 AM. If the issue persists, consult a watch technician.
- **Inaccurate timekeeping:** Automatic watches can vary slightly in accuracy. If the deviation is significant, ensure the watch is being worn consistently or manually wound. Extreme shocks or magnetic fields can affect accuracy. If problems persist, professional servicing may be required.
- **Condensation under crystal:** This indicates a loss of water resistance. Immediately seek professional service to prevent further damage to the movement.

SPECIFICATIONS



Image: A visual guide illustrating different watch case diameters, ranging from 14-16mm up to 50-54mm, providing a reference for watch sizing.

Timex T2M518 Product Specifications

Model Number	T2M518
Movement Type	Automatic
Display Type	Analog
Case Diameter	45 Millimeters
Case Thickness	15 Millimeters
Band Width	20 Millimeters
Case Shape	Round
Dial Window Material Type	Mineral
Dial Color	Black
Band Material	Stainless Steel
Band Color	Silver
Clasp Type	Single Deployment Clasp
Water Resistance Depth	100 Meters (10 ATM)
Special Features	Perpetual Calendar, Water Resistance
Product Dimensions (L x W x H)	10.01 x 10.01 x 5 cm
Item Weight	244.94 Grams

WARRANTY AND SUPPORT

Timex watches are manufactured to high standards and are covered by a limited warranty against manufacturing defects. Please refer to the warranty card included with your purchase for specific terms and conditions, including the warranty period and coverage details.

For technical support, service inquiries, or to locate an authorized service center, please visit the official Timex website or contact their customer service department. Keep your proof of purchase for warranty claims.

Online Resources: www.timex.com