

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Star Wars Clone Trooper Voice Changer Helmet Instruction Manual Model 87627

## Hasbro 87627

# Hasbro Star Wars Clone Trooper Voice Changer Helmet Instruction Manual

Model: 87627

## INTRODUCTION

Congratulations on your purchase of the Hasbro Star Wars Clone Trooper Voice Changer Helmet! This helmet allows you to immerse yourself in the Star Wars universe by transforming your voice to sound like a Clone Trooper and playing authentic movie sound effects. This manual provides essential information for the proper assembly, operation, and maintenance of your helmet to ensure a safe and enjoyable experience.



Image: The assembled Star Wars Clone Trooper Voice Changer Helmet.

## SAFETY INFORMATION

- **Adult Supervision:** This product is recommended for ages 4 and up. Adult supervision is advised during assembly and initial use.
- **Battery Safety:** Use only the specified battery type (3 AA batteries). Do not mix old and new batteries, or different types of batteries. Insert batteries with correct polarity (+/-). Remove batteries if the product is not used for an extended period. Dispose of used batteries responsibly.
- **Choking Hazard:** The helmet contains small parts before assembly. Keep out of reach of small children.
- **Hearing Protection:** Avoid prolonged exposure to loud sounds. Do not place the speaker directly against the ear.
- **Visibility:** The helmet may restrict peripheral vision. Use in open, safe areas and be aware of your

surroundings.

## PACKAGE CONTENTS

---

Please check the package to ensure all components are present:

- Helmet Front Piece
- Helmet Back Piece (may consist of multiple sections)
- Internal Adjustable Head Straps
- Instruction Manual
- 3 AA Batteries (included)

## ASSEMBLY

---

The helmet comes in several pieces that require careful assembly. Follow these steps to ensure the helmet is securely put together:

1. **Unpack Components:** Carefully remove all helmet pieces from the packaging.
2. **Assemble Back Piece:** If the back piece consists of multiple sections, align the notches and slide them together. It is often easier to slide the outside notches in first, then apply pressure to the middle to snap it securely into place. Ensure all connections are firm.
3. **Connect Front and Back:** Align the front helmet piece with the assembled back piece. Carefully snap the two main sections together, ensuring all clips and tabs engage properly. You should hear a click as each section locks into place. Apply even pressure to avoid damaging the plastic.
4. **Install Head Straps:** The helmet includes adjustable internal head straps. Attach these straps according to the diagrams in the manual (if available) or by securing them to the designated attachment points inside the helmet. These straps allow for a comfortable and secure fit for various head sizes.
5. **Verify Assembly:** Once assembled, gently test the helmet's integrity by applying light pressure to the seams. The helmet should feel sturdy and not easily come apart.

*Note: Patience is key during assembly. If pieces do not fit easily, re-check alignment rather than forcing them.*

## BATTERY INSTALLATION

---

The helmet requires 3 AA batteries, which are included with your purchase. Follow these steps to install them:

1. **Locate Battery Compartment:** The battery compartment is typically located on the inside of the helmet, often near the voice changer module.
2. **Open Compartment:** Using a small Phillips head screwdriver (not included), unscrew the battery compartment cover.
3. **Insert Batteries:** Insert 3 new AA batteries, ensuring the positive (+) and negative (-) terminals match the markings inside the compartment.
4. **Close Compartment:** Replace the battery compartment cover and secure it with the screw. Do not overtighten.

## OPERATION

---

### Voice Changer Function

The helmet features a voice amplification system designed to make your voice sound like a Clone Trooper. This

function primarily amplifies your voice rather than digitally altering its pitch or tone significantly.

- **Activate:** Locate the power switch, usually on the side or inside the helmet, and slide it to the 'ON' position.
- **Speak into Microphone:** Position your mouth close to the internal microphone, which is typically located near the mouth area inside the helmet. Speak clearly and directly into the microphone.
- **Adjust Volume:** If available, use the volume control (a dial or button) to adjust the output level of your amplified voice.

*Tip: For best results, ensure your mouth is as close as possible to the microphone. The voice amplification effect is most noticeable when speaking directly into it.*

Sound Effects and Voice Clips

The helmet is pre-programmed with five different voice clips and sound effects from the Star Wars movies.

- **Locate Buttons:** Identify the buttons on the side of the helmet. These buttons are typically labeled or intuitively placed for easy access.
- **Activate Sounds:** Press the buttons to trigger various Clone Trooper phrases and sound effects. Each button may activate a different sound or cycle through multiple sounds.

MAINTENANCE

- **Cleaning:** Wipe the helmet with a soft, slightly damp cloth. Do not use abrasive cleaners or solvents, as these can damage the finish.
- **Storage:** Store the helmet in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Removal:** If the helmet will not be used for an extended period, remove the batteries to prevent leakage and corrosion.
- **Inspection:** Periodically inspect the helmet for any signs of damage or wear. Ensure all connections remain secure.

TROUBLESHOOTING

| Problem                                     | Possible Cause                                                    | Solution                                                                                                                       |
|---------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------|
| Helmet pieces come apart easily.            | Improper assembly; clips not fully engaged.                       | Disassemble and re-assemble carefully, ensuring all notches and clips snap securely into place. Refer to the Assembly section. |
| Voice changer or sound effects not working. | Batteries are dead or incorrectly installed; power switch is off. | Check battery polarity and replace if necessary. Ensure the power switch is in the 'ON' position.                              |
| Voice amplification is too low or unclear.  | Microphone too far from mouth; low batteries.                     | Speak closer to the microphone. Replace batteries if they are weak.                                                            |

SPECIFICATIONS

- **Model Number:** 87627
- **Product Dimensions:** Approximately 10 x 10.75 x 12 inches
- **Item Weight:** Approximately 2 pounds

- **Manufacturer Recommended Age:** 4 - 8 years
- **Batteries:** 3 AA batteries (included)
- **Manufacturer:** Hasbro
- **Release Date:** July 26, 2008

## WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Hasbro website. Keep your purchase receipt as proof of purchase.

**Hasbro Official Website:** [www.hasbro.com](http://www.hasbro.com)