#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Litex /
- Litex UT56WW3M Utility Ceiling Fan User Manual

#### Litex UT56WW3M

# Litex UT56WW3M Utility Ceiling Fan User Manual

Model: UT56WW3M | Brand: Litex

# 1. Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Litex UT56WW3M Utility Ceiling Fan. Please read this manual thoroughly before attempting to assemble, install, operate, or troubleshoot this product. Keep these instructions for future reference.



Figure 1: Litex UT56WW3M Utility Ceiling Fan. This image shows the complete fan assembly, including the motor housing, three matte white blades, and the downrod for ceiling mounting.

# 2. SAFETY INFORMATION

Always follow basic safety precautions when installing and operating this appliance to reduce the risk of fire, electric shock, and personal injury.

- **Electrical Safety:** Ensure the power supply is disconnected at the circuit breaker before installation or servicing. This fan operates on 120 volts.
- Local Laws: Always check and comply with your local electrical codes and regulations before installing this

product.

- **Mounting:** The fan must be mounted to a ceiling joist or a suitable support structure capable of supporting the fan's weight (approximately 1 pound / 16 ounces).
- Clearance: Ensure there is adequate clearance between the fan blades and any obstructions. The fan's installed dimensions from ceiling to bottom are 19 inches.
- Professional Installation: If you are unsure about wiring or installation, consult a qualified electrician.
- Usage: This fan is designed for indoor use only.

# 3. SETUP AND INSTALLATION

Carefully unpack all components and ensure all parts are present before beginning installation. Refer to the included parts list for verification.

#### 3.1. Pre-Installation Checks

- Verify that the electrical box is securely fastened to the building structure and can support the fan's weight.
- Ensure the power is turned off at the main circuit breaker.

# 3.2. Mounting the Fan

- 1. Attach the mounting bracket to the ceiling electrical box. Use screws and washers provided, ensuring a secure fit.
- 2. Assemble the downrod (1/2-inch diameter, 12-inch length) to the fan motor housing.
- 3. Carefully lift the fan assembly and hang it from the mounting bracket.
- 4. Connect the electrical wires according to local codes and the wiring diagram provided in the separate wiring instructions (not included in this general manual).
- 5. Secure the fan canopy to the mounting bracket.

# 3.3. Attaching the Blades

- · Attach the three matte white blades to the blade arms.
- Secure the blade arms to the motor housing. Ensure all screws are tightened to prevent wobbling during operation. The blade arm pitch is 9 degrees.

# 4. OPERATING INSTRUCTIONS

The Litex UT56WW3M Utility Ceiling Fan is designed for efficient air circulation and features a 5-speed wall control for convenient operation.

# 4.1. Wall Control Operation

- Ensure the fan is properly installed and wired to the wall control.
- Turn on the power at the circuit breaker.
- Use the wall control to select one of the five available fan speeds.
- To turn the fan off, select the lowest speed setting or the 'off' position on the wall control.

Note: This model is not light kit adaptable and is designed for hangdown only installation.

# 5. MAINTENANCE

Regular maintenance will help prolong the life and efficiency of your ceiling fan.

- **Cleaning:** Periodically wipe the fan blades and motor housing with a soft, damp cloth. Do not use abrasive cleaners or solvents, as they may damage the finish.
- **Tighten Fasteners:** Check all screws and fasteners annually to ensure they are secure. Loose connections can cause noise or wobbling.
- Lubrication: This fan features permanently lubricated bearings and does not require additional oiling.

# 6. TROUBLESHOOTING

If your ceiling fan is not operating correctly, refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; loose wire connections; faulty wall control.	Check circuit breaker; ensure all wire connections are secure; test wall control.
Fan wobbles	Loose blade screws; unbalanced blades; loose mounting bracket.	Tighten all blade and mounting screws; ensure blades are balanced (balancing kit not included).
Noisy operation	Loose screws; motor hum; fan rubbing against ceiling.	Check and tighten all screws; ensure proper clearance from ceiling.

If the problem persists after attempting these solutions, contact customer support.

# 7. SPECIFICATIONS

Feature	Detail
Brand	Litex
Model Name	UT56WW3M (Part Number: 824021)
Color	White
Electric Fan Design	Ceiling Fan
Power Source	Corded Electric
Style	Modern
Product Dimensions (D x W x H)	56"D x 56"W x 120"H (Note: 120"H likely refers to maximum hang, actual fan height is 19" from ceiling)
Special Feature	Wall Control
Recommended Uses	Air Circulation

Feature	Detail
Wattage	73 Watts
Finish Type	White
Number of Blades	3
Voltage	120 Volts
Item Weight	1 pound (16 ounces)
Included Components	Fan Blade included
Indoor/Outdoor Usage	Indoor
Control Method	Remote (Note: Specifications list "Remote" but feature bullets and special feature list "Wall_control". Prioritizing "Wall_control" as it's more specific to operation.)
Efficiency	Energy Efficient (Energy Star certified)
Number of Power Levels	5
Downrod Length	12 inches (1/2-inch diameter)
Fan Installed Dimensions (Ceiling to Bottom)	19 inches
Blade Arm Pitch	9 degrees

# 8. WARRANTY AND SUPPORT

This Litex UT56WW3M Utility Ceiling Fan comes with a15-year warranty.

For parts, warranty details, or technical support, please contact Litex customer service at800-527-1292.

Please have your model number (UT56WW3M) and purchase information ready when contacting support.

© 2023 Litex Industries. All rights reserved.

#### Related Documents - UT56WW3M



# Litex TIT52SCH5LR/TIT52WW5LR Ceiling Fan Installation Guide

This guide provides detailed instructions for installing Litex TIT52SCH5LR and TIT52WW5LR ceiling fans. It includes safety precautions, parts inventory, step-by-step assembly, wiring instructions, remote control operation, troubleshooting tips, and warranty information.



# South River Ceiling Fan Installation Manual and Operating Guide

Comprehensive guide for installing and operating the South River Ceiling Fan (Model #C-ST52BNK5D1), including safety instructions, troubleshooting tips, and warranty information from Litex Industries.



#### Harbor Breeze Mazon Ceiling Fan Installation and Operation Manual

Comprehensive guide for installing, operating, and troubleshooting the Harbor Breeze Mazon Ceiling Fan (Model MZ44BNK3LR/MZ44MBLK3LR/MZ44WW3LR). Includes safety information, parts list, and warranty details.



# Burbank LED Ceiling Fan Installation and Operation Manual

This manual provides detailed instructions for the installation, operation, and maintenance of the Burbank LED Ceiling Fan (Model #BUR60MBK5LR). It includes safety information, package contents, hardware details, step-by-step installation guides, wiring diagrams, operating instructions, troubleshooting tips, and warranty information.



# Harbor Access QUONTA LED CEURS AUGUSTO POR ACCESS AUGUSTO POR A

# Harbor Breeze Quonta LED Ceiling Fan Installation and Operation Manual

Comprehensive guide for installing, operating, and maintaining the Harbor Breeze Quonta LED Ceiling Fan (Model #CFH52BNK5L). Includes safety information, package and hardware contents, wiring instructions, troubleshooting tips, and limited lifetime warranty details.

