

[Manuals.plus](#) /

› [Hasbro](#) /

› Hasbro Transformers Movie Exclusive Deluxe Action Figure Allspark Power Big Daddy Instruction Manual

Hasbro B00150UKLI

Hasbro Transformers Movie Exclusive Deluxe Action Figure Allspark Power Big Daddy

INSTRUCTION MANUAL

Model: B00150UKLI | Brand: Hasbro

Product Overview

The Big Daddy action figure is an Autobot Micromaster from the Generation 1 continuity family. This figure is designed to convert between robot and vehicle modes, offering dynamic play and display options. It features twin blasters with firing projectiles and a snap-out capture claw, enhancing its interactive capabilities.



Image: Hasbro Transformers Movie Exclusive Deluxe Action Figure Allspark Power Big Daddy, still sealed in its original packaging, showcasing the figure in vehicle mode and its branding.

Package Contents

- Big Daddy Action Figure
- Twin Blasters with Firing Projectiles
- Snap-out Capture Claw

Setup and Transformation

The Big Daddy figure converts between robot and mini-car modes in 23 seamless steps. Follow the visual guide below for detailed transformation instructions.



Video: Official product overview video demonstrating the transformation of the Big Daddy action figure from robot to vehicle mode and highlighting its features.

Step-by-Step Transformation (General Guide):

1. Carefully articulate the figure's limbs and body panels.
2. Fold and rotate sections as indicated by the figure's design to align with the desired mode.
3. Ensure all parts are securely tabbed or snapped into place for a stable configuration.
4. Attach accessories such as the twin blasters or snap-out capture claw as appropriate for the chosen mode.

Operating Instructions

The Big Daddy action figure comes with several accessories to enhance play.

- **Twin Blasters:** These accessories can be attached to designated ports on the figure in both robot and vehicle modes. The blasters feature firing projectiles; insert the projectile into the barrel and press the trigger mechanism to fire.
- **Snap-out Capture Claw:** This accessory can be deployed from its stored position. Consult the figure's specific design for the activation mechanism, typically a button or lever, to extend the claw.

Maintenance

To ensure the longevity of your Big Daddy action figure:

- Keep the figure clean by wiping it with a soft, dry cloth. Avoid harsh chemicals or abrasive materials.
- Store the figure away from direct sunlight and extreme temperatures to prevent material degradation or discoloration.
- Handle all moving parts and transformation joints with care to avoid breakage.

Troubleshooting

If you encounter any issues with your figure:

- **Difficulty in Transformation:** Refer to the transformation steps and video guide. Ensure all parts are correctly aligned and not forced.
- **Loose Joints:** Over time, joints may become loose. This is typical with articulated figures. Gentle manipulation can sometimes improve stability.
- **Missing or Damaged Parts:** Inspect the package contents upon receipt. Contact customer support if any parts are missing or damaged.

Specifications

Feature	Detail
Product Dimensions	7.5 x 3 x 12 inches

Item Weight	8 ounces
ASIN	B00150UKLI
Item Model Number	B00150UKLI
Manufacturer Recommended Age	5 years and up
Manufacturer	Hasbro

Warranty and Support

For warranty information or product support, please refer to the manufacturer's official website or contact their customer service department. Keep your proof of purchase for any warranty claims.

© 2023 Hasbro. All rights reserved. Transformers and all related characters are trademarks of Hasbro.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question