



[Manuals.plus](#) /

› [Teamson Home](#) /

› Teamson Home Madison Freestanding Two-Door Floor Cabinet Model 7060 User Manual

Teamson Home 7060

Teamson Home Madison Freestanding Two-Door Floor Cabinet

Model: 7060 | Brand: Teamson Home

PRODUCT OVERVIEW

The Teamson Home Madison Freestanding Two-Door Floor Cabinet is a versatile storage solution designed to enhance organization in your home. This cabinet features a white finish, a crown molded top, and distinctive arched bottom skirting and legs. It includes a pair of glass doors with chrome knobs that secure with a magnetic latch. Inside, two adjustable shelves provide flexible storage options. Constructed from durable engineered wood and tempered glass, this cabinet is intended to help reduce clutter and maintain a tidy living space.



Image: The Madison Freestanding Two-Door Floor Cabinet, white, positioned in a living room next to a sofa, showcasing its design and utility.

SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- **Secure Fastening:** Always securely fasten the cabinet to a wall using the provided anti-tip hardware to prevent tipping, especially in households with children or pets.
- **Handle with Care:** Exercise caution when handling components with sharp edges or points during assembly.
- **Movement and Handling:** Be cautious when moving or handling the assembled cabinet to avoid damage or injury, particularly due to the engineered wood and tempered glass construction.
- **Weight Limit:** Do not overload the cabinet beyond its specified weight capacity of 100 pounds. Distribute weight evenly across shelves.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support immediately.

- Cabinet Panels (Top, Bottom, Sides, Back)
- Two Glass Doors
- Adjustable Shelves (2)
- Hardware Pack (screws, cam locks, dowels, hinges, door knobs, magnetic latches, shelf pins, anti-tip kit)
- Assembly Instructions Manual

SETUP AND ASSEMBLY

Assembly is required for this product. Detailed, step-by-step instructions and all necessary hardware are included in the package for quick assembly. Please follow the provided instruction manual carefully.

1. **Unpack and Identify:** Carefully unpack all components and hardware. Lay them out on a clean, soft surface to prevent scratches. Identify each part using the diagrams in the included manual.
2. **Assemble Frame:** Follow the instructions to connect the side panels, top, and bottom panels to form the main cabinet frame. Ensure all connections are secure.
3. **Attach Back Panel:** Secure the back panel to the frame.
4. **Install Doors:** Attach the hinges to the glass doors and then to the cabinet frame. Adjust hinges as needed for proper door alignment. Install the chrome door knobs and magnetic latches.
5. **Insert Shelves:** Place the shelf pins into the desired holes and slide the adjustable shelves into position.
6. **Secure to Wall:** For safety, attach the anti-tip hardware to the back of the cabinet and to a wall stud.



Image: A diagram illustrating the dimensions of the cabinet: 25.98" L x 12.99" W x 32.01" H.



Image: The cabinet with its two doors open, revealing the interior with two adjustable shelves and a fixed bottom shelf, holding decorative items.

OPERATING INSTRUCTIONS

- **Opening/Closing Doors:** Gently pull the chrome knobs to open the glass doors. Push the doors firmly to engage the magnetic latches and keep them closed.
- **Adjusting Shelves:** The cabinet features two adjustable interior shelves. To adjust, remove all items from the shelf. Carefully lift the shelf and remove the four shelf pins supporting it. Reinsert the shelf pins into the desired holes at the new height, ensuring they are level, then place the shelf back onto the pins.

MAINTENANCE AND CARE

To maintain the appearance and longevity of your cabinet, follow these care instructions:

- **Cleaning:** Wipe the cabinet surfaces with a dry or slightly damp soft cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the finish or glass.
- **Spills:** Immediately wipe up any spills to prevent moisture damage to the engineered wood.
- **Inspection:** Periodically check all hardware connections to ensure they remain tight. Retighten if necessary.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration of the finish.

TROUBLESHOOTING

If you encounter any issues with your cabinet, consider the following common solutions:

- **Wobbly Cabinet:** Ensure all cam locks, screws, and dowels are fully tightened. Verify that the cabinet is placed on a level surface. Adjust leg levelers if applicable.
- **Doors Not Aligning:** Check the hinge adjustments. Most hinges allow for minor adjustments to align doors horizontally, vertically, and in depth. Refer to the assembly manual for specific hinge adjustment instructions.
- **Magnetic Latches Not Holding:** Ensure the magnetic plates on the doors and the magnets on the cabinet frame are properly aligned. Adjust their position if necessary.
- **Shelves Not Level:** Confirm that the shelf pins are inserted into corresponding holes at the same height on both sides.

For persistent issues or concerns not addressed here, please contact Teamson Home customer support.

SPECIFICATIONS

Model Number	7060
Dimensions (D x W x H)	12.99" x 25.98" x 32.01" (33 cm x 66 cm x 81.3 cm)
Material	Engineered Wood, Tempered Glass
Color	White
Weight Capacity	100 Pounds (evenly distributed)
Number of Doors	2
Number of Shelves	3 (1 fixed bottom, 2 adjustable)
Installation Type	Freestanding



Image: A detailed diagram indicating the length, width, and height measurements of the cabinet, including internal shelf dimensions.

WARRANTY AND SUPPORT

Manufacturer Warranty: This product comes with a 1-year warranty covering manufacturing defects. Free replacement parts will be provided to address such defects.

Customer Support: For warranty claims, missing parts, or any questions regarding assembly or product use, please contact Teamson Home customer service. Refer to the contact information provided in your original product packaging or visit the official Teamson Home website for support details.