Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Disney Interactive 005115

Ultimate Band - Nintendo DS User Manual

Model: 005115 | Brand: Disney Interactive

1. Introduction

Welcome to Ultimate Band for Nintendo DS! This game puts you on the fast track to rock 'n' roll stardom, allowing you to play and perform like a true rock star. Whether you prefer solo acts or forming a full-fledged band with friends, Ultimate Band offers a dynamic musical experience. Learn to master the guitar, bass guitar, and drums using only your D-pad and stylus, advancing your music career from local cafes to international venues.



Figure 1: The game box art for Ultimate Band on Nintendo DS, featuring cartoon band members playing various instruments including drums, guitar, and microphone.

2. Getting Started

2.1. System Requirements

- Nintendo DS, DS Lite, DSi, DSi XL, 3DS, 2DS, New 3DS, New 2DS XL system.
- Ultimate Band Nintendo DS Game Card.
- Stylus for gameplay.

2.2. Inserting the Game Card

1. Ensure your Nintendo DS system is powered off.
2. Locate the Game Card slot on your Nintendo DS system.

3. Insert the Ultimate Band game card firmly into the slot until it clicks into place.
4. Power on your Nintendo DS system. The game icon should appear on the touch screen.
5. Tap the game icon to begin playing.

3. Gameplay Overview

Ultimate Band allows players to experience the thrill of performing in a band. The game features rhythm-based gameplay where players use the D-pad and stylus to hit notes in time with the music.

3.1. Instrument Choices

Players can choose from four unique instruments:

- **Lead Guitar:** Master intricate solos and riffs.
- **Bass Guitar:** Lay down the rhythmic foundation.
- **Rhythm Guitar:** Provide the core chord progressions.
- **Drums:** Keep the beat and drive the band's energy.

3.2. Game Modes

The game offers multiple ways to play:

- **Single Player:** Tackle the music world alone, advancing your career and popularity.
- **Multiplayer:** Connect wirelessly with up to three friends to form a band and perform together.

3.3. Creating Your Own Music

Beyond performing pre-set tracks, players can visit the recording studio to create, perform, and share their own compositions, fostering creative play.

Your browser does not support the video tag.

Video 1: Official trailer for Ultimate Band, showcasing gameplay, character customization, and various musical instruments being played in different virtual venues.

4. Key Features

- **Four Instrument Choices:** Play up to four unique instruments including the lead guitar, bass guitar, rhythm guitar and drums.
- **Plenty of Tracks:** Rock out and perform over 15 music tracks by top artists in rhythm gameplay.
- **Make Your Own Music:** Create, perform and share your own compositions in the recording studio with creative play.
- **Multiple Gameplay Options:** Tackle the music world alone or with your favorite band-mates over a wireless connection.
- **DGamer Functionality Included:** Disney's all-new online community exclusively for Disney gamers DGamer allows players to create a unique 3-D avatar, personalize your profile, unlock exclusive Disney collectibles, track your in-game achievements and chat with your friends using the Nintendo Wi-Fi Connection on your DS.

5. Specifications

Platform:	Nintendo DS
Number of Players:	1 (single-player), up to 4 (wireless multiplayer)

Release Date:	November 25, 2008
ESRB Rating:	Everyone
Item Model Number:	005115
UPC:	712725005115
Dimensions:	0.6 x 4.9 x 5.3 inches
Item Weight:	4.1 ounces

6. Troubleshooting

6.1. Game Not Starting

- Ensure the game card is fully inserted into the Nintendo DS slot.
- Clean the gold contacts on the back of the game card with a soft, dry cloth.
- Try inserting another Nintendo DS game to confirm the system is functioning correctly.

6.2. Wireless Connection Issues

- Ensure all Nintendo DS systems are within close proximity for optimal wireless connection.
- Check that all systems have sufficient battery life.
- Restart all Nintendo DS systems involved in the multiplayer session.

7. Customer Support

For further assistance or technical support regarding Ultimate Band for Nintendo DS, please contact Disney Interactive customer service. Refer to the official Disney Interactive website for contact information and frequently asked questions.
Note: Keep your game card and Nintendo DS system in a clean, dry environment to ensure longevity and optimal performance.

© 2008 Disney Interactive. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B001570VAG

More documents and user manuals: **https://manuals.plus/**