Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Travel Blue 111

Travel Blue Security Money Belt Model 111 Instruction Manual

Introduction

The Travel Blue Security Money Belt Model 111 is designed to secure your valuables such as passports, cash, and cards during travel. Its discreet design allows it to be worn comfortably under clothing, providing an extra layer of protection against theft. This manual provides essential information on how to set up, use, and maintain your money belt.

Setup Instructions

1. **Unpack:** Carefully remove the money belt from its packaging.
2. **Adjust the Waist Strap:** Locate the adjustable buckle on the belt. Thread the strap through the buckle to achieve a snug yet comfortable fit around your waist. Ensure the belt is not too tight to allow for comfortable movement and breathing.
3. **Positioning:** For optimal security, wear the money belt under your outer clothing. The soft, non-woven material is designed for comfort against the skin.



Image: The money belt worn discreetly under clothing.



Image: Detail of the adjustable strap and buckle for secure fitting.

Operating Instructions

1. **Accessing Compartments:** The money belt features two large zippered compartments. Use these to store your passport, cash, credit cards, and other small valuables.
2. **Organizing Contents:** Place flat items like passports and currency in the main compartments. Organize smaller items neatly to prevent bulk and ensure easy access.
3. **Securing Zippers:** Always ensure all zippers are fully closed after accessing your items to prevent anything from falling out.



Image: The money belt displaying its two zippered storage compartments.

Maintenance

- **Cleaning:** The Travel Blue Security Money Belt is designed for hand washing only. Use mild soap and cold water. Do not machine wash, bleach, tumble dry, or iron. Allow to air dry completely before storing or using.
- **Storage:** Store the money belt in a clean, dry place when not in use, away from direct sunlight or extreme temperatures.
- **Inspection:** Periodically inspect the zippers, stitching, and strap for any signs of wear or damage. Discontinue use if significant damage is observed to ensure continued security.

Troubleshooting

- **Discomfort during wear:** Ensure the belt is adjusted correctly and not too tight. The soft material should sit comfortably against your skin. If discomfort persists, try adjusting the position on your waist or the tightness of the

strap.

- **Strap slipping:** Re-adjust the buckle to ensure a firm grip on the strap. The adjustable mechanism is designed to hold the strap securely. If the strap continues to slip, ensure it is threaded correctly through the buckle.
- **Zipper issues:** If a zipper becomes stiff, apply a small amount of zipper lubricant or rub a pencil lead along the teeth. Avoid forcing the zipper, as this can cause damage. If a zipper is broken, the product may need replacement.

Specifications

Model Number	111
Product Dimensions (L x W x H)	27.9 x 5.1 x 52.1 Centimeters
Item Weight	1 Grams
Strap Length	Up to 48 Inches (Adjustable)
Water Resistance	Waterproof
Closure Type	Zipper
Number of Compartments	2 (Zippered)
Material	Soft Non-Woven Fabric
Country of Origin	China

Warranty Information

The Travel Blue Security Money Belt Model 111 comes with a**24-month worldwide guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for any warranty claims. For detailed terms and conditions, refer to the official Travel Blue website or contact customer support.



Image: Product warranty information.

Customer Support

For further assistance, product inquiries, or warranty claims, please contact Travel Blue customer support. Refer to the contact information provided with your product packaging or visit the official Travel Blue website.

Manufacturer Contact Information: TBI HK LTD HWB Service 29/FI Two Exchange Square Hong Kong
You can also visit the Travel Blue Store on Amazon for more information.

© 2024 Travel Blue. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B00159IIWC

More documents and user manuals: **https://manuals.plus/**