

[Manuals.plus](#) /

› [Kaiser](#) /

› Kaiser 205519 Grid Base Board Instruction Manual

Kaiser 205519

Kaiser 205519 Grid Base Board Instruction Manual

Model: 205519

1. INTRODUCTION AND OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Kaiser 205519 Grid Base Board. This product is designed to provide a stable and precise base for photographic setups, featuring a matte gray laminated surface with a printed grid for accurate positioning.




Figure 1.1: Kaiser 205519 Grid Base Board. This image displays the matte gray laminated surface, the integrated grid with inch/cm scale, and the base for column attachment.

Please read this manual thoroughly before using the product to ensure correct usage and to maximize its lifespan.

2. PRODUCT FEATURES

- **Matte Gray Laminated Surface:** Provides a low-glare, durable working area.
- **Mounted Base for Column Attachment:** Securely integrates with compatible photographic columns.
- **Printed Fine Grid with Inch/CM Scale:** Facilitates precise positioning and alignment of subjects.
- **Integrated Spirit Level:** Ensures the base board is perfectly horizontal for accurate work.
- **Individually Height-Adjustable Feet:** Allows for leveling on uneven surfaces and fine-tuning height.
- **Dimensions:** Approximately 31.5 x 23.6 x 1.3 inches (800 x 600 x 32 mm).

3. SETUP

1. **Unpacking:** Carefully remove the Grid Base Board from its packaging. Inspect for any signs of damage during transit.
2. **Placement:** Position the base board on a stable, flat surface where it will be used.
3. **Attaching a Column (if applicable):** Align the base of your compatible photographic column with the mounted base on the grid board. Secure the column using the appropriate fasteners or locking mechanisms provided with your column (refer to your column's manual for specific instructions).
4. **Leveling the Board:**
 - Locate the integrated spirit level on the base board.
 - Adjust the individually height-adjustable feet located on the underside of the board. Turn the feet clockwise to lower and counter-clockwise to raise.
 - Continue adjusting until the bubble in the spirit level is centered, indicating a perfectly level surface.

4. OPERATING INSTRUCTIONS

The Kaiser 205519 Grid Base Board is designed for precision in photography and other applications requiring accurate positioning.

- **Using the Grid:** The printed fine grid with inch/cm scale allows for precise placement of objects. Use the grid lines to align subjects symmetrically or to measure distances accurately.
- **Maintaining Level:** Periodically check the spirit level, especially if the board has been moved or if heavy objects have been placed on it, to ensure it remains perfectly level. Re-adjust the feet as necessary.

5. MAINTENANCE

- **Cleaning:** Wipe the laminated surface with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaning solution can be used. Avoid harsh chemicals or abrasive materials that could damage the surface or grid markings.
- **Storage:** When not in use, store the base board in a dry, stable environment, away from extreme temperatures or humidity.
- **Inspection:** Regularly inspect the adjustable feet and the column mounting area for any signs of wear or damage. Ensure all components are secure.

6. TROUBLESHOOTING

- **Board is not level:**

Check the spirit level. Adjust the individually height-adjustable feet until the bubble is centered. Ensure the surface beneath the board is stable.
- **Column feels unstable:**

Verify that the column is correctly seated and secured in the mounted base. Refer to your column's instruction manual for proper attachment procedures. Ensure all fasteners are tightened appropriately.
- **Grid markings are unclear:**

Clean the surface of the base board with a soft, damp cloth to remove any dust or debris that may be obscuring the grid lines.

7. SPECIFICATIONS

Feature	Detail
Model Number	205519
Brand	Kaiser
Surface	Matte gray laminated
Grid	Printed fine grid with inch/cm scale
Leveling	Integrated spirit level, individually height-adjustable feet
Approximate Dimensions (L x W x H)	31.5 x 23.6 x 1.3 inches (800 x 600 x 32 mm)
Product Weight	10.25 kg (22.6 lbs)

8. WARRANTY AND SUPPORT

For warranty information or technical support regarding your Kaiser 205519 Grid Base Board, please contact Kaiser customer service directly. Details can typically be found on the manufacturer's official website or on the product packaging.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question