



[Manuals.plus](#) /

> [WENKO](#) /

> WENKO Under Sink Organizer Instruction Manual

WENKO 2768010100

WENKO Under Sink Organizer Instruction Manual

Model: 2768010100

1. PRODUCT OVERVIEW

The WENKO Under Sink Organizer is a versatile and expandable storage solution designed to maximize space in kitchen and bathroom cabinets, particularly under sinks. Its adjustable two-tier design accommodates various pipe configurations and storage needs, making it ideal for organizing cleaning supplies, toiletries, and other household items. Constructed from sturdy aluminum and durable plastic panels, this organizer offers a stable and customizable storage system.



Figure 1: Front view of the WENKO Under Sink Organizer.

2. PACKAGE CONTENTS

Please verify that all components are present before beginning assembly.

- Shelf rack components (frames, expandable poles)
- 10 plastic panels
- Hardware (for assembly)
- Instruction manual

3. SPECIFICATIONS

Brand	WENKO
Model Name	Under Sink Organizer
Model Number	2768010100

Product Dimensions	32.28"D x 11.02"W x 15.35"H (Expanded)
Expandable Length	17.7 to 31.5 inches
Number of Shelves	2
Material	Aluminum (frame), Plastic (panels)
Color	Grey
Assembly Required	Yes

4. SAFETY INFORMATION

- Ensure all parts are securely connected before placing items on the organizer.
- Do not overload the shelves. Distribute weight evenly to maintain stability.
- Keep small components away from children during assembly to prevent choking hazards.
- Avoid using abrasive cleaners or harsh chemicals, as they may damage the finish or material.
- Place the organizer on a flat, stable surface to prevent tipping.

5. SETUP

Assembly of the WENKO Under Sink Organizer is designed to be quick and straightforward, typically taking only a few minutes. Follow these steps for proper installation and adjustment:

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, flat surface. Verify all listed package contents are present.
2. **Assemble Side Frames:** Connect the horizontal poles to the vertical side frames. Ensure they click securely into place.
3. **Adjust Length:** The organizer is expandable from 17.7 to 31.5 inches. Gently pull the horizontal poles to extend the frame to your desired length, fitting the width of your cabinet space.
4. **Install Plastic Panels:** Place the plastic panels onto the horizontal poles. These panels are designed to be customizable. You can adjust their position or remove individual panels to accommodate pipes, drains, or other obstacles under your sink.
5. **Adjust Shelf Height:** The side frames feature multiple slots, allowing you to choose from 11 different height levels for each shelf. Select the appropriate height for your items and pipe clearance.
6. **Final Check:** Once assembled, gently push down on the shelves to ensure all connections are secure and the organizer is stable.



Figure 2: Detail of the adjustable shelf and pole connection points.



Figure 3: Illustrates the expandable poles and panel placement.

6. OPERATING INSTRUCTIONS (USAGE)

The WENKO Under Sink Organizer is designed for flexible storage under various cabinets. Its primary function is to create organized, multi-level storage in spaces often obstructed by plumbing.

- **Placement:** Position the assembled organizer under your kitchen or bathroom sink. Adjust its length and shelf heights as needed to fit around pipes and maximize available space.
- **Customization:** Utilize the 10 plastic panels to create solid shelf surfaces. Panels can be removed or repositioned to create gaps for vertical pipes or to accommodate taller items on the lower shelf.
- **Storage:** Use the two tiers to store cleaning supplies, sponges, towels, toiletries, small appliances, or other items. The open design allows for easy access and visibility of stored goods.
- **Versatility:** While primarily for under-sink use, the organizer can also be used in other cabinets or on countertops where adjustable, multi-tier storage is beneficial.



Figure 4: Organizer installed under a kitchen sink, showing items stored.



Figure 5: Organizer demonstrating clearance for sink pipes.

7. MAINTENANCE AND CARE

To ensure the longevity and appearance of your WENKO Under Sink Organizer, follow these simple care instructions:

- **Cleaning:** Wipe down the aluminum frame and plastic panels with a soft, damp cloth and mild soap. Rinse thoroughly with clean water and dry immediately to prevent water spots or residue buildup.

- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, or strong chemical detergents, as these can scratch or damage the surfaces.
- **Regular Inspection:** Periodically check all connections and poles to ensure they remain secure and stable. Tighten if necessary.
- **Ventilation:** Ensure adequate ventilation in the cabinet to prevent moisture buildup, especially if storing damp items.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Organizer feels unstable or wobbly.	Connections are not fully secured; uneven weight distribution; not placed on a flat surface.	Ensure all poles are fully extended and locked into place. Verify plastic panels are seated correctly. Distribute items evenly across the shelves. Place the organizer on a level surface.
Plastic panels fall off or do not stay in place.	Panels not properly seated on the poles; poles not fully extended.	Ensure the panels are firmly pressed down onto the horizontal poles. Confirm the poles are extended to their maximum stable length for the cabinet width.
Organizer does not fit under the sink.	Incorrect length or height adjustment; pipes obstructing placement.	Adjust the expandable length of the organizer to fit the cabinet width. Utilize the 11 height levels to position shelves above or below pipes. Remove or reposition plastic panels to create clearance for plumbing.

9. WARRANTY AND SUPPORT

WENKO products are manufactured with quality and durability in mind. For specific warranty information regarding your Under Sink Organizer, please refer to the documentation included with your purchase or visit the official WENKO website.

If you encounter any issues or require assistance with your product, please contact WENKO customer support:

- **Online Support:** Visit the [WENKO Store on Amazon](#) for FAQs and product information.
- **Contact Information:** Refer to your product packaging or the official WENKO website for the most current contact details (phone, email, or contact form).

