Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Cadillac Deville

2002 Cadillac Deville Owner's Manual

Your comprehensive guide to operating and maintaining your vehicle.

Introduction

This manual contains important information regarding the operation, maintenance, and safety of your 2002 Cadillac Deville. Please read it thoroughly to ensure proper use and care of your vehicle. Keep this manual in your vehicle for quick reference.



Image: Front cover of the official 2002 Cadillac Deville Owner's Manual. This manual provides detailed instructions for vehicle operation and maintenance.

For your convenience, the manual may be stored in a dedicated case, often found in the glove compartment. This ensures all essential documents are kept together and protected.



Image: A black leather-bound case, typically used to store the owner's manual and other vehicle documents, featuring the Cadillac emblem.

Setup and Initial Familiarization

Before operating your Deville, familiarize yourself with its key components and controls. This section guides you through

initial setup procedures.

Dashboard and Controls

- **Ignition System:** Insert the key and turn to the 'ON' position to power the vehicle's electrical systems.
- **Instrument Panel:** Understand the gauges and indicator lights, including speedometer, tachometer, fuel gauge, and warning lights. Refer to the manual for specific light meanings.
- **Steering Wheel Controls:** Locate controls for cruise control, audio, and horn.

Seating and Mirrors

- **Seat Adjustment:** Adjust the driver's seat for optimal comfort and control. Ensure you can comfortably reach pedals and steering wheel.
- **Mirror Adjustment:** Adjust side and rearview mirrors for clear visibility of the surrounding area.

Operating Your Vehicle

This section details the procedures for starting, driving, and parking your 2002 Cadillac Deville.

Starting the Engine

1. Ensure the transmission is in 'PARK' (P) or 'NEUTRAL' (N).
2. Press the brake pedal firmly.
3. Turn the ignition key to 'START' and release once the engine begins to run.

Driving

- **Transmission:** Select 'DRIVE' (D) for normal forward motion. Use 'REVERSE' (R) for backing up.
- **Braking:** Apply steady pressure to the brake pedal to slow down or stop.
- **Lighting:** Use the headlight switch for headlamps, parking lamps, and fog lamps.
- **Climate Control:** Adjust temperature, fan speed, and air distribution using the climate control system.

Parking

1. Shift the transmission to 'PARK' (P).
2. Engage the parking brake.
3. Turn off the engine and remove the key.

For detailed information on customizing vehicle settings and features, refer to the Customer Convenience/Personalization Guide.



Image: Front cover of the 2002 Cadillac Deville Customer Convenience/Personalization Guide, which details customizable features.

Maintenance

Regular maintenance is crucial for the longevity and performance of your Deville. Follow the recommended service

schedule.

Scheduled Maintenance

- **Oil Changes:** Refer to the maintenance schedule for recommended intervals and oil types.
- **Tire Rotation:** Rotate tires every 8,000-12,000 km (5,000-7,500 miles) to ensure even wear.
- **Fluid Checks:** Regularly check engine oil, coolant, brake fluid, power steering fluid, and windshield washer fluid levels.
- **Filter Replacement:** Replace air filter, cabin air filter, and fuel filter as per the maintenance schedule.

Tire Care

- **Tire Pressure:** Maintain correct tire pressure as specified on the driver's side door jamb placard.
- **Tread Depth:** Inspect tire tread for wear indicators. Replace tires when tread depth is insufficient.

Battery Maintenance

Keep battery terminals clean and free of corrosion. Ensure the battery is securely mounted. If the battery requires replacement, use a battery with equivalent specifications.

Troubleshooting

This section provides guidance for common issues you might encounter with your 2002 Cadillac Deville.

Warning Lights

- **Check Engine Light:** If illuminated, it indicates an issue with the engine or emissions system. Consult a qualified service technician.
- **Oil Pressure Light:** If illuminated, immediately stop the vehicle and check the engine oil level. Do not drive with low oil pressure.
- **Brake System Warning Light:** Indicates a problem with the brake system. Have the vehicle inspected immediately.

Common Issues

- **Flat Tire:** Refer to the manual for instructions on using the spare tire and jack.
- **Dead Battery:** Instructions for jump-starting your vehicle are provided in the manual.
- **Engine Overheating:** If the temperature gauge indicates overheating, pull over safely, turn off the engine, and allow it to cool before checking coolant levels.

Specifications

Key technical specifications for the 2002 Cadillac Deville.

Category	Specification
Engine Type	Northstar 4.6L V8
Fuel Capacity	Approximately 75.7 liters (20 US gallons)
Transmission	4-speed automatic

Category	Specification
Tire Size (Standard)	P225/60R16
Wheelbase	2880 mm (113.4 inches)
Overall Length	5494 mm (216.3 inches)

Note: Specific specifications may vary based on trim level and optional equipment. Refer to your vehicle's original documentation for precise details.

Warranty Information

Your 2002 Cadillac Deville came with a limited warranty. Details regarding coverage, duration, and exclusions are provided in the separate Warranty booklet.



Image: Front cover of the 2002 Cadillac Warranty booklet, detailing the terms and conditions of the vehicle's warranty.

It is important to review this document to understand your rights and responsibilities as a vehicle owner concerning warranty claims. Keep proof of all maintenance performed to ensure warranty validity.

Support and Service

For further assistance, service, or parts, please contact an authorized Cadillac dealership. They have trained technicians and genuine parts to ensure your vehicle receives the best care.

- **Authorized Dealerships:** Locate your nearest authorized Cadillac service center for professional maintenance and repairs.
- **Customer Service:** For general inquiries or assistance, refer to the contact information provided in your original vehicle documentation or on the official Cadillac website.

Always use genuine Cadillac parts or approved equivalents for repairs and replacements to maintain vehicle performance and safety standards.

This manual is intended for informational purposes only and should be used in conjunction with the physical owner's manual provided with your vehicle.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0015VLZR0

More documents and user manuals: **https://manuals.plus/**