

[Manuals.plus](#) /

› [Case Logic](#) /

› Case Logic PLS-14 14-Inch Neoprene Laptop Sleeve Instruction Manual

Case Logic PLS-14

Case Logic PLS-14 14-Inch Neoprene Laptop Sleeve Instruction Manual

INTRODUCTION

The Case Logic PLS-14 is a form-fitting neoprene sleeve designed to protect laptops with up to a 14-inch display. Its slimline design allows for standalone use or placement within a larger bag. This manual provides instructions for proper usage, care, and maintenance to ensure the longevity and effectiveness of your laptop sleeve.



Image showing the Case Logic PLS-14 14-inch neoprene laptop sleeve in black, highlighting its slim profile and zippered closure.

PRODUCT FEATURES

- **Form-fitting Neoprene Material:** Stretches to accommodate most laptops with a 14-inch display, providing a snug and secure fit.
- **Sueded Internal Lining:** Offers additional cushioning and protection for your computer's surface.
- **Zippered Power Pocket:** A dedicated compartment for storing your power adapter and other small accessories.
- **Dedicated USB Drive Pocket:** Located within the accessory compartment, keeping your USB drive safe and easily accessible.
- **Slimline Design:** Allows the sleeve to be used independently or placed inside another bag for enhanced protection.
- **Asymmetrical Zipper:** Provides convenient and easy access to your laptop.

USAGE INSTRUCTIONS

Inserting Your Laptop

1. Ensure your laptop is powered off or in sleep mode before inserting it into the sleeve.
2. Open the asymmetrical main zipper of the sleeve.
3. Gently slide your 14-inch laptop into the main compartment. The neoprene material will stretch to provide a secure, form-fitting hold.
4. Close the main zipper completely to secure your laptop.

Using Accessory Pockets

- **Power Pocket:** Utilize the zippered power pocket to store your laptop's power adapter, charging cables, or other larger accessories.
- **USB Drive Pocket:** Within the accessory compartment, locate the smaller dedicated pocket for your USB drive. This keeps it separate and protected.

The slim design allows the sleeve to be carried on its own or easily slipped into a backpack, briefcase, or tote bag for added protection during travel.

CARE AND MAINTENANCE

To maintain the appearance and protective qualities of your Case Logic PLS-14 laptop sleeve, follow these care instructions:

- **Cleaning:** For minor dirt or spills, wipe the exterior neoprene surface with a damp cloth and mild soap. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the sleeve to air dry completely before reinserting your laptop or storing it. Do not use direct heat sources like hair dryers.
- **Storage:** Store the sleeve in a cool, dry place away from direct sunlight when not in use.
- **Avoid Overstuffing:** Do not overfill the sleeve or its pockets, as this can strain the zippers and material, potentially causing damage.

TROUBLESHOOTING

- **Laptop Does Not Fit:** Ensure your laptop's dimensions (length, width, height) are within the specified limits for a 14-inch display (approximately 13.5 x 1.5 x 10.1 inches). The neoprene material offers some stretch, but exceeding these dimensions may prevent proper closure or damage the sleeve.
- **Zipper Issues:** If a zipper becomes stiff, apply a small amount of zipper lubricant or rub a graphite pencil along the teeth. Avoid forcing the zipper, as this can cause damage.
- **Sleeve Odor:** New neoprene products may have a slight odor. This typically dissipates with air exposure. Air out the sleeve in a well-ventilated area if needed.

SPECIFICATIONS

Attribute	Detail
Brand	Case Logic
Model Number	PLS-14 BLACK (PLS14K)

Color	Black
Compatible Devices	Laptops up to 14 inches
Compatible Device Size Maximum (Internal)	13.5 x 1.5 x 10.1 inches (L x W x H)
Material	Neoprene, Suede
Shell Type	Soft
Water Resistance Level	Water Resistant
Item Dimensions (External)	1.73 x 14.49 x 11.26 inches (L x W x H)
Item Weight	0.6 Pounds
Manufacturer	CASE LOGIC

WARRANTY AND SUPPORT

Warranty Information: The Case Logic PLS-14 laptop sleeve comes with a warranty as labeled by the manufacturer. Please refer to the product packaging or the official Case Logic website for specific warranty terms and conditions.

Customer Support: For further assistance, product inquiries, or support, please visit the official Case Logic store or contact their customer service department.

Official Case Logic Store: [Visit Case Logic Store](#)