

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Sharp](#) /

› [Sharp LC32SB24U 32-Inch 720p LCD HDTV User Manual](#)

## Sharp LC32SB24U

# Sharp LC32SB24U 32-Inch 720p LCD HDTV User Manual

## INTRODUCTION

---

This manual provides essential information for the safe and efficient operation of your Sharp LC32SB24U 32-Inch 720p LCD HDTV. Please read these instructions thoroughly before using your television and retain them for future reference. This model features a 32-inch LCD panel with 720p resolution, built-in ATSC/QAM/NTSC tuners, and multiple connectivity options including HDMI and PC input.

## SAFETY INFORMATION

---

Always observe the following safety precautions to prevent electric shock, fire, or damage to the unit.

- Do not expose this apparatus to rain or moisture.
- Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- Only use attachments/accessories specified by the manufacturer.
- Unplug this apparatus during lightning storms or when unused for long periods of time.
- Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way.

## WHAT'S IN THE BOX

---

Verify that all components are present before proceeding with setup.

- Sharp LC32SB24U 32-Inch 720p LCD HDTV
- TV Stand
- Remote Control (with batteries)
- Power Cord
- User Manual (this document)

## SETUP

---

## 1. Attaching the Stand

Carefully place the TV screen-down on a soft, clean surface to prevent scratches. Align the stand with the mounting holes on the bottom of the TV and secure it using the provided screws.



Illustration of the TV stand attachment process.

## 2. Connecting Power

1. Connect the power cord to the AC input on the back of the TV.
2. Plug the other end of the power cord into a wall outlet.

## 3. Connecting External Devices

Your Sharp LC32SB24U offers various input options for connecting external devices such as cable boxes, DVD/Blu-ray players, game consoles, and PCs.

- **HDMI:** For high-definition digital audio and video. Connect an HDMI cable from your device to one of the two HDMI inputs on the TV.
- **Component Video:** For high-quality analog video. Connect the Y, Pb, Pr cables (green, blue, red) and the corresponding audio cables (red, white) from your device to the Component Video inputs.
- **Composite Video:** For standard-definition analog video. Connect the yellow video cable and red/white audio cables from your device to the Composite Video inputs.
- **PC Input (VGA):** To use the TV as a computer monitor. Connect a VGA cable from your computer to the PC input, and an audio cable from your computer's audio output to the PC Audio In jack.
- **Antenna/Cable:** Connect your antenna or cable TV coaxial cable to the ANT/CABLE input for over-the-air or standard cable channels.



Rear panel connections for external devices.

## OPERATING THE TV

---

### Remote Control Functions

The included remote control allows you to access all TV functions. Ensure batteries are correctly inserted.

- **POWER:** Turns the TV on or off.
- **INPUT:** Selects the input source (HDMI1, HDMI2, Component, Video, PC, TV).
- **CH +/-:** Changes channels.
- **VOL +/-:** Adjusts the volume level.
- **MUTE:** Mutes or unmutes the sound.
- **MENU:** Opens the on-screen menu for picture, sound, and other settings.
- **Navigation Buttons (Up/Down/Left/Right):** Navigates through menu options.
- **ENTER:** Confirms selections in the menu.
- **EXIT:** Closes the on-screen menu.

### Initial Setup Wizard

The first time you power on the TV, an initial setup wizard will guide you through basic settings such as language, time zone, and channel scanning. Follow the on-screen prompts.

## Picture and Sound Settings

Access the MENU to customize picture (brightness, contrast, color, sharpness) and sound (bass, treble, balance, sound mode) settings to your preference.

## MAINTENANCE

---

Proper care ensures the longevity and performance of your TV.

- **Cleaning the Screen:** Gently wipe the screen with a soft, lint-free cloth. For stubborn marks, dampen the cloth with a small amount of water or a specialized screen cleaner. Never spray cleaner directly onto the screen.
- **Cleaning the Cabinet:** Use a soft, dry cloth to wipe the TV cabinet. Do not use abrasive cleaners or solvents.
- **Ventilation:** Ensure the ventilation openings on the back of the TV are not blocked to prevent overheating.
- **Power Cord:** Regularly check the power cord for any damage. If damaged, replace it immediately with an authorized part.

## TROUBLESHOOTING

---

Before contacting customer support, try the following solutions for common issues.

Problem	Possible Solution
No power	Ensure the power cord is securely plugged into the TV and a working wall outlet. Check if the power outlet is active.
No picture, but sound is present	Check the input source selection. Ensure the external device is powered on and connected correctly.
No sound, but picture is present	Check the volume level and ensure the TV is not muted. Verify audio cable connections for external devices.
Remote control not working	Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.
Poor picture quality	Adjust picture settings (brightness, contrast, sharpness). Check antenna or cable connections. For external devices, ensure you are using appropriate cables (e.g., HDMI for best quality).

## SPECIFICATIONS

---

Technical details for the Sharp LC32SB24U LCD HDTV.

Feature	Detail
Model Number	LC32SB24U
Screen Size	32 Inches
Display Technology	LCD
Resolution	720p (1366 x 768)

Feature	Detail
Aspect Ratio	16:9
Contrast Ratio	800:1
Brightness	500 cd/m2
Response Time	6 Milliseconds
Viewing Angle	160° (Horizontal) x 150° (Vertical)
Tuners	ATSC, QAM, NTSC
HDMI Inputs	2
Other Inputs	Component Video (2), Composite Video (2), S-Video, VGA (PC Input)
Audio Output	Digital Audio Out (Optical)
Item Weight	29.8 Pounds

## WARRANTY AND SUPPORT

---

Your Sharp LC32SB24U LCD HDTV comes with a limited warranty.

- **Warranty Period:** 1 Year for Parts, 90 Days for Labor.
- This warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or external causes.

For technical assistance, warranty claims, or to purchase replacement parts, please contact Sharp customer support. Refer to the official Sharp website or your purchase documentation for current contact information.

You can visit the official Sharp store for more product information:[Sharp Official Store](#)