

Gerber D606225

Gerber Plumbing Wall Mount Tub Spout with Diverter Instruction Manual

Model: D606225

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your Gerber Wall Mount Tub Spout with Diverter, Model D606225. Please read this manual thoroughly before beginning installation or use to ensure proper function and longevity of the product. Retain this manual for future reference.

2. SAFETY INFORMATION

- Always turn off the main water supply before installing or servicing any plumbing fixture.
- Wear appropriate personal protective equipment, such as safety glasses and gloves, during installation.
- If you are unsure about any part of the installation process, consult a qualified plumber.
- Do not overtighten connections, as this may cause damage to the product or plumbing.
- Ensure all connections are secure and leak-free before restoring water supply.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation. If any parts are missing or damaged, do not proceed with installation and contact Gerber customer support.

- Gerber Wall Mount Tub Spout with Diverter (Model D606225)
- Mounting hardware (typically includes an adapter for 1/2 inch copper or 1/2 inch IPS stub out nipple)

4. SETUP AND INSTALLATION

Tools Required:

- Adjustable wrench or pipe wrench
- Plumber's tape (thread seal tape)

- Soft cloth

Installation Steps:

1. **Turn off Water Supply:** Locate the main water shut-off valve for your home or the specific bathroom and turn it off. Open a nearby faucet to relieve any remaining water pressure.
2. **Remove Old Tub Spout (if applicable):** If replacing an existing tub spout, loosen any set screws or unscrew the old spout counter-clockwise from the wall pipe. Clean the area around the stub out nipple.
3. **Prepare the Stub Out Nipple:** Ensure the 1/2 inch copper or 1/2 inch IPS stub out nipple extending from the wall is clean and free of debris. Apply plumber's tape clockwise around the threads of the stub out nipple.
4. **Install the New Tub Spout:** Carefully thread the new Gerber tub spout onto the stub out nipple. Turn clockwise by hand until it is snug.
5. **Align and Tighten:** Use an adjustable wrench to gently tighten the tub spout until it is securely fastened and properly aligned. Avoid overtightening. The spout should be flush against the wall.
6. **Restore Water Supply:** Slowly turn the main water supply back on. Check for any leaks around the newly installed tub spout. If leaks occur, turn off the water, re-tighten, and re-check.



Figure 1: Gerber Wall Mount Tub Spout with Diverter in Chrome Finish. This image displays the Gerber Wall Mount Tub Spout, featuring a polished chrome finish and an integrated diverter knob on top. The spout is designed for wall-mounted installation.

5. OPERATING INSTRUCTIONS

The Gerber Wall Mount Tub Spout features an integrated diverter for easy control of water flow.

- **To Fill the Tub:** Ensure the diverter knob on top of the spout is in the down position. Water will flow directly from the spout into the tub.
- **To Use the Showerhead:** Pull the diverter knob upwards. This action redirects the water flow from the tub spout to your showerhead.
- **To Return to Tub Flow:** Push the diverter knob back down. Water will resume flowing from the tub spout.

The diverter is designed for easy pull-up, pop-down operation, providing a smooth transition between tub and shower functions.

6. MAINTENANCE

Proper care and maintenance will help preserve the finish and functionality of your tub spout.

- **Cleaning:** Clean the chrome finish regularly with a soft, damp cloth. For stubborn spots, use a mild soap and water solution. Rinse thoroughly and dry with a soft cloth to prevent water spots.
- **Avoid Harsh Cleaners:** Do not use abrasive cleaners, scouring pads, ammonia-based cleaners, or cleaners containing bleach, acids, or alcohol. These can damage the chrome finish and void the warranty.
- **Diverter Care:** If the diverter mechanism becomes stiff, a small amount of silicone-based lubricant can be applied to the moving parts.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Water leaks from the base of the spout.	Loose connection to the stub out nipple; insufficient plumber's tape.	Turn off water supply. Unscrew the spout, reapply plumber's tape to the threads, and re-tighten the spout securely.
Diverter does not fully redirect water to the showerhead.	Low water pressure; debris in diverter mechanism; worn diverter seal.	Check household water pressure. Clean the diverter mechanism if accessible. If the issue persists, the diverter seal may need replacement. Contact Gerber support.
Diverter knob is stiff or difficult to operate.	Mineral buildup; lack of lubrication.	Clean the diverter area. Apply a small amount of silicone-based lubricant to the moving parts of the diverter.

8. SPECIFICATIONS

Feature	Detail
Brand	Gerber
Model Name	Tub Spout

Feature	Detail
Model Number	D606225
Mounting Type	Wall Mount
Finish Type	Chrome
Material	Chrome (Handle Material: Copper)
Spout Reach	5 Inches
Spout Height	3.13 Inches
Item Weight	15.2 Ounces
Installation Type	Single Hole
UPC	019934028363



9. WARRANTY INFORMATION





This Gerber product is covered by a **Limited Lifetime Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the official Gerber warranty documentation or contact Gerber customer service.

10. SUPPORT AND CONTACT

For technical assistance, replacement parts, or warranty claims, please contact Gerber customer support through their official website or the contact information provided with your purchase documentation. When contacting support, please have your product model number (D606225) and purchase date available.

Related Documents - D606225

	<p>Gerber Plumbing Fixtures Limited Lifetime Warranty Information</p> <p>Official limited lifetime warranty details for Gerber Plumbing Fixtures LLC products, covering kitchen and bath faucets, valves, and accessories. Learn about warranty terms, exclusions, and how to obtain service.</p>
	<p>Gerber Single Handle Kitchen Faucet Installation Guide and Product Information</p> <p>Comprehensive guide for Gerber single handle kitchen faucets, covering product overview, installation procedures, maintenance tips, and troubleshooting. Features various models including pull-down and bar faucets.</p>

	<p>Gerber Plumbing Fixtures Limited Lifetime Warranty</p> <p>Details the limited lifetime warranty provided by Gerber Plumbing Fixtures LLC for kitchen and bath faucets, bath accessories, and valves. Covers warranty terms, exclusions, conditions, and how to obtain service.</p>
	<p>Gerber Northerly Single Handle Pull-Down Prep Faucet Installation Guide</p> <p>Detailed installation instructions and troubleshooting guide for the Gerber Northerly Single Handle Pull-Down Prep Faucet. Learn how to properly install and maintain your new faucet.</p>
	<p>Gerber Dimension 200 Router/Engraver: User Manual & Operation Guide</p> <p>Explore the capabilities of the Gerber Dimension 200, a powerful router and engraver for 3D signage and ADA-compliant graphics. This manual covers installation, operation, safety, and maintenance for the Dimension 200 system and its associated GRAPHIX ADVANTAGE and ART Path software.</p>
	<p>Gerber Two Piece Toilet Installation Manual</p> <p>Step-by-step installation guide for Gerber two-piece toilets, covering tank-to-bowl assembly and important care instructions.</p>