

GROHE 28631000

GROHE Relaxa Plus Soap Dish (Model 28631000) Instruction Manual

INTRODUCTION

This manual provides instructions for the installation, operation, and maintenance of your GROHE Relaxa Plus Soap Dish, Model 28631000. This soap dish is designed for use with GROHE hand shower bars 28 620 (24") or 28 621 (40"). Please read these instructions carefully before installation and use to ensure proper function and longevity of the product.

SETUP

The GROHE Relaxa Plus Soap Dish is designed for easy installation onto compatible GROHE shower bars. Ensure you have a GROHE hand shower bar model 28 620 or 28 621 before proceeding with installation.

Installation Steps:

1. Identify the compatible GROHE shower bar (models 28 620 or 28 621).
2. Slide the soap dish onto the shower bar from either end. The design allows for smooth movement along the bar.
3. Position the soap dish at your desired height. The internal friction mechanism will hold it securely in place.
4. Ensure the soap dish is level and securely attached before placing items on it.




Image 1: The GROHE Relaxa Plus Soap Dish (Model 28631000) attached to a shower bar. This image illustrates the product's appearance and how it integrates with a shower bar, demonstrating its height-adjustable feature.

OPERATING

The GROHE Relaxa Plus Soap Dish provides a convenient storage solution for soap or other small shower items. Its height-adjustable design allows you to customize its position on the shower bar for optimal accessibility.

Usage:

- Place your bar soap or small shower accessories directly onto the plastic soap dish.
- To adjust the height, gently slide the soap dish up or down the shower bar to your preferred position.
- The dish is designed with drainage slots to prevent water accumulation and keep soap dry.

MAINTENANCE

To ensure the longevity and appearance of your GROHE Relaxa Plus Soap Dish, regular cleaning is recommended. The product features a durable plastic construction and a GROHE StarLight finish.

Cleaning Instructions:

1. Clean the soap dish regularly with a soft cloth and a mild, non-abrasive cleaning agent.
2. Avoid using harsh chemicals, abrasive cleaners, or scouring pads, as these can damage the plastic and the Grohe StarLight finish.
3. Rinse thoroughly with clean water after cleaning and dry with a soft cloth to prevent water spots.
4. For stubborn soap residue, a solution of warm water and vinegar can be used, followed by thorough rinsing.

TROUBLESHOOTING

This section addresses common issues you might encounter with your GROHE Relexa Plus Soap Dish.

Common Issues and Solutions:

- **Issue:** Soap dish slides down the bar or does not stay in position.
Solution: Ensure the shower bar is clean and free of soap residue or mineral buildup, which can reduce friction. The soap dish is designed for a snug fit; if it becomes loose over time, inspect the internal gripping mechanism for wear. If the issue persists, contact GROHE customer support.
- **Issue:** Soap residue buildup is difficult to remove.
Solution: Refer to the 'Maintenance' section for recommended cleaning practices. Regular cleaning prevents heavy buildup. For persistent residue, a gentle scrub with a soft brush and a mild cleaning solution may be necessary.

SPECIFICATIONS

Model:	28631000
Material:	Plastic
Color:	Chrome
Dimensions (L x W):	7.63 inches x 1.13 inches
Item Weight:	8 ounces
Compatibility:	Designed for GROHE Hand Shower Bars 28 620 (24") and 28 621 (40")
Finish:	GROHE StarLight

WARRANTY AND SUPPORT

Warranty Information:

GROHE products are manufactured to the highest standards and undergo rigorous quality checks. For specific warranty details applicable to your region and product, please refer to the official GROHE website or contact GROHE customer service directly. Keep your proof of purchase for warranty claims.

Customer Support:

For further assistance, technical support, or spare parts, please visit the official GROHE website or contact their customer service department. Contact information can typically be found on the GROHE website or product packaging.

