

ABUS 26801

ABUS FTS3002 W Sliding Window Lock Instruction Manual

Model: 26801

1. INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your ABUS FTS3002 W Sliding Window Lock. Designed for outward-opening windows, French doors, and sliding windows made of aluminum, wood, or plastic, this lock enhances security by significantly reducing the risk of unauthorized entry. The robust construction features hardened steel components and a high-quality 4-pin cylinder technology for reliable protection.

2. SAFETY INFORMATION

- Read all instructions carefully before installation and use.
- Ensure all mounting screws are securely fastened to prevent loosening over time.
- Keep keys out of reach of children to prevent accidental locking or unlocking.
- Regularly inspect the lock for any signs of wear or damage. Replace if necessary.
- This lock is designed as an additional security measure and should not replace primary locking mechanisms.

3. PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- 1 x Lock Housing
- 1 x Galvanized Housing (Striking Plate)
- 4 x Screws (4.8 x 38 mm)
- 2 x Screws (4.2 x 50 mm)
- 2 x Keys
- 1 x Assembly Instruction (this document)

4. SETUP AND INSTALLATION

The ABUS FTS3002 W lock is designed for straightforward installation. Follow these steps carefully:

4.1 Identify Mounting Location

Choose a suitable location on your window or door frame where the lock housing and striking plate can be securely mounted. Ensure there is sufficient clearance for the bolt to extend and retract without obstruction.



Image 1: Example of the ABUS FTS3002 W lock installed on a wooden window frame, demonstrating proper alignment of the lock body and striking plate when the window is closed.

4.2 Mount the Lock Housing

1. Position the main lock housing on the window frame. Mark the screw holes accurately.
2. Drill pilot holes if necessary, appropriate for the screw size and frame material.
3. Secure the lock housing using the provided 4.8 x 38 mm screws. Ensure it is firmly attached.

4.3 Mount the Striking Plate

1. Close the window or door. Align the galvanized striking plate with the lock housing so that the bolt can extend into the plate's opening.
2. Mark the screw holes for the striking plate.
3. Drill pilot holes if necessary.
4. Secure the striking plate using the provided 4.2 x 50 mm screws. Test the alignment by extending the lock bolt. Adjust if the bolt does not engage smoothly.



Image 2: The ABUS FTS3002 W lock shown installed on a sliding window. A key is inserted into the cylinder, and the bolt is in the retracted (unlocked) position, demonstrating the key operation.

5. OPERATION

The ABUS FTS3002 W lock features a simple and effective locking mechanism:

- **To Lock:** Simply close the window or door. The bolt will automatically extend into the striking plate, securing the window. No key is required for locking.

- **To Unlock:** Insert one of the provided keys into the lock cylinder. Turn the key to retract the bolt. The window or door can now be opened. Remove the key after unlocking.

6. MAINTENANCE

To ensure the longevity and optimal performance of your ABUS FTS3002 W lock, follow these maintenance guidelines:

- **Cleaning:** Wipe the lock body with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lubrication:** Periodically apply a small amount of graphite-based lubricant or a specialized lock lubricant into the keyway to ensure smooth operation of the cylinder. Do not use oil-based lubricants as they can attract dust and grime.
- **Inspection:** Regularly check all mounting screws for tightness. Inspect the lock bolt and striking plate for any signs of wear, corrosion, or misalignment.

7. TROUBLESHOOTING

If you encounter issues with your ABUS FTS3002 W lock, consider the following:

- **Lock does not engage:** Check the alignment of the lock housing and striking plate. Ensure the window or door is fully closed. The striking plate may need slight adjustment.
- **Key is difficult to turn:** The lock cylinder may require lubrication. Apply a suitable lock lubricant as described in the maintenance section. Ensure the key is fully inserted.
- **Lock feels loose:** Tighten all mounting screws on both the lock housing and the striking plate. If the frame material is damaged, consider reinforcing the mounting area.

8. SPECIFICATIONS

Feature	Detail
Brand	ABUS
Model Number	26801
Lock Type	Pin Tumbler
Special Feature	Key Unlock
Material	Alloy Steel
Color	White
Dimensions (L x W x H)	2.28 x 2.95 x 1.34 inches (approx. 58 x 75 x 34 mm)
Item Weight	9.9 ounces (approx. 280 grams)
Security Level	ABUS Security Level 5




Image 3: Technical drawing illustrating the precise dimensions of the ABUS FTS3002 W lock in millimeters, useful for installation planning.

9. WARRANTY AND SUPPORT

ABUS provides a **10-year manufacturer's warranty** on the absence of defects in materials and workmanship for the FTS3002 W Sliding Window Lock.

For technical support, warranty claims, or further assistance, please contact ABUS customer service through their official website or the retailer where the product was purchased. Please have your model number (26801) and proof of purchase available.


© 2025 ABUS. All rights reserved.

Related Documents - 26801




[ABUS DF 88 Skylight Lock Installation and Operation Instructions](#)

Comprehensive guide for installing and operating the ABUS DF 88 skylight lock, providing enhanced security for dormer windows. Includes parts list, tools, and step-by-step instructions.

	<p>ABUS 10171551 Product Safety and Usage Instructions</p> <p>Essential safety guidelines and usage instructions for the ABUS 10171551 security hardware, covering general precautions, installation, and maintenance.</p>
	<p>ABUS 6950AM Bicycle Frame Lock: Installation and User Manual</p> <p>Comprehensive guide for installing and using the ABUS 6950AM bicycle frame lock. Includes safety warnings, mounting instructions for different options, operation details, and warranty information.</p>
	<p>ABUS HomeTec Pro CFF3100 Bluetooth Remote Control - User Manual & Instructions</p> <p>Download the official user manual for the ABUS HomeTec Pro CFF3100 Bluetooth remote control. Get detailed instructions on setup, app integration, battery replacement, technical specifications, safety guidelines, warranty information, and disposal procedures.</p>
	<p>ABUS 770A SmartX Fahrradschloss: Montage- und Bedienungsanleitung</p> <p>Umfassende Anleitung für das ABUS 770A SmartX Fahrradschloss mit Alarmfunktion und SmartX-Technologie. Enthält detaillierte Informationen zur Installation, Bedienung, App-Integration und Sicherheitshinweise.</p>
	<p>ABUS U-Lock Combination Reset Guide</p> <p>Learn how to easily reset the combination on your ABUS U-Lock with this step-by-step visual guide. Includes instructions for setting a new personal code.</p>

Documents - ABUS – 26801




[Global Express Guaranteed Service Guide - International Shipping Policies](#)

Comprehensive guide detailing policies, regulations, and procedures for Global Express Guaranteed (GXG) international expedited delivery services offered by the United States Postal Service in partnership with FedEx Express. Covers shipping requirements, prohibited items, insurance, and form instructions.

lang:en score:25 filesize: 19.87 M page_count: 1159 document date: 2012-06-12



AOS-W 3.4.2 Command Line Interface



[\[pdf\]](#) User Manual Reference Guide Specifications Guide


Alcatel Lucent Command Line Interface Reference Guide Version 3 4 2 Dec 09 CLI by command Aruba Networks Technical Publications Dept OAW 4x04 AOS W support alcadis nl Support files OmniAccess series EOS Manuals |||

AOS-W 3.4.2 Command Line Interface Reference Guide Copyright 2009 Alcatel-Lucent. All rights res ... o infringement of copyright on behalf of Cisco Systems or Nortel Networks. www.alcatel-lucent.com **26801** West Agoura Road Calabasas, CA 91301 AOS-W 3.4.2 Command Line Interface Reference Guide 051...

lang:en score:18 filesize: 4.85 M page_count: 1228 document date: 2012-05-21



Alcatel-Lucent 5.0 Command Line Interface



[\[pdf\]](#) User Manual Reference Guide Specifications Guide

ArubaOS Command Line Interface Reference Guide Version 5 0 June 2010 CLI by command Aruba Networks Technical Publications Dept OAW 4x04 AOS W support alcadis nl Support files Alcatel Lucent OmniAccess series EOS Manuals 2 |||

Alcatel-Lucent 5.0 Command Line Interface Reference Guide Copyright 2010 Alcatel-Lucent. All rig ... o infringement of copyright on behalf of Cisco Systems or Nortel Networks. www.alcatel-lucent.com **26801** West Agoura Road Calabasas, CA 91301 Alcatel-Lucent 5.0 Command Line Interface Reference Gui...

lang:en score:18 filesize: 6.69 M page_count: 1122 document date: 2010-06-07



AOS-W 3.4.1 Command Line Interface



[\[pdf\]](#) User Manual Reference Guide Specifications Guide

Alcatel Lucent Command Line Interface Reference Guide Version 3 4 1Feb 09 CLI by command Aruba Networks Technical Publications Dept AOS W 1 What s New In The following commands have been added in the Modified Commands were modified NOTE Telnet access is disabled default on switches To enable enter telnet cli v3 Commandline support alcadis nl Support files OmniAccess OAW 6000 EOS Manuals

AOS-W 3.4.1 Command Line Interface Reference Guide Copyright 2009 Alcatel-Lucent. All rights res ... o infringement of copyright on behalf of Cisco Systems or Nortel Networks. www.alcatel-lucent.com **26801** West Agoura Road Calabasas, CA 91301 AOS-W 3.4.1 Command Line Interface Reference Guide 051...

lang:en score:14 filesize: 6.28 M page_count: 1222 document date: 2009-10-19




[pdf]

26801 ger DE mobil abus de abusproductsheet 76654 |||

...

lang:en score:13 filesize: 53.65 K page_count: 2 document date: 2022-09-26



[pdf] User Manual Catalog

PRIJSLIJST TARIF PRICELIST Toussaint be Cette mention fait référence à l anse Manual cover to

protect the keyhole from dirt and corrosion Portée radio 400 m 10 % champ libre

nGXWQnc0WirzL9ooJgvqsv3G11oEE7qE9OiOo9k4 toussaint catalogues |||

PRIJSLIJST TARIF PRICELIST ALGEMENE CATALOGUS 2020 CATALOGUE

GNRAL 2020 GENERAL CATALOGUE 20 ... B CL/DFNLI FTS3002 S AL0125 EAN

4003318 Art.-Grp. Familie Family Uitvoering Excutions Variants **26801** 4 78769 0

78768 3 31728 6 0903 0903 0903 0903 Uitvoering Level VE Coloris Degr Finish Lev...


lang:nl score:13 filesize: 26.54 M page_count: 173 document date: 2020-04-16



[Total 911 Magazine: The Ultimate Porsche 911 Publication](#)

Explore the world of the Porsche 911 with Total 911 magazine, featuring in-depth reviews, historical features, owner stories, technical insights, and exclusive access to rare models.

lang:en score:11 filesize: 55.94 M page_count: 116 document date: 2013-12-05



[\[pdf\]](#) Dimension Guide Catalog

Catalogue Quincaillerie 2020 sans prix abus fr content 56532 4839249 file

ABUS France www.abus.com GAMME QUINCAILLERIE C A T A L O G U E 2021

CADENAS CONSIGNATION CYLINDR ... 3002 B CL/DFNLI FTS3002 S KA AL0125

N Article 0019989 0021499 0069805 0069804 0024719 EAN 4003318 **26801** 4

28934 9 78769 0 78768 3 31728 6 Groupe Remise Article 0528 0528 0528 0528 0528

Excutions ...

lang:fr score:10 filesize: 51.27 M page_count: 314 document date: 2021-01-11