#### Manuals+

Q & A | Deep Search | Upload

#### manuals.plus /

- Jung /
- Jung UAE8UPOK6 Network Outlet Insert Instruction Manual

## Jung UAE8UPOK6

# Jung UAE8UPOK6 Network Outlet Insert Instruction Manual

Model: UAE8UPOK6 | Brand: Jung

## 1. Introduction

This manual provides detailed instructions for the installation, operation, and maintenance of the Jung UAE8UPOK6 Network Outlet Insert. This product is designed to provide a reliable network connection point within your electrical system. Please read this manual thoroughly before proceeding with installation or use.

# 2. SAFETY INFORMATION

WARNING: Risk of electric shock. Installation should only be performed by a qualified electrician or a person with appropriate electrical knowledge and experience.

- Always disconnect power at the main circuit breaker before installing or servicing electrical devices.
- Ensure all local and national electrical codes are followed during installation.
- Do not install in wet or damp locations.
- · Verify correct wiring connections to prevent damage to the device or connected equipment.
- · Use appropriate tools for installation.

# 3. PACKAGE CONTENTS

Verify that your package contains the following items:

• Jung UAE8UPOK6 Network Outlet Insert (1 unit)

If any items are missing or damaged, please contact your supplier immediately.

# 4. SETUP AND INSTALLATION

The Jung UAE8UPOK6 Network Outlet Insert is designed for screw-in installation into a standard electrical wall box. Follow these steps for proper installation:

- 1. **Power Disconnection:** Before beginning, ensure the power supply to the installation area is completely disconnected at the main circuit breaker.
- 2. **Prepare Wiring:** Carefully strip the outer jacket of your network cable (e.g., Cat5e, Cat6) to expose the individual twisted pairs. Do not strip the insulation from the individual wires.
- 3. **Connect Wires:** Refer to the color codes marked on the insert's terminals. The insert supports standard network wiring configurations. Insert each individual wire into its corresponding terminal according to the desired wiring standard (e.g., T568A or T568B). The image below illustrates the terminal layout and color markings. Secure the wires firmly.
- 4. **Mount the Insert:** Place the network outlet insert into the wall box. Use the provided screws to secure the insert firmly to the wall box.
- 5. **Install Faceplate (Optional):** If using a decorative faceplate (sold separately), attach it according to its specific instructions.
- 6. **Restore Power:** Once installation is complete and all connections are secure, restore power at the main circuit breaker.




Figure 1: Jung UAE8UPOK6 Network Outlet Insert. This image displays the Jung UAE8UPOK6 network outlet insert. It features an RJ45 port in the center for network cable connection. Around the port, there are clearly marked terminals with

## 5. OPERATING INSTRUCTIONS

Once the Jung UAE8UPOK6 Network Outlet Insert is correctly installed and power is restored, it functions as a standard network connection point.

- 1. **Connect Network Cable:** Insert a standard RJ45 network cable from your device (e.g., computer, printer, smart TV) into the RJ45 port on the front of the installed insert.
- 2. **Verify Connection:** Ensure the cable clicks securely into place. Most network devices will indicate a successful connection with an LED light on the device or the network card.

## 6. MAINTENANCE

The Jung UAE8UPOK6 Network Outlet Insert requires minimal maintenance.

- **Cleaning:** To clean the surface, gently wipe with a soft, dry cloth. Do not use abrasive cleaners, solvents, or excessive moisture, as these can damage the plastic or internal components.
- **Inspection:** Periodically inspect the insert for any signs of physical damage or loose connections. If any issues are found, disconnect power and consult a qualified electrician.

# 7. TROUBLESHOOTING

If you experience issues with your network connection through the Jung UAE8UPOK6 Network Outlet Insert, consider the following:

#### · No Network Connection:

- Ensure the network cable is securely plugged into both the device and the outlet insert.
- Verify that the other end of the network cable (connected to your router/switch) is also secure and functional.
- Check the network cable for any visible damage. Try a different cable if available.
- Confirm that the network equipment (router, switch) is powered on and functioning correctly.
- If you suspect a wiring issue, disconnect power and have a qualified electrician inspect the internal connections of the insert.

## • Slow Network Speed:

- Ensure you are using appropriate network cables (e.g., Cat5e or Cat6 for higher speeds).
- Check your network equipment and internet service provider for potential bottlenecks.

# 8. SPECIFICATIONS

Feature	Detail
---------	--------

Brand	Jung
Model Number	UAE8UPOK6
Product Dimensions (L x W x H)	8.51 cm x 8 cm x 5.99 cm
Weight	140.61 grams
Material	Plastic
Color	Silver
Installation Type	Screw-in
Country of Origin	France
International Article Code	04011377987739

# 9. WARRANTY AND SUPPORT

For information regarding warranty coverage and technical support for your Jung UAE8UPOK6 Network Outlet Insert, please refer to the documentation provided with your purchase or visit the official Jung website. Contact details for customer service are typically available on the manufacturer's website.

© 2023 Jung. All rights reserved. This manual is for informational purposes only.

## **Related Documents - UAE8UPOK6**



JUNG HOME Socket (French/Belgian System) - Operating Instructions and Technical Data

Comprehensive operating instructions and technical specifications for the JUNG HOME socket, French/Belgian system (Art. no. BT..1521FS.. and BT..1521FSE..). Learn about installation, operation, features, and troubleshooting.



Electrical planning with the JUNG Switch Range Configurator in Autodesk Revit

## Electrical Planning with JUNG Switch Range Configurator in Autodesk Revit

A comprehensive tutorial guide on utilizing the JUNG Switch Range Configurator within Autodesk Revit for efficient electrical planning. Covers BIM object creation, product configuration, symbol management, and troubleshooting.



#### JUNG Watch J43C-01-BLACK User Manual

Official user manual for the JUNG Watch model J43C-01-BLACK, providing operating instructions, features, and maintenance information.



## JUNG DALI Gateway TW 2099REGHE: Operating Instructions

Operating instructions and technical data for the JUNG DALI Gateway TW (Art. no. 2099REGHE), a KNX device for DALI lighting control, covering installation, function, operation, and troubleshooting.



#### JUNG ZigBee Wand- / Handsender Kurzanleitung und Kompatibilität

Diese Kurzanleitung von JUNG bietet detaillierte Informationen zur Einrichtung und Nutzung von ZigBee Wand- und Handsendern. Enthält Kompatibilitätslisten für Philips Hue, Osram/Ledvance, dresden elektronik, Innr und IKEA Trådfri sowie eine umfassende FAQ-Liste zur Fehlerbehebung.

DUNG

Floor thermodist Art. no. FTR281

#### JUNG FTR231 Floor Thermostat Operating Instructions

Comprehensive operating instructions for the JUNG FTR231 floor thermostat, detailing installation, functional description, operation, technical specifications, and warranty information for electric underfloor heating systems.

ASPECTANG OWN'S CO.XO Vanadada I BETS Educationate of Balany Todax - 40 200 BDs C Todax - 40 200 BDs C Todax - 40 200 BDs C Todax - 40 200 BDs C