



[Manuals.plus](#) /

› [TAG Heuer](#) /

› TAG Heuer Formula 1 Chronograph Watch User Manual

TAG Heuer CAH1110.BA0850

TAG Heuer Formula 1 Chronograph Watch User Manual

Model: CAH1110.BA0850

INTRODUCTION

This manual provides comprehensive instructions for the proper use, setup, and maintenance of your TAG Heuer Men's CAH1110.BA0850 Formula 1 Chronograph Watch. Please read this manual carefully to ensure optimal performance and longevity of your timepiece.



Figure 1: Front view of the TAG Heuer Formula 1 Chronograph Watch (Model CAH1110.BA0850). This image displays the watch's black dial with three subdials, luminescent hands and markers, a date window, and a unidirectional bezel. The watch is presented on its fine-brushed stainless steel bracelet.

SETUP

1. Setting the Time

1. Unscrew the crown (if applicable) and pull it out to the time-setting position (usually the outermost click).
2. Turn the crown clockwise or counter-clockwise to move the hour and minute hands to the desired time. Ensure you differentiate between AM and PM if the watch has a 24-hour indicator or date function.

3. Push the crown back in and screw it down (if applicable) to secure the water resistance.

2. Setting the Date

The date indication is located between 3 and 4 o'clock.

1. Unscrew the crown (if applicable) and pull it out to the date-setting position (usually the first click).
2. Turn the crown to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement. If the current time falls within this period, set the time outside this range first, then set the date, and finally reset the time.
3. Push the crown back in and screw it down (if applicable) to secure the water resistance.

3. Bracelet Adjustment

The fine-brushed stainless steel bracelet can be adjusted for a comfortable fit. This typically involves removing or adding links. It is recommended to have this procedure performed by a qualified watchmaker or an authorized TAG Heuer service center to prevent damage to the bracelet or clasp.

OPERATING INSTRUCTIONS

1. Chronograph Function

Your watch features a chronograph function with 60-second, 30-minute, and 1/10th-second subdials for precise time measurement.

- **Start:** Press the upper push-button to start the chronograph. The central chronograph second hand will begin to move.
- **Stop:** Press the upper push-button again to stop the chronograph. The elapsed time will be indicated on the subdials.
- **Reset:** After stopping the chronograph, press the lower push-button to reset all chronograph hands to their zero positions.
- **Intermediate Time (Split Time):** Some models allow for intermediate time measurement. Consult your specific model's detailed instructions if this feature is available.

2. Unidirectional Bezel

The watch is equipped with a unidirectional rotating bezel with a scratch-resistant titanium carbide coating. This bezel is designed to rotate only counter-clockwise, preventing accidental extension of dive times.

- To use, align the triangle marker on the bezel with the minute hand at the start of an event (e.g., a dive).
- The minute hand will then indicate the elapsed time against the bezel's scale.

MAINTENANCE AND CARE

1. Water Resistance

Your TAG Heuer Formula 1 watch is water resistant to 660 feet (200 meters), making it suitable for recreational diving. To maintain water resistance:

- Ensure the crown and push-buttons are fully pushed in and screwed down (if applicable) before any contact with water.
- Do not operate the crown or push-buttons when the watch is wet or submerged.
- Rinse the watch with fresh water after exposure to salt water or chlorine.

- Have the water resistance checked annually by an authorized service center.

2. Cleaning

Clean your watch regularly with a soft cloth. For the stainless steel case and bracelet, you can use a soft brush and soapy water, ensuring the crown is fully secured. Rinse thoroughly with fresh water and dry with a soft cloth.

3. Battery Replacement

As a quartz watch, your timepiece is powered by a battery. When the battery is low, the second hand may jump every four seconds (End-of-Life indicator). It is recommended to have the battery replaced by an authorized TAG Heuer service center to ensure proper sealing and water resistance.

4. Service Intervals

Regular servicing by an authorized TAG Heuer service center is recommended every 2-3 years to ensure the watch's optimal performance and longevity, including checking the movement, seals, and water resistance.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch not running or running intermittently.	Low battery.	Replace battery at an authorized service center.
Date not changing at midnight.	Time set incorrectly (AM/PM).	Adjust time to ensure it passes midnight correctly.
Water condensation under crystal.	Loss of water resistance.	Immediately take to an authorized service center for inspection and repair.
Chronograph hands not resetting to zero.	Requires calibration.	Consult the detailed movement instructions or an authorized service center for calibration procedure.

SPECIFICATIONS

- **Model Number:** CAH1110.BA0850
- **Movement:** TAG Heuer Swiss Quartz Movement
- **Case Material:** Solid 41-mm Brushed Stainless Steel
- **Caseback:** Checkered Flag Decorated
- **Bracelet Material:** Fine-brushed Stainless Steel with Diving Extension
- **Crystal:** Scratch-Resistant Sapphire Glass
- **Bezel:** Unidirectional, with Scratch-Resistant Titanium Carbide Coating
- **Hands & Markers:** Luminescent
- **Chronograph:** Yes, with 60-second, 30-minute, and 1/10th-second subdials
- **Date Display:** Yes, between 3 and 4 o'clock
- **Water Resistance:** 200 meters (660 feet), suitable for recreational diving

- **Product Dimensions:** 14.99 x 14.73 x 11.43 cm (5.9 x 5.8 x 4.5 inches)
- **Product Weight:** 907.18 g (2 lbs)
- **Department:** Men's

WARRANTY AND SUPPORT

Your TAG Heuer watch is covered by a manufacturer's warranty against manufacturing defects. For specific warranty terms and conditions, please refer to the warranty card provided with your purchase or visit the official TAG Heuer website. For service, repairs, or technical support, please contact an authorized TAG Heuer service center. You can find a list of authorized service centers on the official TAG Heuer website: www.tagheuer.com/service

